

# **INTELLIS** 7300 SERIES

INSTALLATION AND OPERATION MANUAL

### TABLE OF CONTENTS

1.	Introd	uction
	1.1	Product certification
	1.2	Warnings
	1.3	Description
	1.3.1	Technical specification
	1.4	Principles of operation
	1.4.1	Configuration
	1.4.2	Blocks modes
	1.4.3	Blocks and I/O channels
	1.4.4	DI (Discrete Input) channels
	1.4.5	DO (Discrete Output) channels 13
	1.4.6	AI (Analog Input) channels
	1.4.7	Configuration overview
	1.4.8	Fault state configuration
	1.4.9	Resource block fault state
		parameters
	1.4.10	Discrete output block fault state
		(IFS) parameters
	1.4.11	Standard transducer block fault
		state parameters
	1.4.12	Forcing fault state from an
		auxiliary input
	1.4.13	Testing fault state configuration 20
	1.5	Special features
	1.5.1	Advanced valve diagnostics
	1.5.2	The "Maskable signal"
	1.5.3	Examples of advanced
		diagnostics usage
	1.5.4	Additional diagnostics
	1.5.5	MODULE_IO_SUMMARY parameter24
	1.5.6	OUT_LOAD_STATUS parameter 25
	1.5.7	DIAG_CNTR parameter
2.	Order	guide
3.	Definit	tions
4.	Install	ation 27
	4.1	Mounting27
	4.1.1	Intellis 7300 (the FPAC) electronic
		module overview
	4.1.2	Description of the dipswitch
	4.1.3	Description of the LEDs
	4.1.4	Pneumatic Connections
	4.1.5	Tubing and Fittings 29
	4.1.6	Porting for Falcon Solenoids
	4.1.7	Wiring instructions and examples 29
	4.1.8	FPAC BUS connector pin out 29
	4.2	Calibration
	4.2.1	Configuration and operation
	4.2.2	Installing DD/CF and handheld
		support files

	4.2.3	Configuration examples
	4.2.4	one valve, rotary, simple solenoid 32
	4.2.0	one valve, rotary, dual coil/piezo
	4.2.6	Configuration for example #3: one
	4.2.7	Configuration for example #4: two
		rotary valves, direct and reverse action
	4.2.8	Configuration for example #5: two valves, rotary/linear, monitoring/
	4.2.9	control
		potentiometer
	4.3	Configuration and operation with a FF Handheld or FF Bench Host 64
5.	Field	wiring
	5.1.1	Wiring examples76
	5.1.2	Wiring for example #1: one valve,
	E 1 0	Viring for events 12 and viring for events
	0.1.3	rotary, dual coil/piezo solenoid 77
	5.1.4	Wiring for example #3: one valve,
		linear, with simple solenoid
	5.1.5	Wiring for example #4: two rotary
	F 1 /	valves, direct and reverse action 79
	5.I.6	wiring for example #5: two valves,
	5.1.7	Wiring for example #6: one
		valve, rotary, simple solenoid,
		potentiometer option
6.	Maint	enance and repair82
	6.1	Troubleshooting 82
	6.2	FPAC does not turn on, LEDs do
	10	not light when powered up
	6.3	and firmware version?
	64	Which DD version should Luse? 82
	6.5	How do I perform a factory default? 82
	6.6	FPAC2 lost configuration after
		some time
	6.7	The device is not communicating
		or the Host communication
		statistics is showing errors
	6.8	Blocks' tags on my application
		are different from the references
		011 UIIS IIIdIIUdt

# **INTELLIS** 7300 SERIES INSTALLATION AND OPERATION MANUAL

6.9	Some parameters are showing
	"Error: Dictionary string not found" 83
6.10	Transducer MODE_BLK does
	not go to AUTO 83
6.11	Transducer MODE_BLK =
	AUTO but BLOCK_ERR =
	BlockConfiguration
6.12	Can't write to ACTION FLEMENT
0.12	narameter 8/
613	Cap't write to IO_ASSIGNMENT
0.15	parameter 84
414	The value data pat as to FAII
0.14	The valve does not go to FAIL
/ 1 5	position when FPAC is powered off 84
6.15	The valve does not go to FAIL
	position when communication
	ıs lost
6.16	The valve does not STOP at last
	position when communication
	is lost
6.17	FPAC is not communicating
	with the FF Host
6.18	Indication of valve closed or
	valve opened is wrong
6.19	Valve is not moving when set-point
	is written to the DO block
6.20	D0 block entered IMAN or AUTO
0.20	mode 85
6.21	BKCAL OUT Diparameter is not
0.21	indicating actual value pacifian
( ))	Indicating actual valve position 85
6.ZZ	DI.UUI_D parameter is not
( 00	Indicating actual valve position 86
6.23	Valve UPENED and CLUSED
	indications are inverted
6.24	Analog Input block is not working 86
6.25	Diagnostic parameters that
	measure time are not working 86
6.26	Transducer block is in "LO"
	(Local Override) mode
6.27	Where can I see statistics of the
	FF communication?
6.28	What does MissedViewListScan
	indicate about system operation? 87
6.29	When configuration is changed
	from "Double Action" to "Single
	Action" or vice-versa it does not
	work properly 87
6 30	Resolving problems using status
0.00	and substatus
4 20 1	Discrete output status and
0.30.1	Disci ete output status allu
( 20 2	Substatus
6.3U.Z	Discrete input status and substatus89
6.30.3	Analog Input status and sub-status 89
6.31	Resolving problems using BLUCK_
	ERR (Block Error) parameter
6.31.1	Resource block
6.31.2	Transducer blocks TB1 and TB2
	(Standard Discrete Transducer) 91
6.31.3	Diagnostic Block (TB3 and TB4) 92
6.31.4	Discrete input 92
6.31.5	Discrete output
6.31.6	Analog input
632	Resolving problems using block

	51	5	
alarms	active	parameter	93

7.	Apper	ndix	74
	7.1	Appendix A - Limit switches	
		and potentiometer calibration	74
	7.1.1	Quick test after factory default 9	74
	7.1.2	Cam shaft adjustment when FPAC	
		IS NOT controlling valve position 9	25
	7.1.3	Cam shaft adjustment when FPAC	
		IS controlling valve position	25
	7.1.4	otentiometer calibration	96
	7.2	Appendix B - Dip switch usage 9	?7
	7.2.1	Switch #1 write protect	?7
	7.2.2	Switch #2 simulate enable	8
	7.2.3	Switch #3 factory default	
	<b>–</b> • <i>i</i>	procedure	28
	7.2.4	Deep default	18
	7.2.5	Switch #4 and #5 local	
	70/	Calibration and real time clock 9	19
	/.Z.6	Switch #6 Auxiliary power, nigh	0
	70		19
	7.5	Appendix C - DO. READBACK	າດ
	7 /	Appendix D - Complete list of	10
	7.4	block parameters	າດ
	741	Common definitions and tables 10	0
	742	Complete list of discrete standard	/0
	/	transducer block parameters 10	)2
	7.4.3	Complete list of discrete	
		output block parameters	)7
	7.4.4	Complete list of discrete input	
		block parameters	)9
	7.4.5	Complete list of analog input	
		block parameters11	1
	7.4.6	Complete list of diagnostic	
		transducer block parameters 11	3
	7.4.7	Complete list of resource	
		block parameters11	7
	7.5	Appendix E - wiring instructions	
		for 7345-FC-SRS 12	22
	7.6	Appendix F - Installation in	
		hazardous locations	23
	/./	Appendix G - Installing DD files 12	(3 )0
	/./.	Importing to DeltaV/AMS system 12	:3
	1.1.Z	importing to 475/375 field	57
	70	Appendix H DD Menu tree 12	24
	7.0	Appendix I - Blocks relationship	. /
	1.1	diagram	20
	7 10	Appendix 1 - Cycle time	.0
	7.10	measurement timing diagram	9
	7.11	Appendix K - List of useful	- '
		technical notes	30

### **1 INTRODUCTION**

The Intellis 7300 is a family of industrial discrete valve controllers suited for the demanding applications of today's industry. It connects to any FF compliant control system and is capable of monitoring and controlling up to 2 (two) independent valves with complete diagnostics.

This IOM is valid for FPAC device revision 5 or above (DD 0501 or above). For devices with revision 4 or below (DD 0401 or below), please consult previous versions of this IOM or contact Westlock. This manual is not an introduction on fieldbus technology and is intended for users with previous knowledge on the following subjects:

- Installation and configuration of foundation fieldbus field devices.
- Valve automation, including installation and test of pneumatic valves and actuators.

# 1.1 Product certification

### Hazardous ratings<sup>[1]</sup>

The FPAC is designed in accordance with criteria for NI and IS/FISCO devices. It requires the use of an agency approved barrier in IS applications. For information on the barrier used by Westlock Controls to obtain the agency approvals listed above, appropriate network architecture and segment device limits, refer to Control Drawing WD-11835 located in Appendix E of this document. The FPAC is approved for both Entity and FISCO IS applications. Refer to the tables below for more details and Contact Westlock to obtain the certificates.

### NOTE

 Reference only. Contact Westlock for approvals and certificates.

Certification		
agency	Housing/ type	Rating
EM	73x4 (Resin, Alum, SST) / Intrinsically safe	IS/I/1/ABCD/T4/Ta=80°C
	73x4 (Resin Alum SST) / Non-incendive	NI/I/2/ABCD; S/II,III/2/FG/T4 Ta=60°C TYPE 4X
ATEX	3600 (Resin,Alum,SST) / Intrinsically safe	Pending
IEC	3600 (Resin, Alum, SST) / Intrinsically safe	Pending
	73x4 (Resin, Alum) / Intrinsically safe	Ex ia IIC T4 Gb IP66W
	7345 (Resin) / Intrinsically safe	Ex ia IIC T4 Gb IP66W
INMETRO	73x4 (Resin, Alum) / Non-incendive	Pending
	7345 (Resin) / Non-incendive	Pending
	7379 (Aluminum)/ Explosion proof*	Pending

\* Contact Westlock for more information.

Intrinsically safe parameters for bus connector J2 pins 1, 3

FISCO
Ui = 17.5 V
li = 380 mA
5.32 W
Ci = 5 nF
Li = 10 uH

### 1.2 Warnings

N/A

### **1.3 Description**

1.3.1 Technical specification

### • Fieldbus information

- ITK version: 6.1.1
- PHY compliance: FF-830 FS2.0
- MANUFAC\_ID: 0x574343
- DEV TYPE: 0x0001
- DEV REV: 0x05
- DD REV: 0x01[2]
- No of Blocks: 1xRB, 4xTB, 6xDI, 4xDO, 1xAI
- Block execution time: 30 ms (DI, DO, AI)
- Device class: BASIC
- Default address: 234 (0xEA)
- More at: www.fieldbus.org

### • Fieldbus input

- Connector: J2 (pins 1 and 3)
- Grounding: J3 pin 2 (do not connect cable shield)
- Operating voltage: 9 to 32 VDC (Max 35 VDC) - Bus current: 12 mA (17 mA in high current model
- Non-resettable fuse: 50 mA

### • Discrete inputs TOP and BOTTOM

- Internal Hall Effect sensors
- Indicate CLOSED and OPENED
- Activated by cam shaft magnets
- Resolution: ± 2% degrees

### • Discrete inputs AUX1 and AUX2

- Connector: J4 (pins 1,2 and 3,4)
- Maximum cable length: 3 m (10 feet)
- Suitable for dry-contact switches. See Drawing WD-12059 in the Appendix for inductive sensor and open-drain/collector option
- Embedded pull-up 510 k to 3.1 V

### • Discrete outputs OUT0 and OUT1

- Connector: J3 (pins 1,2 and 3,4)
- Maximum cable length: 3 m (10 feet)
- Current source for up to 2 (two) ultra-low power solenoids powered from the bus
- Open circuit voltage: 6.5 VDC
- Maximum operating current: 5.0 mA
- Output impedance: 320 Ohms
- Overcurrent limited to 5.2 mA (it indicates short-circuit when the output is active)
- Minimum load current: 1 mA (it indicates open circuit when the output is active)

### • Real time clock (optional)

- Adjusted using diagnostic transducer block
- Used for automatic PST<sup>[3]</sup> function
- Back-up: Lithium battery
- Back-up life: 10 years at 20°C (68°F)
- Contact Westlock for this option

### • Temperature sensor

- Embedded digital temperature sensor
- Used for alarm generation
- Accuracy<sup>[4]</sup>: ± 2°C

### Potentiometer input (optional)

- Connector J5
- Industrial ruggedized pre-installed
- Angle of rotation: 30 to 110 degrees
- Maximum wire length: 10 cm (4 inches)
- Resolution: 0.2% FS
- Accuracy<sup>[5]</sup>: ± 1% FS
- Closed/Opened tolerance: ± 2% FS
- Contact Westlock for this option

### Environmental

- Operating<sup>[6]</sup>: -40°C to +85°C
- (-40°F to +185°F)
- Storage: -40°C to +85°C (-40°F to +185°F)
- Relative Humidity: 0 to 95% non-condensed
- Vibration: 2 g, 10 Hz to 1000 Hz
- Shock: 18 g, 3 axis, 100 bumps each axis
- References: IEC61514-2, IEC 60068-2-29/27, IEC 61298-3, IEC 60068-2-1/2

### • Ingress Protection rating (base models)

- 7344: IP65
- 7379: IP65
- Contact Westlock for other models
- Reliability data
- MTBF (Electronic module): Pending.
- Reference: MIL-HDBK-217F N1/2.

### NOTES

- 2. For reference only. Check your actual device or consult Westlock for more information.
- 3. Future implementation, contact Westlock for more information.
- 4. Combined linearity, hysteresis and repeatability over the operating temperature range.
- 5. Combined linearity, hysteresis and repeatability over the operating range.
- 6. Valid for general purpose application only. Contact Westlock for hazardous areas. It does not include pneumatic assembly.

### • Electro-Magnetic Compatibility (EMC):

Immunity test	Standard	Level	Class*
Electrostatic Discharge - ESD	IEC 61000-4-2	Direct ±4 kV, air ±8 kV	А
Electric Fast Transient Burst - EFTB	IEC 61000-4-4	±2 kV	А
Lightning Surge - SURGE	IEC 61000-4-5	±1 kV	А
Power Frequency Magnetic Field - PFMF	IEC 61000-4-8	30 A/m 50 Hz and 60 Hz	А
Radiated Immunity - RI	IEC 61000-4-3	10 V/m 80 MHz-1 GHz	А
		3 V/m 1 GHz-2.7 GHz	
Conducted Immunity - CI	IEC 61000-4-6	10 Vrms 150 kHz-80 MHz	А

### NOTE

\* Class A: device does not exhibit noticeable interference. Class B: device may exhibit temporary interference with loss of function, but self-recovers. Reference standards: IEC 61514-2, IEC61326, IEC61000-6-4, IEC61000-6-2.

Emissions test	Standard	Level	Class
Radiated Emissions - RE	CISPR 11	Class A QP 3 m	А
Conducted Emissions - CE	CISPR 22	Class A	А

### 1.4 Principles of operation

### 1.4.1 Configuration

Now that you have determined your application and wired the bus, limit switches and solenoids, it is time to configure the module in order to control and/or monitor the valve(s). For this you will make use of the resource, transducer, channel and function blocks.

### 1.4.2 Blocks modes

The MODE\_BLK parameter controls the block execution and is comprised of four subparameters:

- 1. Target: determines which mode the user wants the block to assume. Usually it needs to be set to 00S before any configuration parameter can be changed.
- 2. Actual: set by the block during its execution based on the target and internal diagnostics. Typically it needs to be in AUTO or CAS (cascade) for the block to execute its normal function.
- 3. Permitted: defines the modes supported by this block.
- 4. Normal: desired operating mode of the block in normal operation.

When a block is in Out of Service mode (O/S or OOS) it will not run and the associated data will have Bad Status. If the mode is OOS the output of the function block is usually maintained at the last value but can be configured to go to a predefined fail state (See section "Fault State / Fail Safe Configuration". Parameter configurations are usually performed in OOS mode so there is no bump in a running process. Before a particular block will be usable in a configuration, the mode must not be OOS and block specific parameters may need modification (appropriate Channel or ACTION\_ELEMENT selected, etc.).

### MODE\_BLK PARAMETER (VALUES IN HEXDECIMAL)

Value	Enumerations	Notes
0x01	Remote-Output (Rout)	
0x02	Remote-Cascade (RCas)	
0x04	Cascade (CAS)	Typical mode for DO blocks
0x08	Automatic (AUTO)	Typical mode for transducers, DI and AI blocks
0x10	Manual (MAN)	Use this mode to actuate manually
0x20	Local Override (LO)	
0x40	Initialization Manual (IMan)	
0x80	Out of Service (OOS or O/S)	Out of Service, block is not running

### 1.4.3 Blocks and I/O channels

Throughout this document, all references to blocks are made using factory default tags, but in a real application block tags are different from TB1 or DI\_1 (more likely TRANSDUCER482 or FFDI35). Thus, it is useful to know how to find out in your application the block you want to configure or link. The table below shows the pre-instantiated blocks, their VFD indexes (object directory/table index) and the physical I/O that every block can access through the proper configuration of the transducer parameters and function blocks channels.

Default block tag	VFD index	Description	Top hall (open)	Bottom hall (close)	Aux1 J4 1,2 (open)	Aux2 J4 3,4 (close)	Out0 J3 1,2 (valve 1)	0ut1 J3 3,4 (valve 2)	Maskable	Aux3 J5 (analog)
RB	407	Resource block	-	-	-	-	-	-	-	-
TB1-STD-VALVE1	482	Standard discrete transducer block valve 1	•	•	•	•	•	•*	•	•
TB2-STD-VALVE2	554	Standard discrete transducer block valve 2	•	•	•	•	•*	•	•	•
TB3-DIAG-VALVE1	626	Diagnostics transducer block valve 1	•	•	•	•	•	•*	•	•
TB4-DIAG-VALVE2	694	Diagnostics transducer block valve 2	•	•	•	•	•*	•	•	•
DI_1	762	Discrete input for general purpose	•	•	•	•	-	-	•	-
DI_2	791	Discrete input for general purpose	•	•	•	•	-	-	•	-
DI_3	820	Discrete input for general purpose	•	•	•	•	-	-	•	-
DI_4	849	Discrete input for general purpose	•	•	•	•	-	-	•	-
DI_5	878	Discrete input for general purpose	•	•	•	•	-	-	•	-
DI_6	907	Discrete input for general purpose	•	•	•	•	-	-	•	-
D0_1	936	Discrete output for general purpose	•	•	•	•	•	•	-	•
D0_2	967	Discrete output for general purpose	•	•	•	•	•	•	-	•
D0_3	998	Discrete output for general purpose	•	•	•	•	•	•	-	•
D0_4	1029	Discrete output for general purpose	•	•	•	•	•	•	-	•
Al	1060	Analog input for potentiometer/temperature	-	-	-	-	-	-	-	•

• available

\* Transducer controls both outputs only when configured for Double Action.

**Note:** the "Maskable" signal is the only virtual I/O in the FPAC. It is generated by the combination of certain conditions configured in the transducer block, typically for advanced diagnostics. See Advanced Valve Diagnostics chapter for further details.

Before the FPAC can be configured it is important to understand which I/O channels and function blocks are available. The following function blocks are pre-instantiated in the device:

- Discrete Input (DI): 6 (six). DI blocks can be used to read position feedback, auxiliary inputs and diagnostic alarms (maskable signal), depending on which channel is configured.
- Discrete Output (DO): 4 (four). DO blocks can be used to control one or two outputs (solenoid) AND to read position feedback.
- Analog Input (AI): 1 (one). AI block can be used to read position feedback when the optional potentiometer is installed, or device's onboard temperature.

The function blocks behavior will depend on which option has been configured in the CHANNEL parameter. See in the next sections a detailed description of all I/O channels available for these function blocks. The I/O channels provide value and status for the function blocks. There are 5 (five) possible values for the position feedback of a valve that can be read from the blocks. The transducer block parameters WORKING\_POS\_D and FINAL\_POSITION\_VALUE\_D read and pass along to DIs and DOs the following values via the configured CHANNEL.

Value	Description
0: Closed / Not Opened	The transducer block is indicating the valve is closed or not opened, depending on the selected CHANNEL.
1: Opened / Not Closed	The transducer block is indicating the valve is opened or not closed, depending on the selected CHANNEL.
2: Stopped / Intermediate	The transducer block is indicating the valve has been stopped by a DO block, depending on the selected CHANNEL.
3: Opening / Intermediate	The transducer block is indicating the valve is moving from closed to opened position. Both limit switches are not active.
4: Closing / Intermediate	The transducer block is indicating the valve is moving from opened to closed position. Both limit switches are not active.

On the other hand, there are only 3 (three) possible values\* to write to a D0 block set-point to control the valve position. The D0 will pass along these values to the transducer block, via configured CHANNEL, to parameters FINAL\_VALUE\_D and WORKING\_SP\_D, which in turn can assume the values:

Value	Description
0: Close	The transducer block is indicating there is a DO commanding the valve to move to the closed position.
1: Open	The transducer block is indicating there is a DO commanding the valve to move to the opened position.
2: Stop	The transducer block is indicating there is a D0 commanding the valve to stop at the current position (it removes power from the physical output OUT0, OUT1 or both when in Double Action applications.

\* Values > 2 do not affect the DO block.

### NOTE

See Appendix I for a diagram of the connections between the transducers and function blocks.

1.4.3.1 Standard transducer block overview

Transducer blocks are responsible for isolating the function blocks from the specificities of the device's I/O subsystem. The following transducer blocks are available:

- Standard Discrete Transducer: 2 (two), used to control up to two valves.
- Diagnostics Transducer: 2 (two), used for the diagnostics of up to two valves. These transducer blocks work in pairs:
- TB1 and TB3 form a pair of transducers that works for the "local valve" or "valve 1". All configuration and diagnostics related to valve 1 reside in this pair of transducers.
- TB2 and TB4 form the other pair of transducers that work for the "remote valve" or "valve 2".

All configuration and	diagnostics related t	o valve Z reside in 1	this pair of transducers.

		Position feedback indication		Output
	Opened	Opening/closing/stopped	Closed	Solenoid*
	TOP Hall sensor:		TOP Hall Effect sensor	OUTO (J3 1,2) active
Local (Value 1)	active	Top = Bottom = both	not active	opens the valve
Local (valve I)	BOTTOM Hall sensor:	active or not active	BOTTOM Hall Effect	OUT0 not active
	not active		sensor active	closes the valve
	AUX1 (J4 1,2):		AUX1 (J4 1,2):	OUT1 (J3 3,4) active
Domoto (Volvo 2)	pins shorted out	AUX1 = AUX2 = both	pins opened	opens the valve
Remote (Valve Z)	AUX2 (J4 3,4):	opened or shorted out	AUX2 (J4 3,4):	OUT1 not active
	pins opened		pins shorted out	closes the valve

\* If the solenoid requires the use of the two outputs, use OUT0 to move the valve to the opened position and OUT1 to move the valve to the closed position.

### 1.4.3.2 Outstanding parameters

See Appendix B for factory default procedure and Appendix D for a complete list of parameters including default values. The transducer block parameters that determine the normal operation of the device and are mandatory to configure are the following:

- ACTION\_ELEMENT: select the type of application, Single Action, Double Action or Monitoring. Single Action means the transducer block will control the valve using only one physical output either OUT0 or OUT1. Double Action means the transducer will control both outputs OUT0 and OUT1. Monitoring tells the transducer just to look at the limit switches and ignore the output. Monitoring applications do not need a Discrete Output block or I/O, while the others need at least one DO.
- IO\_ASSIGNMENT: selects the physical I/O used for opened limit switch, closed limit and solenoid output, in this order.
- SIGNAL\_ACTION: selects the polarity of the physical output. Default is "0: Increase to Open" which means '1' in the transducer/DO set-point will energize the physical output. If configured to "1: Increase to Close" the same '1' in the transducer/DO set-point will make the physical output de-energize. This can also be seen from the associated output LED. This is useful when configuring fail opened or fail closed valves. Pneumatics have to be installed accordingly to obtain the desired valve position.

There are some optional parameters that can be configured in order to document the application, like ACT\_TYPE, which indicates the type of the assembly (rotary, linear etc.). This parameter does not affect the operation of the device though. See Appendix D for the complete list of parameters. After the transducer block is properly configured it can be used to control the outputs and to read the limit switches. The transducer block mode should be set to MAN. Then, the following parameters can be used to verify the position feedback:

- WORKING\_POS\_D: the actual measured discrete feedback position. This is the raw value obtained from the limit switches configured with IO\_ASSIGNMENT parameter. For example, if the limit switch that indicates valve opened is active, WORKING\_POS\_D = '1' (OPENED).
- FINAL\_POSITION\_VALUE\_D: the actual valve position and status. This is the value sent to be used for a DI block or as the READBACK\_D in a D0 block.

The following parameters can be used to control the physical outputs:

- WORKING\_SP\_D: the final discrete command value to the positioning algorithm. This parameter can be written by the user when the transducer block mode is MAN. This is the raw value that goes to the physical output(s) configured in the IO\_ASSIGNMENT parameter depending on the configuration of the ACTION\_ELEMENT parameter. For example, if ACTION\_ELEMENT = 2: Double Action, and user writes WORKING\_SP\_D = '1' (OPEN), the transducer will command the 2 outputs to a state where the valve should move to the opened position. In the default configuration is corresponds to OUT1 energized and OUT2 off.
- FINAL\_VALUE\_D: the requested valve position and status written by a DO Block. This parameter can only be written by a properly configured DO block.

The table below shows the relation between parameters IO\_ASSIGNMENT, WORKING\_POS\_D and the physical inputs. In the table below the value "0,0" or "1,1" means both limit switches not active or both are active, respectively:

IO_ASSIGNMENT	Top, Bottom = 0.0 or 1.1	Top, Bottom = 1.0 WORKING_POS_D	Top, Bottom = 0.1
0: No selection	0	0	0
1: Top,Bottom,Out0	2	1	0
2: Top,Bottom,Out1	2	1	0
3: Bottom,Top,Out0	2	0	1
4: Bottom,Top,Out1	2	0	1

	Aux1,Aux2 = 0.0 or 1.1	Aux1,Aux2 = 1.0	Aux1,Aux2 = 0.1
IO_ASSIGNMENT		WORKING_POS_D	
5: Aux1,Aux2,Out0	2	1	0
6: Aux1,Aux2,Out1	2	1	0
7: Aux2,Aux1,Out0	2	0	1
8: Aux2,Aux1,Out1	2	0	1

	Pot=INTERMEDIATE	Pot=CLOSED	
IO_ASSIGNMENT		WORKING_POS_D	
9: Analog,Out0	2	1	0
10: Analog,Out1	2	1	0

### NOTE

Top = Top hall sensor, Bottom = Bottom hall sensor, '1' = Limit switch active, '0' = Limit switch not active WORKING\_POS\_D: 0 = CLOSED, 1 = OPENED, 2 = INTERMEDIATE.

- Example #1: IO\_ASSIGNMENT = 1: Top, Bottom, OutO. When magnet activates the Top Hall sensor but not the bottom sensor, WORKING\_POS\_D = 1 = OPENED.
- Example #2: IO\_ASSIGNMENT = 8: Aux2, Aux1, Out1. When the Aux1 input is active (shorted out) but Aux 2 is not, WORKING\_POS\_D = 0 = CLOSED.
- Example #3: IO\_ASSIGNMENT = 9: Analog,Out0. If the shaft is in the middle of the stroke WORKING\_POS\_D = 2 = INTERMEDIATE.
- Example #4: IO\_ASSIGNMENT = 4: Bottom,Top,Out1. If both sensors are active or both sensors are not active, it will indicate WORKING\_POS\_D = 2 = INTERMEDIATE. This condition maybe a problem and should be fixed if persists.

The following tables show the relationship between the parameters IO\_ASSIGNMENT, WORKING\_ SP\_D and the physical outputs OUT0 and OUT1. The result also depends on parameters SIGNAL\_ ACTION and ACTION\_ELEMENT:

### • ACTION\_ELEMENT = 1: Single Action

- SIGNAL\_ACTION = 0: Increase to Open or 1:Increase to Close.

- WORKING\_SP\_D > 1 does not affect the outputs.

- OUT/OUT1: 0 = output not energized; 1 = output energized; NA: Not affected.

			L	Γ = 1: Single Action	1: Single Action				
		WORKING	_SP_D = 0			WORKING_SP_D = 1			
	SIGNAL_A	CTION = 0	SIGNAL_	ACTION = 1	SIGNAL_A	CTION = 0	SIGNAL_A	ACTION = 1	
IO_ASSIGNMENT	OUTO	OUT1	OUTO	OUT1	OUTO	OUT1	OUTO	OUT1	
0: No selection	NA	NA	NA	NA	NA	NA	NA	NA	
1: Top,Bottom,Out0	0	NA	1	NA	1	NA	0	NA	
2: Top,Bottom,Out1	NA	0	NA	1	NA	1	NA	0	
3: Bottom,Top,Out0	0	NA	1	NA	1	NA	0	NA	
4: Bottom,Top,Out1	NA	0	NA	1	NA	1	NA	0	
5: Aux1,Aux2,Out0	0	NA	1	NA	1	NA	0	NA	
6: Aux1,Aux2,Out1	NA	0	NA	1	NA	1	NA	0	
7: Aux2,Aux1,Out0	0	NA	1	NA	1	NA	0	NA	
8: Aux2,Aux1,Out1	NA	0	NA	1	NA	1	NA	0	
9: Analog,Out0	0	NA	1	NA	1	NA	0	NA	
10: Analog,Out1	NA	0	NA	1	NA	1	NA	0	

### • ACTION\_ELEMENT = 2: Double Action

- SIGNAL\_ACTION = 0: Increase to Open or 1:Increase to Close.

- WORKING\_SP\_D > 2 does not affect the outputs.

- OUT/OUT1: 0 = output not energized; 1 = output energized; NA: Not affected.

### 1.4.4 DI (Discrete Input) channels

The discrete input channels will reflect the physical I/O depending on the configuration made on the transducer blocks TB1 and TB2. They can be used to read the position feedback as well as some advanced diagnostics. The following channels are available for the DI blocks: 29.

•	Typica	l applic	ations	use	channe	ls 9,	14, 1	15	or	2
---	--------	----------	--------	-----	--------	-------	-------	----	----	---

DI b	ock - Discrete input channels	OUT_D.Value	Description
0	No Transducer Connection	-	Default value for DI_2 to DI_6.
9	TRD1: 0-Closed / 1-Opened	0 = CLOSED 1 = OPENED 3 = OPENING 4 = CLOSING	OUT_D will indicate '0' when the I/O configured in TB1 indicates closed and '1' for opened. This is the factory default value for DI_1.
10	TRD1: 0-Not Opened / 1-Opened	0 = Any other 1 = OPENED	OUT_D will indicate '1' when TB1 indicates valve OPENED and '0' for any other position (closed, opening, closing, stopped). Typically used in combination with channel 11.
11	TRD1: 0-Not Opened / 1-Opened	0 = Any other 1 = CLOSED	OUT_D will indicate '1' when TB1 indicates valve CLOSED and '0' for any other position (opened, opening, closing, stopped). Typically used in combination with channel 10.
12	TRD1: 0-Closed / 1-Opened / 2-Stopped	0 = CLOSED 1 = OPENED 2 = STOPPED 3 = OPENING 4 = CLOSING	OUT_D will indicate '0' when the I/O configured in TB1 indicates closed, '1' for opened and '2' for stopped. Value 2 = STOPPED is valid only when the FPAC is controlling the valve through a DO block and the transducer is configured as Double Action.
13	TRD1: Maskable Signal	0 = NOT ACTIVE 1 = ACTIVE	It show the state of the maskable signal configured in TB1.
14	Auxiliary Input 1	0 = NOT ACTIVE 1 = ACTIVE	AUX1 input is active when pins 1 and 2 of J4 are shorted out. This channel is connected directly to the physical I/O and does not use the transducer block.
15	Auxiliary Input 2	0 = NOT ACTIVE 1 = ACTIVE	AUX2 input is active when pins 3 and 4 of J4 are shorted out. This channel is connected directly to the physical I/O and does not use the transducer block.
29	TRD2: 0-Closed / 1-Opened	0 = CLOSED 1 = OPENED 3 = OPENING 4 = CLOSING	OUT_D will indicate '0' when the I/O configured in TB2 indicates closed and '1' for opened. This is the factory default value for DI_1.
210	TRD2: 0-Not Opened / 1-Opened	0 = Any other 1 = OPENED	OUT_D will indicate '1' when TB2 indicates valve opened and '0' for any other position (closed, opening, closing, stopped). Typically used in combination with channel 211.
211	TRD2: 0-Not Closed / 1-Closed	0 = Any other 1 = CLOSED	OUT_D will indicate '1' when TB2 indicates valve closed and '0' for any other position (opened, opening, closing, stopped). Typically used in combination with channel 210.
212	TRD2: 0-Closed / 1-Opened / 2-Stopped	0 = CLOSED 1 = OPENED 2 = STOPPED 3 = OPENING 4 = CLOSING	OUT_D will indicate '0' when the I/O configured in TB2 indicates closed, '1' for opened and '2' for stopped. Value 2 = STOPPED is valid only when the FPAC is controlling the valve through a DO block and the transducer is configured as Double Action.
213	TRD2: Maskable Signal	0 = Any other 1 = OPENED	It show the state of the maskable signal configured in TB2.

There are some basic rules to follow when working with DI channels:

- 1. More than one DI can be configured to use the same channel. For example, DI\_1 and DI\_3 can be configured with channel 9: TRD1: 0-Closed / 1-Opened.
- 2. Channels 10, 11 and 210, 211 typically work in pairs requiring two DIs: one DI to indicate the valve is opened and another DI to indicate the valve is closed.
- 3. The auxiliary inputs can be used for any application where one needs to monitor a dry-contact switch. Just connect the dry-contact switch to one of the auxiliary inputs (J4) and configure the correct channel in the DI block (channels 14 and 15).
- Example #1: one rotary valve (local) with one DI for feedback position using transducer TB1: Configure the DI block channel with 9: TRD1: 0-Closed / 1-Opened.
- Example #2: one rotary valve (local) with double action solenoid, one DI for position feedback using TB1:
  - Configure the DI block channel with 12: TRD1: 0-Closed / 1-Opened / 2-Stopped. The stopped will only be seen when the DO block commands the valve to stop.
- Example #3: one linear valve (remote) with two independent DIs for opened and closed positions, using transducer TB2:
  - Configure the channel of the first DI block (OPENED indication) with 210: TRD2: 0-Not Opened / 1-Opened.
  - Configure the channel of the second DI block (CLOSED indication) with 211: TRD2: 0-Not Closed / 1-Closed.
- Example #4: two valves, one rotary (local) and one linear (remote), with feedback position using TB1 and TB2. Configure one DI for each valve:
  - Configure the channel of the first DI block (local valve) with 9: TRD1: 0-Closed / 1-Opened.
  - Configure the channel of the second DI block (remote valve) with 209: TRD2: 0-Closed / 1-Opened.
- Example #5: one rotary valve (local) with feedback position using one DI, transducer TB1 and one leak detector switch with dry contact output connected to AUX1:
  - Configure the DI block channel with 9: TRD1: 0-Closed / 1-Opened.
  - Configure another DI block channel with 14: Auxiliary Input 1.

### 1.4.5 DO (Discrete Output) channels

The discrete output channels will control physical outputs and read limit switches depending on the configuration made on the transducer blocks TB1 and TB2. The following channels are available for the D0 blocks:

• Typical applications use channels 1 or 21.

DOb	olock - Discrete Output Channels	DO Set-point*	Description
0	No Transducer Connection	-	Default value for DO_2 to DO_4.
1	TRD1: 0-Close / 1-Open	0 = CLOSE 1 = OPEN	Writing '1' to the DO block set-point will make TB1 open the valve while '0' will close the valve.
2	TRD1: 0-Not Open / 1-Open	0 = Other DO 1 = OPEN	Writing '1' to the DO block will make TB1 open the valve, while '0' will release the control to another DO block. Typically used in combination with channel 3 and 4 to control double action solenoid valves.
3	TRD1: 0-Not Close / 1-Close	0 = Other DO 1 = CLOSE	Writing '1' to the D0 block will make TB1 CLOSE the valve, while '0' will release the control to another D0 block. Typically used in combination with channels 2 and 4 to control double action solenoid valves.
4	TRD1: 0-Not Stop / 1-Stop	0 = Other DO 1 = STOP	Writing '1' to the DO block will make TB1 STOP the valve, while '0' will release the control to another DO block. Typically used in combination with channels 2 and 3 to control double action solenoid valves.
5	TRD1: 0-Close / 1-Open / 2-Stop	0 = CLOSE 1 = OPEN 2 = STOP	Writing '1' to the D0 block will make TB1 OPEN the valve, while '0' will make TB1 CLOSE the valve and in the case of a Double Action solenoid, '2' will make TB1 STOP the valve (de-energize both outputs).
21	TRD2: 0-Close / 1-Open	0 = CLOSE 1 = OPEN	Writing '1' to the DO block will make TB2 open the valve while '0' will close the valve.
22	TRD2: 0-Not Open / 1-Open	0 = Other DO 1 = OPEN	Writing '1' to the DO block will make TB2 OPEN the valve, while '0' will release the control to another DO block. Typically used in combination with channel 3 to control double action solenoid valves.
23	TRD2: 0-Not Close / 1-Close	0 = Other DO 1 = CLOSE	Writing '1' to the D0 block will make TB2 CLOSE the valve, while '0' will release the control to another D0 block. Typically used in combination with channels 23 and 24 to control double action solenoid valves.
24	TRD2: 0-Not Stop / 1-Stop	0 = Other DO 1 = STOP	Writing '1' to the D0 block will make TB2 STOP the valve, while '0' will release the control to another D0 block. Typically used in combination with channels 22 and 23 to control double action solenoid valves.
25	TRD2: 0-Close / 1-Open / 2-Stop	0 = CLOSE 1 = OPEN 2 = STOP	Writing '1' to the D0 block will make TB2 OPEN the valve, while '0' will make TB2 CLOSE the valve and in the case of a Double Action solenoid, '2' will make TB2 STOP the valve (de-energize both outputs).
91	FSTATE - TRD 1 (Valve 1)	TBD	TBD
92	FSTATE - TRD2 (Valve 2)	TBD	TBD

 $^{*}$  Set-point can be SP\_D or CAS\_IN\_D depending on the mode and application.

Depending on the channel selected on one DO block, some constraints may apply to the remaining channels:

### **DO CHANNEL INTERLOCKS**

Selected channel	0	1/21	2/22	3/23	4/24	5/25	91/92
1/21	0	Х	Х	Х	Х	Х	0
2/22	0	Х	Х	!	0	Х	0
3/23	0	Х	!	Х	0	Х	0
4/24	0	Х	0	0	Х	Х	0
5/25	0	Х	Х	Х	Х	Х	0
91/92	0	0	0	0	0	0	Х

! - Required (Two DO blocks are required), X - Not allowed, O - Optional

As indicated in the table above, there are certain rules associated with the DO channels:

- 1. A channel cannot be used by more than one D0 block. If more than one D0 is using a channel for the same transducer block, that transducer will not work and the physical inputs and output wills remain frozen until this condition is fixed.
- 2. Channels 2, 3, 4, 22, 23 and 24 are meant for applications where the solenoid valve employs two coils/piezos (Double Action, one coil to open the valve and another coil to close the valve) AND the user wants to control each coil separately using up to 3 (three) D0 blocks and the two physical outputs OUT0 and OUT1. When these channels are used with Single Action solenoid valves (one coil), it means there will be more than one D0 block controlling one physical output at the same time. If it happens and the D0 blocks force the physical output to different logic levels, the physical output will remain frozen until the condition ceases.
- 3. The effect of the channels 4 and 24 (STOP) on the physical output is to de-energize the output (Single Action) or both outputs (Double Action).
- 4. It is important to verify the configuration of the transducer block and to check the output LEDs to make sure the DO is working as expected.

**Note:** for double action valves it is possible to command the D0 to "STOP" the valve at the current position writing value '2' to the D0 set-point. The transducer block will deactivate both OUT0 and OUT1 to trap the air in the actuator causing the valve to stay at the current position. Depending on the time to open or close the valve may stop at any intermediate position.

**Note:** if a value higher than '2' is written to the DO block set-point (or to the transducer block set-point) the device will enter into fault state and remain until this conditions ceases.

When properly configured, the D0 blocks can be used to control and monitor the position feedback, usually through BKCAL\_OUT\_D and READBACK\_D. Typically the I0\_OPTS parameter will have the bit 9 set (Use PV for BKCAL\_OUT). This way BKCAL\_OUT\_D will indicate the real position of the valve. The values these parameters will show are the same as for the DI blocks, namely:

### Possible Values for BKCAL\_OUT\_D and READBACK\_D

0 = CLOSEDParameter will indicate '0' when the channel configured in the D0 indicates closed, '1' for1 = OPENEDopened and '2' for stopped. Value 2 = STOPPED is valid only when the FPAC is controlling2 = STOPPEDthe valve through a D0 block and the transducer is configured as Double Action. Closing3 = OPENINGand Opening are intermediate states when both limit switches are not active.

4 = CLOSING

**Note:** notice that, although the D0 blocks can be used to provide position feedback through BKCAL\_OUT\_D or READBACK\_D, the DI blocks can be used freely in combination with the D0s, depending only on the application and correct configuration of the transducer blocks and channels.

- Example #1: one rotary valve (local) with one DO for control and position feedback, using transducer TB1:
- Configure the DO block channel with 1: TRD1: 0-Close / 1-Open. The position feedback can be read from BKCAL\_OUT\_D or READBACK\_D.
- Example #2: one rotary valve (local) with Double Action solenoid (two coils/piezos), one DO for control and position feedback using TB1:
- Configure the DO block with channel 5: TRD1: 0-Close / 1-Open / 2-Stop.
- Example #3: one linear valve (remote) with Double Action solenoid (two coils/piezos) and three independent DOs for opened, closed and stopped positions, using transducer TB2:
- Configure the channel of the first DO block (OPEN) with 22: TRD2: 0-Not Open / 1-Open.
- Configure the second DO block (CLOSE) with 23: TRD2: 0-Not Close / 1-Close.
- Configure the third DO (STOP) to 24: TRD2: 0-Not Stop / 1-Stop.
- Position feedback can be read from BKCAL\_OUT\_D or READBACK\_D.
- Example #4: two valves, one rotary (local) and one linear (remote), with feedback position using TB1 and TB2. Configure one D0 for each valve:
  - Configure the channel of the first DO block (local valve) with 1: TRD1: 0-Close / 1-Open.
- Configure the second DO block (remote valve) with 21: TRD2: 0-Close / 1-Open.
- The position feedback can be read from BKCAL OUT D or READBACK D.

### 1.4.5.1 READBACK\_D parameter operating modes

To enable BKCAL\_OUT\_D parameter report the actual position, the IO\_OPTS parameter "Bit 9: Use PV for BKCAL\_OUT" must be set to '1'. The DO block mode must be OOS before modifying IO\_OPTS. This way BKCAL\_OUT\_D will publish position feedback according to READBACK\_D parameter.

The READBACK\_D parameter indicates the actual position of the valve when properly configured. This parameter has some special operating modes configured with the XD\_STATE parameter. When the XD\_STATE parameter is '0' (default), the READBACK\_D can assume the following values:

- XD\_STATE = '0' (default):
- 0 = CLOSED
- 1 = OPENED
- 2 = STOPPED
- 3 = OPENING
- 4 = CLOSING

Changing XD\_STATE parameter to other values makes READBACK\_D assume different values according to the table below:

READBACK_D	Value	XD_STATE = 64001 (0xFA01)	XD_STATE = 64000 (0xFA00)						
Bit0	0	OUTO NOT active	TB1.FINAL_VALUE_D = 0 (Close)						
	1	OUT0 active	TB1.FINAL_VALUE_D = 1 (Open)						
Bit1	0	OUT1 NOT active	TB2.FINAL_VALUE_D = 0 (Close)						
	1	OUT1 active	TB2.FINAL_VALUE_D = 1 (Open)						
Bit2	0	BOTTOM Hall sensor NOT active	TB1.FINAL_POSITION_VALUE_D = 0 (Closed)						
	1	BOTTOM Hall sensor active	TB1.FINAL_POSITION_VALUE_D = 1 (Not Closed)						
Bit3	0	TOP Hall sensor NOT active	TB1.FINAL_POSITION_VALUE_D = 0 (Opened)						
	1	TOP Hall sensor active	TB1.FINAL_POSITION_VALUE_D = 1 (Not Opened)						
Bit4	0	AUX1 shorted out	TB1.FINAL_POSITION_VALUE_D = 0 (Stopped)						
	1	AUX1 opened	TB1.FINAL_POSITION_VALUE_D = 1 (Not Stopped)						
Bit5	0	AUX2 shorted out	TB2.FINAL_POSITION_VALUE_D = 0 (Closed)						
	1	AUX2 opened	$TB2.FINAL_POSITION_VALUE_D = 1$ (Not Closed)						
Bit6*	0	Analog = CLOSED	$TB2.FINAL_POSITION_VALUE_D = 0$ (Opened)						
	1	Analog = OPENED	TB2.FINAL_POSITION_VALUE_D = 1 (Not Opened)						
Bit7	0	Associated channel NOT in Fault state	TB2.FINAL_POSITION_VALUE_D = 0 (Stopped)						
	1	Associated channel in Fault state	TB2.FINAL_POSITION_VALUE_D = 1 (Not Stopped)						
* Only valid when trai	nsducer is configured	Convigid when transducer is configured to use the applical potentiameter to read position. IO: ASSIGMENT – "Applica Out1/2"							

Only valid when transducer is configured to use the analog potentiometer to read position. IO ASSIGMENT = "Analog,Out1/2

**Note:** the status of the READBACK\_D parameter is not affected by the XD\_STATE parameter.

### 1.4.6 AI (Analog Input) channels

There are two channels available for the AI block:

AI - Analog Input Channels Description		Description	XD_SCALE and OUT_SCALE
0	No Transducer Connection	No transducer channel assigned.	Not necessary
1	Actual Position	Default value for the AI block. Outputs	• EU_100 = 100
		the valve position from 0% to 100%.	• EU_0 = 0
			<ul> <li>UNITS_INDEX = % = XDUCER_UNITS (this unit comes from the transducer)</li> </ul>
			• DECIMAL = 3
2	Internal Temperature	Outputs the onboard temperature.	• EU_100 = 200
			• EU_0 = -100
			<ul> <li>UNITS_INDEX = XDUCER_UNITS (this unit comes from the transducer as °C or °F)</li> </ul>
			• DECIMAL = 3

Before the AI block can be used for position monitoring:

- The optional potentiometer must be installed and calibrated. See section about potentiometer calibration for further detail. Contact Westlock for more information on this option.
- Transducer block TB1 or TB2 must be configured with IO\_ASSIGMENT = "9: Analog,Out0" or "10: Analog,Out1"
- AI.CHANNEL = "1: Actual Position"
- XD\_SCALE and OUT\_SCALE parameters should be configured to match the channel according to the previous table.

Before the AI block can be used for onboard temperature monitoring:

- Transducer block TB1 or TB2 must have INTERNAL\_TEMP\_UNITS configured to °C or °F
- AI.CHANNEL = "2: Internal Temperature"
- XD\_SCALE and OUT\_SCALE parameters should be configured to match the channel according to the previous table.

### 1.4.7 Configuration overview

Configuration of the FPAC module demands full understanding of all blocks involved, including Resource, Transducer and Function blocks. It also requires the reader has previous knowledge on how to install and configure Foundation Fieldbus field devices. Although a myriad of parameters are available in the blocks, just a small number of them needs to be configured in order to make FPAC work as required. The most important parameters that have to be configured are the following:

- RESOURCE BLOCK
- MODE\_BLK
- STANDARD TRANSDUCER BLOCK
  - MODE\_BLK
  - SIGNAL\_ACTION: controls the polarity of the physical output.
  - ACTION\_ELEMENT: indicates the type of device being controlled/monitored:

			TB2.ACTION_ELEMEN	т	
TB1.ACTION_ELEMENT	0: No selection	1: Single Action	2: Double Action	3: See other transducer	4: Monitoring
0: No selection	OK	OK	Invalid	OK	OK
1: Single Action	OK	OK*	Invalid	Invalid	OK
2: Double Action	OK	Invalid	Invalid	OK	Invalid
3: See other transducer	Invalid	Invalid	OK	Invalid	Invalid
4: Monitoring	OK	OK	Invalid	Invalid	OK

\* Set dipswitch #6 to ON and parameter SET\_CURRENT\_SINK = 2: Current Level 2.

For all the other configurations the dipswitch #6 must be OFF.

The option "3: See other transducer" is automatically selected when Double Action is selected in the other transducer.

IO\_ASSIGNMENT: assigns physical I/O to the transducer. Each transducer must use different I/O even if the transducer is only monitoring. The valid combinations are detailed in the table below:

	TB2.I0_ASSIGNMENT										
TB1.I0_ASSIGNMENT	0: No selection	1: Top,Bottom,Out0	2: Top,Bottom,Out1	3: Bottom,Top,Out0	4: Bottom,Top,Out1	5: Aux1,Aux2,Out0	6: Aux1,Aux2,Out1	7: Aux2,Aux1,Out0	8: Aux2,Aux1,Out1	9: Analog,Out0	10:Analog,Out1
0: No selection	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
1: Top,Bottom,Out0	OK	Х	Х	Х	Х	Х	OK	Х	OK	Х	OK
2: Top,Bottom,Out1	OK	Х	Х	Х	Х	OK	Х	OK	Х	OK	Х
3: Bottom,Top,Out0	OK	Х	Х	Х	Х	Х	OK	Х	OK	Х	OK
4: Bottom,Top,Out1	OK	Х	Х	Х	Х	OK	Х	OK	Х	OK	Х
5: Aux1,Aux2,Out0	OK	Х	OK	Х	OK	Х	Х	Х	Х	Х	OK
6: Aux1,Aux2,Out1	OK	OK	Х	OK	Х	Х	Х	Х	Х	OK	Х
7: Aux2,Aux1,Out0	OK	Х	OK	Х	OK	Х	Х	Х	Х	Х	OK
8: Aux2,Aux1,Out1	OK	OK	Х	OK	Х	Х	Х	Х	Х	OK	Х
9: Analog,Out0	OK	Х	OK	Х	OK	Х	OK	Х	OK	Х	Х
10: Analog,Out1	OK	OK	Х	OK	Х	OK	Х	OK	Х	Х	Х

- DISCRETE OUTPUT BLOCK:
- MODE BLK
- CHANNEL
- IO OPTS
- SHED OPTS
- DISCRETE INPUT BLOCK
- MODE BLK
- CHANNEL
- L TYPE
- ANALOG INPUT BLOCK - MODE BLK
- CHANNEL
- OUT SCALE
- XD SCALE

The DIAGNOSTIC transducer block does not require any configuration for the basic usage and will be addressed in the section "Advanced Valve Diagnostics".

You will need to identify how to configure each of these parameters on your particular FF Host and for your particular application. The FPAC DD provides a configuration method/wizard to make the basic step-by-step configuration very easy. Some configuration examples will be shown in the following sections.

1.4.8 Fault State Configuration

Three failure scenarios are considered: power failure, communication failure and internal failure

- 1. During a power failure event, the pneumatics (air supply, solenoid, actuator, tubing etc.) should ensure the fail-safe position is achieved. The FPAC electronic module is out of the loop. Carefully verify the pneumatic installation and simulate this condition before assembly acceptance.
- 2. When a communication failure event is detected and FPAC has lost the setpoint sent by another block in the application, it can move the valve to a pre-configured fault state / fail safe position. This also happens when there is no LAS in the bus to maintain the FF communication.
- 3. When an internal block failure occurs, one of the blocks in the FPAC experiments a fault condition, bad status or is forced to Out of Service mode. This condition may also happen in normal situations like when the user is downloading a new configuration, for example. In this case a fault state condition can also be configured.

The configuration made in the transducer block takes precedence over the DO block. In other words, the DO block IFS will only prevail if the transducer block is not forcing the fault state condition.

Note: fail last applications typically require a double coil/piezo solenoid that allows the air to be trapped inside the actuator during failures, including power failures. See wiring example #2 for more details.

- 1.4.9 Resource block fault state parameters
  - FAULT STATE parameter located in the Resource block indicates if the device is in a fault condition.
  - SET FSTATE and CLR FSTATE parameters can be used to force and clear this condition for maintenance and test purposes.

### 1.4.10 Discrete output block fault state (IFS) parameters

The DO block will be present in the application whenever the FPAC is controlling the valve position. The DO block has standard parameters that allow a fault state action to be specified on detection of an input with bad status or uncertain quality. The configuration for these parameters follows the standard IFS specification. The following parameters have to be configured in the DO:

- IO OPTS: there are 3 bits in this parameter to control the fault state actions:
- Bit4: Fault State to value. If this bit is set to '0' (Freeze) the output will hold the current value (freeze) if a fault is detected. If this bit is set to '1' (Go to preset value), the output will go to the preset FSTATE\_VAL\_D value.
- Bit5: Fault State restart. When this bit is set to '1' the block output will use the value of FSTATE VAL D parameter if the device is restarted, otherwise it will use the nonvolatile value stored for OUT D parameter. - Bit6: Target to Manual if IFS. This option in
- IO OPTS may be used to latch the FAULT STATE parameter. Setting this bit value will cause the target mode to automatically change to MAN when a fault is detected. The block will then have to be manually set to its normal target mode when fault conditions are fixed. If the external condition which caused the fault state has not been cleared the device will immediately reenter fault state

- STATUS\_OPTS: options which the user may select in the block processing of status.
- Bit0: Propagate Fault Backward. If the status of CAS\_IN\_D parameter is Failure the block will propagate it to BKCAL\_OUT\_D parameter without generating an alarm. The substatus FaulStateActive indicates the block entered fault state (IFS).
- FSTATE \_TIME: the time, in seconds, from the detection of a failure of the output block remote set-point to the output action of the block output if the condition still exists.
- FSTATE\_VAL\_D: the preset discrete SP\_D value to use when a failure occurs. This value will be used if IO OPTS = "Fault State to value" is selected. The possible values are: 0: Close, 1: Open and 2: Stop.

10 DI_1 (DI)	TH FPAC	-2-DO_1 (DO)	_	i i	
Ox0c, Bad::NoComm TARJEI = Auto ACTUAL - Auto	WithLastUsableValue:NotLimited invited T	IN D OU ARGEI = Cas   Auto CTUAL - LO Tro	T D D D D ms D nds D	0, Good 4, Good	Cascade::NonSpecific:Constant Cascade::NotInvited:Constant

Typically, a FF alarm will be generated upon transition to a fault state. The alarm should be handled using the standard alarm handling mechanism present in the FF Host system. A typical situation where the D0 blocks goes to fault state is illustrated above. In this case, a communication problem occurred on the DI\_1 block that was generating the set-point to the FPAC-2-D0\_1 block. The status of the D0 set-point changed to Bad-NoComm\_ WithLastUsableValue-NotLimited. The D0 block automatically switched its mode to L0 (Local Override) and initiated the fault state action keeping the output at a constant value.

# 1.4.11 Standard Transducer block fault state parameters

In addition to the DO standard IFS parameters, there are 3 (three) parameters in the standard transducer blocks TB1 and TB2 that can be used to configure the action the transducer will take in case of a fault state. It is important to understand this configuration do not replace the standard DO fault state configurations as the transducer blocks fault state is device specific.

The standard transducer will enter a fault state in the following situations;

- Configuration mistake: 2 (two) DO's using the same channel or no DO using the transducer channel (when in Single or Double Action)
- 2. Bad quality in the FINAL\_VALUE\_D parameter: example, D0 in OOS mode.
- Forced by a D0 configured with channel options "FSTATE - TRD 1 (Valve 1)" or "FSTATE - TRD 2 (Valve 2)" see next section for an example of this configuration.
- PSNR\_FSTATE\_OPT: whenever the transducer block enters into a fault state (D0 sends a BAD status to the FINAL\_ VALUE\_D parameter, for example) the device will control the valve according to what is defined in this parameter.
- 0: Hold Last Value
- 1: Fail Closed
- 2: Fail Open
- 3: PSNR\_FSTATE\_VAL\_D (uses the value configured in this parameter)

- PSNR\_OOS\_OPT: whenever the transducer block enters into Out of Service (OOS) mode the device will control the valve according to what is defined in this parameter.
  - 0: Hold Last Value
  - 1: Fail Closed
  - 2: Fail Open
- 3: PSNR\_FSTATE\_VAL\_D (uses the value configured in this parameter)
- PSNR\_FSTATE\_VAL\_D: if this parameter was chosen in any of the two previous parameters the state assumed by any of the physical outputs will match the value configured in this parameter. Valid values are: 0: Close, 1: Open and 2: Stop.

**Note:** see Appendix D for a complete list of blocks and parameters including default values.

1.4.12 Forcing fault state from an auxiliary input Auxiliary inputs AUX1 and AUX2 can be used to force the transducer into a fault state value and, in turn, move the valve to a fail-safe position (block or vent). This can be accomplished by using one DI and one DO blocks, linked together and properly configured, as in the example below.

Example #1: configure FPAC to go to fault state and command valve 1 (TB1) to open (fail opened) when auxiliary input AUX1 is active (inputs pins are shorted out):

- DI block configuration:
  - CHANNEL = 14: Auxiliary Input 1 - MODE\_BLOCK = AUTO
- D0 block configuration:
  - CHANNEL = 91: FSTATE TRD 1 (Valve 1)

- MODE\_BLOCK = CAS + AUTO **Note:** in the application, DI.OUT\_D output has to be linked to the DO.CAS\_IN\_D input.

- Standard Transducer block configuration: - PSNR\_FSTATE\_OPT = 2: Fail Open
- MODE\_BLK = AUTO Short out AUX1 pins. AUX1 LED will turn on. Notice the OUT0 LED will turn on indicating the command to open the valve in fault state. Transducer block mode should go to "LO" (Local Override). BLOCK\_ALMS\_ACT will set the Device Fault State bit. Resource Block will indicate Fault State in the BLOCK\_ERR parameter.

1.4.13 Testing fault state configuration After transducer and DO blocks have been configured, use Resource block SET FSTATE parameter to force the fault state in the DO block. Check if FAULT\_STATE = ACTIVE. Check that block error should be indicating DeviceFaultState. DO block should immediately transition to fault state, which is indicated by the mode changing to LO (Local Override). Transducer blocks and physical outputs OUTO and OUT1 must transition to the configured fault state according to the set-point DO block will send to parameter FINAL\_VALUE\_D.

• Example #1: D0 block mode is CAS+AUTO, DO receives a BAD or UNCERTAIN status in its CAS IN D input with substatus FaultStateActive, the device will enter fault state defined by the parameters configured in the DO block. Parameters in the transducer block do not take any effect. DO mode goes to LO (Local Override) while in fault state.

To test the transducer block fault state change the DO block mode to OOS. The FINAL\_ VALUE\_D parameter will receive a BAD status then transducer will switch to fault state.

• Example #2: DO block goes to OOS. In this situation the DO will send a BAD status to the transducer FINAL\_VALUE\_D parameter, that will command the valve to a state defined in the transducer block parameters. The DO IFS parameters do not take effect. WORKING\_ SP\_D substatus change to FaultStateActive, indicating the transducer block is in fault state. The configuration in the transducer block parameters determines the valve position.

### 1.5 Special features

1.5.1 Advanced valve diagnostics This chapter presents the advanced diagnostic features available in the Intellis 7300 series (the FPAC) of discrete valve controllers. The Diagnostic Transducer block is an outstanding tool to help users anticipate potential problems and prevent unwanted losses and injuries. Some of the available diagnostics can generate standard FF alarms handled by the FF Host system. There is also the maskable signal that allows DI blocks to indicate some alarm status, like cycle counter limit or valve cycle time exceeded. The operational diagnostics and the associated parameters, maskable signals and alarms are summarized in the tables below. Notice the diagnostic transducer must be in AUTO for the diagnostics to work.

CYCLE_CNTR		Alarm => CYCLE_COUNT_ALM			
What is it?	What is it used for?	How does it work?	How to use it?	Clear?	
Totalizes cycle counts for the	Depending on the	It accumulates in non-volatile	Configure the desired	Write '0' directly to CYCLE_	
valve controlled or monitored	characteristics of the valve	memory how many times the	maximum limit in CYCLE_	CNTR or Set bit 9 (0x0100) in	
by the transducer.	assembly it may be required	valve completed a movement	CNTR_LIM. If required,	the parameter CLEAR_CNTR in	
	to perform maintenance after	from one end to another.	configure SIGNAL_MASK bit	the Diagnostics transducer.	
	a given number of cycles.	If the count limit set in	0 and one DI block channel.		
	Contact valve and actuator	CYCLE_CNTR_LIM is exceeded	Set CYCLE_COUNT_PRI = 1 to		
	manufacturer for more	the CYCLE_COUNT_ALM	enable the alarm.		
	information.	is generated. Optionally a			
		maskable signal channel can			

inform a DI this alarm is active. Then the user can schedule a preventive maintenance.

Maskable signal => SIGNAL MASK bit 0 = Cycle Count 1 exceeds limits

• CYCLE\_CNTR resides in transducer blocks TB1 and TB2 (Standard Discrete Transducer).

• CYCLE\_CNTR\_LIM and CYCLE\_COUNT\_ALM are in the transducer blocks TB3 and TB4 (Diagnostic Transducer).

# **INTELLIS** 7300 SERIES INSTALLATION AND OPERATION MANUAL

		Maskable signal => SIGNAL_MA	SK bit 1 = Cycle Time exceeds lin	nits
VALVE_CYCLE_TIME		Alarm => CYCLE_TIME_ALM		
What is it?	What is it used for?	How does it work?	How to use it?	Clear?
The time in seconds (with	Detect early problems with	It measures the complete	Configure the maximum time in	Factory default, Power cycle.
resolution of 100 ms) the	solenoid valves, air leakage,	time in seconds between	CYCLE_TIME_LIM. If required,	
valve took to complete the	supply pressure issues, valve	two consecutive strokes	configure SIGNAL_MASK bit 1	
last two cycles. It is the same	shaft/stem or any other	and compare with the limit	and one DI block channel. Set	
as STROKE_TIME_CLOSED +	mechanic or pneumatic	configured in the parameter	CYCLE_TIME_PRI = 1 to enable	
STROKE_TIME_OPEN.	component that may prevent	CYCLE_TIME_LIM. If this limit is	the alarm.	
	the valve to move properly.	exceeded CYCLE_TIME_ALM is		
		triggered.		

• CYCLE\_TIME \_LIM resides in the transducer blocks TB1 and TB2 (Standard Discrete Transducer).

• VALVE\_CYCLE\_TIME and CYCLE\_TIME\_ALM reside in transducer blocks TB3 and TB4 (Diagnostic Transducer).

		Maskable signals => SIGNAL_M	ASK bits 3 and 4 = Low/Hi Tempe	rature
INTERNAL_TEMP		Alarms => HIGH_TEMPERATUR	E_ALM and LOW_TEMPERATURE	_ALM
What is it?	What is it used for?	How does it work?	How to use it?	Clear?
The electronic module onboard	Used to discover unexpected	It compares onboard	Configure maximum and	Factory default, Power cycle.
temperature. Units according to	temperature conditions.	temperature with parameters	minimum temperatures	
parameter INTERNAL_TEMP_	Typically the operating range	LOW_TEMPERATURE_LIM and	LOW_TEMPERATURE_LIM and	
UNITS.	of most coil/piezo operators	HIGH_TEMPERATURE LIM. If	HIGH_TEMPERATURE LIM. If	
	is narrower than the FPAC	temperature exceeds the limits,	required, configure SIGNAL_	
	electronic module.	alarms LOW_TEMPERATURE_	MASK bits 3 and 3 or and one	
		ALM or HIGH_TEMPERATURE_	DI block channel. Set HIGH/	
		ALM are triggered.	LOW_TEMPERATURE_PRI = 1	
			to enable the alarms.	

• All parameters in the table are located in the transducer blocks TB1 and TB2 (Standard Discrete Transducer).

The following parameters do not generate FF alarms nor maskable signal but are still useful for general diagnostics. User can monitor them periodically to check some operational conditions:

STROKE_TIME_CLOSED / STROKE_TIME_OPEN					
What is it?	What is it used for?	How does it work?	How to use it?		
The time in seconds the valve	Detect early problems with	It measures time between the activation of the valve and the	Although this parameter does no		
took in its last movement to go	solenoid valves, air leakage,	detection of the CLOSED/OPENED limit switch. These times are	generate any alarm is indirectly		
from opened/closed to closed/	supply pressure issues,	then summed up to update the parameter VALVE_CYCLE_TIME.	monitored though the parameter		
opened position. It is used to	valve shaft/stem or any other	It is then compared against the pre-configured limit CYCLE_	VALVE_CYCLE_TIME that		
calculate VALVE_CYCLE_TIME.	mechanic or pneumatic	TIME_LIM. If these limits are exceeded, the CYCLE_TIME_ALM	generates an alarm. The user can		
	component that may prevent	is triggered, then the user can schedule a maintenance. It can	also verify this parameter From		
	the valve to move properly.	also be monitored using a DI block and the corresponding	time to time against some pre-		
		maskable signal.	determined limit.		

• STROKE\_TIME\_CLOSED and STROKE\_TIME\_OPEN are located in blocks TB3 and TB4 (Diagnostic Transducer).

		BREAKAWAY_TIME	
What is it?	What is it used for?	How does it work?	How to use it?
The last reported time taken	Detect early problems with solenoid	It measures for every cycle the time	Although this parameter does no generate any
in seconds for valve to begin	valves, air leakage, supply pressure	between the activation of the valve and	alarm is indirectly monitored though the parameter
moving (opening or closing).	issues, valve shaft/stem or any other	the detection of the associated limit	VALVE_CYCLE_TIME that generates an alarm. The
	mechanic or pneumatic component that	switch.	user can also verify this parameter From time to
	may prevent the valve to move properly.		time against some pre-determined limit.

• BREAKAWAY\_TIME is located in blocks TB3 and TB4 (Diagnostic Transducer).

The CYCLE\_TIME\_HISTORY stores up to 400 cycle times for later analysis. To retrieve the collected data configure the CYCLE\_TIME\_HISTORY parameter as a standard fieldbus trend in your FF Host system. See the following table:

CYCLE_TIME_HISTORY					
What is it?	What is it used for?	How does it work?	How to use it?		
An array of up to 400	It is used for trending the cycle time	It collects cycle times in an array	Configure the type of collection you want to perform in the		
valve cycle times	to detect early problems with solenoid	for later analysis. Set of up to 400	parameter CYCLE_TIME_COLLECT_TYPE as Continuous		
collected on demand.	valves, air leakage, supply pressure	cycle times can be stored in the	or Stop when full. To initiate the collection the COLLECT_		
	issues, valve shaft/stem or any other	device and later retrieved using the	CYCLE_TIME parameter must be set to Active. Writing		
	mechanic or pneumatic component that	standard fieldbus trend system.	Inactive will stop collecting data. To have the report sent, set		
	may prevent the valve to move properly.		COLLECT_CYCLE_TIME parameter to Report. The standard		
			trend mechanism should then retrieve the collected data.		

### 1.5.2 The "Maskable signal"

The Maskable Signal is a virtual signal generated from one or more alarms and conditions preconfigured in the transducer blocks using the parameter SIGNAL\_MASK. The active conditions can be verified in the parameter MASKABLE\_SIGNAL. Some of the diagnostics explained in the previous tables can be linked to a DI block using the maskable signal. The options available for this parameter are:

	SIGNAL_MASK MASKABLE_SIGNAL	
Bit	TB1 and TB2 TB3 and TB4	Description
0	Cycle Count 1 exceeds limits	CYCLE_CNTR exceeded CYCLE_CNTR_LIM
1	Cycle Time exceeds limits	VALVE_CYCLE_TIME exceeded CYCLE_TIME_LIM
2	Bad Xducer Status	The associated transducer (TB1 or TB2) has a BAD status
3	High Temperature	INTERNAL_TEMP exceeded HIGH_TEMPERATURE_LIM
4	Low Temperature	INTERNAL_TEMP exceeded LOW_TEMPERATURE_LIM

The "Maskable Signal" can be used to link some of the diagnostic alarms directly to a DI. This allows the alarms states to be linked directly to another function block for immediate action in the process. Since FPAC can control up to two valves, every transducer pair can generate its own Maskable Signal, creating a multitude of options for the user to report alarms in the application for up to two valves.

For example, maintenance alarms can be generated when the user configured Cycle Count Limit is reached. The CYCLE\_CNTR\_LIM parameter in the Diagnostic transducer is set during configuration with the limit chosen by the user. The maintenance alarm will be generated when CYCLE\_CNTR accumulates a number larger than the associated CYCLE\_CNTR\_LIM. This condition can trigger a FF alarm on the bus that can be handled via the standard alarm handling, depending on the FF Host System. This condition can also immediately transmit to other function blocks on the application bus using the Maskable Signal channel configured in a DI block. To use the maskable signal you have to follow the general guidelines below:

- 1. Set one or more maskable signal bits in the SIGNAL\_MASK parameter located in the standard transducer blocks (TB1 for valve 1, TB2 for valve 2). The block can be in any mode.
- 2. For every condition configured in the SIGNAL\_MASK, there is a corresponding status bit in the MASKABLE\_SIGNAL parameter located in the diagnostics transducer blocks (TB3 and TB4).
- 3. Configure the advanced diagnostic parameters as explained in the previous sections with the appropriate limits for your application.
- 4. Configure the DI block CHANNEL with "13: TRD1: Maskable Signal" or "213: TRD2: Maskable Signal" depending on which transducer block you want to use. If FPAC is controlling or monitoring two valves you may want to use two DI blocks, one for each transducer.
- 5. Set block modes to AUTO: DIs and TB1 to TB4.
- When at least one of the conditions enabled in the SIGNAL\_MASK parameter occurs the corresponding bit in MASKABLE\_SIGNAL parameter will be set and the DI.OUT\_D = MASKABLE\_SIGNAL.
- 7. When the conditions cease  $DI.OUT_D = '0'$ .
- This DI output can be used in the application to generate an operator or maintenance alarm, or to trigger preventive actions, like forcing that valve to a fail-safe position. See section about Fault State Configuration for more details.

**Note:** the Maskable Signal is active only while the condition exists. It does not latch the condition. Example, if a valve takes too long to open and triggers a cycle time exceeded signal, the DI output will indicate '2' only while the VALVE\_CYCLE\_TIME > CYCLE\_TIME\_LIM. If in the next valve movement the cycle takes less than the limit the corresponding maskable signal and the DI output will be cleared. In order to latch the maskable signal events it is necessary to configure the associated alarms as indicated in the following examples. Otherwise, the events can go away and the user will not be notified.

### 1.5.3 Examples of advanced diagnostics usage

- Example #1: configure DI\_2 to indicate when the CYCLE\_COUNT\_ALM an alarm when the valve 1 opens and closes more than 1000 times. This example assumes the transducer block TB1 has been already configured.
  - TB1.MODE\_BLK = 00S.
- TB1.CYCLE\_CNTR\_LIM = 1000.
- TB1.CYCLE\_CNTR\_PRI = 1. (Enables CYCLE\_COUNT\_ALM)
- TB1.SIGNAL MASK = check bit 0 = Cycle Count 1 exceeds limits.
- TB1.MODE BLK = AUTO.
- TB3.MODE BLK = AUTO.
- DI 2.MODE BLK = 00S.
- DI 2.CHANNEL = 13: TRD1: Maskable Signal.
- DI 2.MODE BLK = AUTO.
- Example #2: configure DI\_4 to report an alarm if onboard temperature rises above +60°C. In this case it does not matter transducer TB1 or TB2 is used as there is only one onboard temperature sensor and both transducers will show the same onboard temperature.
- TB1.MODE BLK = 00S.
- TB1.HIGH\_TEMPERATURE\_LIM = 60.
- TB1.HIGH\_TEMPERATURE\_PRI = 1. (Enables HIGH\_TEMPERATURE\_ALM)
- INTERNAL\_TEMP\_UNITS = °C.
- TB1.SIGNAL\_MASK = Check bit 3 = High Temperature.
- TB1.MODE\_BLK = AUTO.
- TB3.MODE\_BLK = AUTO.
- DI\_2.MODE\_BLK = 00S.
- DI\_2.CHANNEL = 13: TRD1: Maskable Signal.
- $DI_2.MODE_BLK = AUTO.$

# INTELLIS 7300 SERIES INSTALLATION AND OPERATION MANUAL

- Example #3: Configure DI\_2 to report the alarms on examples #1 and #2, plus any time the valve 1 (TB1) takes more than 10 seconds to open or close:
  - TB1.MODE\_BLK = OOS.
  - TB1.CYCLE\_CNTR\_LIM = 1000.
  - TB1.CYCLE\_COUNT\_PRI = 1. (Enables CYCLE\_COUNT\_ALM)
- TB1.CYCLE\_TIME\_LIM = 10.
- TB1.CYCLE\_TIME\_PRI = 1. (Enables CYCLE\_TIME\_ALM)
- TB1.HIGH\_TEMPERATURE\_LIM = 60.
- TB1.HIGH\_TEMPERATURE\_PRI = 1. (Enables HIGH\_TEMPERATURE\_ALM)
- INTERNAL\_TEMP\_UNITS = oC.
- TB1.SIGNAL\_MASK = Check bits 0, 1 and 3 = Cycle Count 1 exceeds limits | Cycle Time exceeds limits | High Temperature
- TB1.MODE BLK = AUTO.
- TB3.MODE\_BLK = AUTO.
- DI 2.MODE BLK = 00S.
- DI 2.CHANNEL = 13: TRD1: Maskable Signal.
- DI 2.MODE BLK = AUTO.
- Example #4: configure a DI block to inform if the transducer TB1 as detected a bad status:
  - TB1.MODE\_BLK = OOS.
  - TB1.SIGNAL\_MASK = Check bit 2 (third bit) = Bad Xducer Status.
- TB1.MODE\_BLK = AUTO.
- TB3.MODE\_BLK = AUTO.
- DI\_2.MODE\_BLK = 00S.
- DI\_2.CHANNEL = 13: TRD1: Maskable Signal.
- DI\_2.MODE\_BLK = AUTO.
- Example #5: Configure cycle time history to collect valve 1 cycle times until it is full then
- transfer to the Host:
- Configure parameter CYCLE\_TIME\_HISTORY as a trend in your FF Host system.
- TB1.MODE\_BLK = AUTO.
- TB1. COLLECT\_CYCLE\_TIME = 2: Stop when full.
- TB1.CYCLE\_TIME\_COLLECT\_TYPE = 1: Active.
- Wait until TB1.CYCLE\_TIME\_COLLECT\_TYPE = 0: Inactive, indicating the history is full.
- TB1.CYCLE\_TIME\_COLLECT\_TYPE = 2: Report
- The data will be transferred to the FF Host through the standard trend mechanism.

### 1.5.4 Additional diagnostics

### 1.5.5 MODULE\_I0\_SUMMARY parameter

Use the MODULE\_I0\_SUMMARY parameter located in Diagnostics blocks (TB3/TB4) to check the status of any pin in the module. Both transducers exhibit the same value. It is summarized in the table below:

Bit	Hex	Mnemonic	Description
0	0x0001	WRP	Write protect DIPswitch #1 is ON
1	0x0002	SIM	Simulate enable DIP switch #2 is ON
2	0x0004	FCT	Factory default DIP switch #3 is ON
3	0x0008	CAL	Calibration enable DIP switch #4 is ON
4	0x0010	0/C	Open/Close DIP switch #5 is ON
5	0x0020	AUX	Auxiliary DIP switch #6 is ON
6	0x0040	OUTO	Discrete Output 0 is energized
7	0x0080	OUT1	Discrete Output 1 is energized
8	0x0100	AUX1	Discrete Auxiliary Input 1 pins are shorted out
9	0x0200	AUX2	Discrete Auxiliary Input 2 pins are shorted out
10	0x0400	TOP	Top Hall Effect sensor is active (magnet detected)
11	0x0800	BOT	Bottom Hall Effect sensor is active (magnet detected)
12-15	-	-	Reserved for future use

### 1.5.6 OUT\_LOAD\_STATUS parameter

Use OUT\_LOAD\_STATUS parameter to verify the status of the load connected to outputs OUT0 and OUT1. Whenever the output is active to power the coil/piezo it will indicate whether it is shortcircuited or opened. It is helpful to diagnose wiring problems or solenoid faults. In addition, any time the output circuit detects a fault, the corresponding LED will blink. If the output is not active or not used it does not indicate open circuit. As soon as the problem ceases the corresponding bit is cleared. See technical specification page for thresholds.

### FIGURE 1

Output LEDs for solenoid diagnostic

Bit	Output status	LEDs will blink
Bit0	Out0 Short	
Bit1	Out0 Open	
Bit2	Out1 Short	
Bit3	Out1 Open	30000

### 1.5.7 DIAG\_CNTR parameter

For more advanced diagnostics there is the  $\mathsf{DIAG}\_\mathsf{CNTR}$  parameter. It is a set of counters that record events.

Element	Mnemonic	Description
0	DIAG_CNTR(0)	Reserved for future use
1	DIAG_CNTR(1)	Number of device resets since last clear
2	DIAG_CNTR(2)	Reserved for future use
3	DIAG_CNTR(3)	Reserved for future use
4	DIAG_CNTR(4)	Reserved for future use
5	DIAG_CNTR(5)	Reserved for future use
6	DIAG_CNTR(6)	Reserved for future use
7	DIAG_CNTR(7)	Reserved for future use

**Note:** to clear counters in the parameter DIAG\_CNTR, one must set the corresponding bit in the parameter DIAG\_CLR. For example, to clear the counter DIAG\_CNTR(1) set bit DIAG\_CLR(1) = '1'. The counter will be cleared and the bits will be automatically set back to '0'.

### 2 ORDER GUIDE

Please Contact Westlock to get the most recent Ordering Guide.

### **3 DEFINITIONS**

- Single Action: in this document refers to an application where the FPAC uses only one output connected to a single coil to control the main valve. When powered, this coil makes the valve move to one position (typically opened) and when unpowered it moves the valve to the other position (typically closed). The FPAC is able to control up to 2 (two) single action valves simultaneously.
- Double Action: in this document refers to the use of two coils and, in turn, the two FPAC outputs, to control the main valve. Each coil moves the valve to one position, while both coils powered or unpowered stop the valve at the current position.
- Valve cycle or valve stroke: a complete movement from one end to the other. For example, if the valve goes from opened to closed position it represents a cycle; back to opened position it counts another cycle. If the valve starts moving but goes back to the same end it does not count as a cycle.
- Valve opened: it means the valve is at the position the user determined as opened.
   For the FPAC it means the shaft is in the position where the top cam magnet is facing the canister that activates the top internal Hall Effect limit switch, which turns on LED OPEN. Alternatively, a dry-contact connected to discrete input AUX1 can be used to indicate the opened position when the contact is shorted out, which in turn, makes the LED AUX1 turn on.
- Valve closed: it means the valve is at the position the user determined as closed. For the FPAC it means the shaft is in the position where the bottom cam magnet is facing the canister that activates the bottom internal Hall Effect limit switch, which makes the LED CLSD turn on. Alternatively, a dry-contact connected to discrete input AUX2 can be used to indicate the closed position when the contact is shorted out. This makes the LED AUX2 turn on.
- Valve is opening: the valve is moving from the closed position to the opened position. The FPAC recognizes this state just after the closed limit switch has been deactivated but the opened limit switch is still not activate.
- Valve is closing: the valve is moving from the opened position to the closed position. The FPAC recognizes this state just after the opened limit switch has been deactivated but the closed limit switch is still not activate.
- Intermediate position: the valve can be either opening or closing. This condition always happens when both limit switches are not active. If the optional potentiometers is used the exact position can be determined.

- Valve is stopped: the valve was either opening or closing, then it stopped somewhere along the stroke. For the DI block this condition happens when both position sensors are not active, indicating the valve is not closed and not opened.
- Open: command sent by a DO block to move the valve to the opened position. Typically this command will energize the corresponding output, with the LED turning on.
- Close: command sent by a DO block to move the valve to the closed position. Typically this command will de-energize the corresponding output, with the LED turning off.
- Stop: for the D0 block this command turns OFF (de-energizes) both outputs on a Double Action solenoid valve, making it stop at the current position, including anywhere in the middle of the stroke. The operation and position where the valve will stop depends on pneumatic connection and application.
- TB or TRD: Transducer block or simply Transducer, used to insulates function blocks from the specifics of I/O hardware, such as sensors, actuators, and switches. Transducer blocks allow for configuration and perform functions such as calibration. Transducer blocks are defined to decouple function blocks from the local input/output functions required to read sensor hardware and command effector hardware.
  - FPAC provides two ENHANCED STANDARD DISCRETE POSITIONER TRANSDUCER BLOCKS, that allow control and monitoring of up to 2 (two) valves. They are referred in this document as TB1/TB2, TRD1/TRD2 or Std Transducer 1/2.
- It also provides 2 diagnostics transducer blocks with a variety of diagnostics such as cycle counter, cycle time measurement, open and close times among others. They are referred in this document as TB3/TB4, TRD3/TRD4 or DIAG1/DIAG2.
- Direct action: also known as "increase to open". When the valve set-point = '1' (on the transducer block or DO block) FPAC activates its output and power the solenoid that forces the actuator/valve to the Opened position. This is often referred as a fail closed valve because in the absence of power the pneumatics/actuator spring will force the valve to the closed position.
- Reverse action: also known as "increase to close". When the valve set-point = '1' (on transducer block or D0 block) FPAC deactivates its output removing power from the solenoid.

### **4 INSTALLATION**

### 4.1 Mounting

4.1.1 Intellis 7300 (the FPAC) electronic module overview

- The Intellis 7300 electronic module (the FPAC) includes the following physical I/O:
- 1 (one) bus connector for Foundation Fieldbus compliant bus (J2);
- 1 (one) analog input for position sensing potentiometer (J5);
- 2 (two) internal Hall Effect limit switches to be used with the cam shaft magnets;
- 2 (two) dry-contact discrete inputs AUX1 and AUX2 (J4);
- 2 (two) current source outputs for ultra-low power solenoids OUT0 and OUT1 (J3);
- See the technical specification page for more information on electrical characteristics and limits.

### FIGURE 1

Example of 7379 internal components and explosion proof junction box

The FPAC module can control and/or monitor up to 2 (two) independent valves. The internal Hall Effect sensors read the cam shaft magnets, thus the "valve 1" or "local valve" has to be the one where the housing shaft is attached to and is, in turn, rotary. Typically the solenoid to control valve 1 is wired to OUT0. See Appendix A for more details on how to adjust the cams for internal sensors.

The "valve 2" or "remote valve" can be either rotary or linear depending on the installation. The limit switches for the remote valve are typically connected to auxiliary inputs AUX1 and AUX2, while the solenoid to control valve 2 is wired to OUT1.

 Discrete inputs AUX1 and AUX2, when not used to monitor valve position, can be used as general purpose dry contact inputs to connect leak detectors, tamper proof switches, level or pressure switches and so forth. See technical specification page for characteristics and limits.



FIGURE 2 FPAC module overview



### 4.1.2 Description of the DIP switch

For more information on every function of the DIP switches see Appendix B.

Switch	Name	Function
1	WRP - Write Protect	Disable writing to parameters in the blocks
2	SIM - Simulate Enable	Enable simulation capability for the blocks
3	FCT - Factory Default	Restore factory default values to non-volatile parameters
4	CAL - Calibration Enable	Enable local calibration and Real Time Clock adjustment
5	0/C - Open/Close	Open or close the valve during local calibration
6*	AUX - Auxiliary function	Enable high current mode. See note below

\* THIS SWITCH SHOULD ALWAYS BE IN THE OFF POSITION, unless FPAC is configured to control 2 (TWO) SINGLE ACTION VALVES with power coming from the bus. It is NOT necessary to turn switch #6 ON for any other configuration. Use the MODULE\_IO\_SUMMARY parameter from the Diagnostics transducer block to read the switch status.

### 4.1.3 Description of the LEDs

On power up, all LEDs blink once for a self-test. Then each LED assumes its normal function as indicated in the table below, except when a factory default is underway. See Appendix B for more information on the factory default procedure using the dip switch and the behavior of the LEDs.

LED	Function	ON	Blinking	OFF
BUS	Bus communication status	There is activity on the bus but the device	There is activity on the bus and the device is ready	There is no activity at all on
		is not ready	to use	the bus
OPEN	Top Hall Effect limit switch	TOP Hall sensor is active, magnet detected	Factory default	The TOP switch is not active
CLSD	Bottom Hall Effect limit	The BOT Hall sensor is active, magnet	Factory default	The BOT switch is not active
	switch	detected		
AUX1	Auxiliary discrete input 1	AUX1, J4 pins 1,2 are shorted out	Factory default	AUX1 J4 pins 1,2 are opened
AUX2	Auxiliary discrete input 2	AUX2, J4 pins 3,4 are shorted out	Factory default	AUX2 J4 pins 3,4 are opened
OUTO	Discrete output 0	OUTO (J3 pins 1,2) is energized and there is	The output is energized but the load is open or	OUT0 is not energized
		a normal load connected to it	short-circuited (See OUT_LOAD_STATUS parameter	
			in the Diagnostics block for more details)	
OUT1	Discrete output 1	OUT1 (J3 pins 3,4) is energized and there is	The output is energized but the load is open or	OUT1 is not energized
		a normal load connected to it	short-circuited (See OUT_LOAD_STATUS parameter	
			in the Diagnostics block for more details)	



4.1.4 Pneumatic connections

### WARNING

Personal injury and/or property damage may occur from loss of process control if the supply medium is not clean, dry, oil-free and noncorrosive. Instrument quality air that meets the requirements of ISA S7.3-1975 is recommended for use with pneumatic equipment in process control environments. Westlock Controls recommends the use of a 20 micron filter with all solenoids.

### 4.1.5 Tubing and fittings

The use of copper, stainless steel, nylon or polyethylene tubing is recommended for piping up air circuits and equipment. As a general rule, pipe threaded fittings should not be assembled to a specific torgue because the torgue required for a reliable joint varies with thread quality, port and fitting materials, sealant used, and other factors. The suggested method of assembling pipe threaded connections is to assemble them finger tight and then wrench tighten further to a specified number of turns from finger tight. The assembly procedure given below is for reference only; the fitting should not be over tightened for this will lead to distortion and most likely, complete valve failure.

- Inspect ports and connectors to ensure that the threads on both are free of dirt, burrs and excessive nicks.
- 2. Apply sealant/lubricant or Teflon tape to the male pipe threads. With any sealant tape, the first one or two threads should be left uncovered to avoid system contamination.
- 3. Screw the connector into the port to the finger tight position.
- Wrench tighten the connector approximately 1 - 2 turns (to seal) from finger tight. Again this is only reference - the fitting should NOT be over tightened.

4.1.6 Porting for falcon solenoids

4.1.7 Wiring instructions and examples

### WARNING

All wiring must be in accordance with National Electrical Code (ANSI-NFPA-70) for the appropriate area classifications or the local electrical code when applicable. Always check the nameplate to make sure the agency approval ratings coincide with the application.

### NOTE

The proper wiring diagram for your unit is shown on the inside of the enclosure cover.

*4.1.8 FPAC BUS Connector pin out* See Figure 3.

### NOTE

The FF input is polarity insensitive.



**3 Way spring return valve** Description of operation: Solenoid de-energized - air flows from Outlet Port 2 to Exhaust Port 3.

Solenoid energized - air flows from Inlet Port 1 to Outlet Port 2.



**4 way spring return valve** Description of operation:

Solenoid de-energized - air flows from Inlet Port 1 to Outlet Port 2 and exhausts from Port 4 to Port 5.

Solenoid energized - air flows from Inlet Port 1 to Outlet Port 4 and exhausts from Port 2 to Port 3.

FIGURE 4 FPAC mini and micro connectors pin out



### 4.2 Calibration

- 4.2.1 Configuration and operation
- 4.2.1.1 Configuration overview

This section shows how to configure and operate the FPAC provided it has been properly installed. Basically what you need to operate FPAC is to create a control strategy linking the function blocks in the FPAC with function blocks in the control application/strategy. The way this is accomplished is particular for control system from different vendors and will not be addressed in this document. Contact Westlock for technical notes regarding your particular FF Host system. This IOM will show a general overview about the possible applications with some examples. The examples shown hereafter assume the device has been commissioned and is at the factory default configuration. Factory default configuration pre-configures some block parameters for the typical applications. See Appendix B for factory default procedure and Appendix D for a complete list of parameters including default values. The most important parameters used for the configuration and operation of the FPAC are:

• RESOURCE BLOCK

- MODE\_BLK: after factory default goes to AUTO.
- DISCRETE STANDARD TRANSDUCER BLOCK
   MODE, BLK: parmally chauld be in AUTO
- MODE\_BLK: normally should be in AUTO. When in MAN it allows direct control of outputs.
- SIGNAL\_ACTION: after factory default TB1 = Increase to Open.
- ACTION\_ELEMENT: after factory default TB1 = Single Action.
- IO\_ASSIGNMENT: after factory default: TB1 = Top,Bot,Out0.
- SET\_CURRENT\_SINK: used to increase bus current when FPAC controls 2 (two) single action valves.
- WORKING\_POS\_D: this is the raw value obtained from the limit switches configured in the IO\_ASSIGNMENT parameter. For example, if the limit switch that indicates valve opened is active, WORKING\_POS\_D = '1' (OPENED).
- WORKING\_SP\_D: this parameter can be written manually when the block mode is MAN. This is the raw value that goes to the physical output(s) configured in the IO\_ASSIGNMENT parameter: write '0' to CLOSE, '1' to OPEN and '2' to STOP.

- DIAGNOSTIC TRANSDUCER BLOCK
- MODE\_BLK: normally should be in AUTO.
   MODULE\_IO\_SUMMARY: allow user to monitor the raw value for any I/O in the
- device.OUT\_LOAD\_STATUS: outputs diagnostics for coil/piezo short or open detection.
- DISCRETE OUTPUT BLOCK:
- MODE\_BLK: normally in CAS+AUTO for automatic control. Can also be used in MAN or AUTO for testing purposes and manual control.
- CHANNEL: configured for the target transducer block.
- OUT\_D: value and status sent to transducer block via configured channel.
- SP\_D: block set-point, can be written in MAN. When in MAN, write to this parameter to control valve position: write '0' to CLOSE, '1' to OPEN and '2' to STOP.
- CAS\_IN\_D: remote set-point, written by another block in the application/control strategy through a fieldbus link.
- READBACK\_D: position feedback taken from the transducer block channel. Typically '0' = CLOSED, '1' = OPENED, '2' = STOPPED, '3' = OPENING and '4' = CLOSING.
- BKCAL\_OUT\_D: position feedback sent to another function block in the application/ control strategy through a fieldbus link.
   Typically '0' = CLOSED, '1' = OPENED, '2' = STOPPED, '3' = OPENING and '4' = CLOSING.
- DISCRETE INPUT BLOCK
- MODE\_BLK: typically in AUTO.
- CHANNEL: configured for the target transducer block.
- OUT\_D: position feedback sent to another function block in the application/control strategy through a fieldbus link. Typically
   '0' = CLOSED, '1' = OPENED, '2' = STOPPED, '3' = OPENING and '4' = CLOSING.
- ANALOG INPUT BLOCK
- MODE BLK: usually in AUTO.
- CHANNEL: configured for position or temperature.
- OUT: position feedback in % open sent to another function block in the application/ control strategy through a fieldbus link. Alternatively it can be the onboard temperature depending on channel configuration.

### 4.2.2 Installing DD/CF and handheld support files

Registered DD/CF files can be downloaded from the Fieldbus Foundation registered products website: www.fieldbus.org.

For more information on how to install the files see an example on Appendix G. Contact Westlock in case of any problem.

### 4.2.3 Configuration examples

Among the many possible applications the examples herein will give you an idea of the flexibility of the Intellis 7300 (the FPAC). The examples shown typically do not depend on the model/housing and can be applied to any FF Host or control system. Contact Westlock in case of any question. Despite of the tremendous flexibility of the FPAC, you will need to configure just a few parameters to get it working. Most of the block parameters are pre-configured at factory default. See Appendix B for factory default instructions and Appendix D for a complete list of blocks and parameters including default values. Look up in the table below the example(s) that is closest to your application. It is easy to adapt the examples for applications that are not listed.

Example #	Number		Type (Valve1/	SOV (number	Commonte
1A, 1B, 1C	One	Control / not used	Rotary	One	Typical installation for the 7344 model
2	One	Control / not used	Rotary	Two	One SOV with 2 piezos on the same housing (LG2 housing)
3A, 3B	One	Control / not used	Linear	One	Using Silver Bullet/Magnum for the linear actuator
4	Two	Control / control	Rotary/rotary	One	Using 764 for the second valve (second housing has only switches and SOV)
5	Two	Control / monitor	Rotary/linear	Two	Using dual coil/piezo solenoid for the local valve; Silver Bullet/Magnum to monitor position of the remote linear valve
6A, 6B	One	Monitoring and control	Rotary	One	Using potentiometer connected to analog input J5 instead of cam shaft magnets

**Note:** the examples below use a FF Host system to configure and exemplify some control strategies. You can adapt the examples according to your application.

**Note:** the examples assume the reader has a good knowledge of the FF Host system, as tasks like device commissioning, I/O assignment, device configuration and setup, control module edition etc. are not covered in detail.

4.2.4 Configuration for example #1: one valve, rotary, simple solenoid

This example assumes the device is at the factory default state. The FPAC is installed on top of the actuator and the internal Hall effect sensors are used as limit switches. It assumes it is wired as illustrated in the previous section "Wiring for Example #1". The tables below show 3 (three) possible realizations for this example:

A. Just monitoring the valve with one DI block. The valve is controlled by some other means (manually or by a separate controller):

Blocks and parameters that need configuration				
Resource	TB1	DI_1		
MODE_BLK = AUTO	ACTION_ELEMENT = 4: Monitoring	MODE_BLK = AUTO		
	MODE BLK = AUTO			

B. The second variant of the example assumes the FPAC is controlling the valve using a D0 block (OUT0 is used to power the solenoid) and the position feedback is given by the same D0 through BKCAL\_OUT\_D parameter:

Blocks and parameters that need configuration				
Resource	TB1	D0_1		
MODE_BLK = AUTO	MODE_BLK = AUTO	IO_OPTS = Use PV for BKCAL_OUT		
		MODE BLK = CAS+AUTO*		

C. The third variant of the example uses a combination of one DO block to control the valve position (OUT0 is used to power the solenoid) and 2 (two) DI blocks for the position feedback:

Blocks and parameters that need configuration					
Resource	TB1	D0_1	DI_1 (CLOSED)	DI_2 (OPENED)	
MODE_BLK = AUTO	MODE_BLK = AUTO	IO_OPTS = Use	CHANNEL = 11:	CHANNEL = 10:	
		PV for BKCAL_	TRD1: 0-Not Closed /	TRD1: 0-Not Opened /	
		OUT	1-Closed	1-Opened	
		MODE_BLK =	MODE_BLK = AUTO	MODE_BLK = AUTO	
		CAS+AUTO*			

### 4.2.4.1 Just monitoring one valve with a DI block

The transducer block configuration for this example is going to be shown in two ways: first using the DD method "Basic Device Configuration" to configure the transducer blocks; second writing directly to block parameters. The rest of the example is the same independently of the way you prefer to configure the transducer.

4.2.4.1.1 Transducer configuration using the DD method "Basic Device Configuration"

- 1. This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- 3. Right-click on the device you want to configure and chose Configure/Setup. See Figure 5.
- 4. The Device Identification window will appear after a few seconds. Click on Basic Device Configuration to start the method. A series of warning windows will be shown. Read them carefully and click Next until the method starts making changes to the device. See Figure 6.
- 5. A series of messages will be displayed, for a few seconds. Wait until the message "Transducer blocks are in OOS (WCON005)" is shown. Then click Next.
- 6. Configure there is only 1 valve attached to this FPAC and click on Next. Configure the FPAC will be just monitoring the valve and click on Next. See Figure 7.

### FIGURE 5



### FIGURE 7

Basic Device Configuration - FPAC2	×	Siz Basic Device Configuration - FPAC2	×
Are you going to connect 1 or 2 Valve(s) / Actuato(s)? (WCON006) C 1 or 2 Valve(s) / Actuato(s)? C 2 (two) C Abort		Are you going to use the valve(s) for monitoring and control or just for monitoring? (WCONKOR) (* Monit Only) (* Monit Control (* Abot (* Back	
Next> Cancel	Help	Next> Cancel Help	

- Choose now the internal sensors and click Next. Configure the valve type is Rotary. This is informative and does not affect any functionality. Click on Next to continue. See Figure 8.
- A series of messages will follow, for a few seconds. Wait until the message "Configuration finished. Start downloading/ writing...(WCON0019)" appears, then click on Next to continue.
- Another series of configuration messages will be shown. Wait until the message "Configuration finished. Returning transducers to Auto...(WCON0020)" appears, then click on Finish to close the method window.
- 10. Close the Configure/Setup window. If you want see how to configure the blocks directly without the method, proceed to the next section. If you want to go directly to control module example, skip the next section.

4.2.4.1.2 Transducer configuration writing directly to block parameters

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- Right-click on the device you want to configure and chose Configure/Setup. See Figure 9.
- The Device Identification window will appear after a few seconds. Click on Transducer Basic Setup and wait a few seconds until all parameters are read.
- In the Std Transducer 1 parameters group, click on the parameter ACTION\_ELEMENT drop box and select the option Monitoring. Click on Apply, and then on the screen that opens click on Yes. See Figure 10.

### FIGURE 8



### FIGURE 9

FIGURE 10



- 6. On the menu tree, select Function Block Utils, then click on Block Modes and finally select the tab Block Mode-Std Transducer. In the Std TRD 1 Target Mode group, select the target mode to Automatic. Make sure to uncheck the Out of Service option. Click on Apply to write the configuration. See Figure 11.
- After a few seconds, confirm the transducer block changed the mode to Automatic by observing the parameters in the left side of the window, group Std TRD 1 Actual Mode. See Figure 12.
- 8. Close Configure/Setup window.

4.2.4.1.3 Control module using the DI block **Note:** although possible, it is not recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section.

- Open or create a control module and add one DI block. Assign this DI block to the DI\_1 block in the FPAC. If desired, add more blocks and create links from the DI\_1. OUT\_D.
- Click on the DI block and make sure that Mode = Auto and Channel = 9 - TRD1: 0-Closed / 1-Opened. See Figure 13.
- 3. Download the control module configuration the fieldbus network. See Figure 14.

### FIGURE 11

#### FIGURE 12



2 4

signed to CTLA-STERRO

Hardwide Co.

4. When the download finishes, open the control module on-line to verify the DI.OUT\_D parameter. Move the valve and observe it will show '0' for valve closed, '1' for valve opened and '3' or '4' for opening/closing positions. The LEDs on the module will indicate the position accordingly. Notice the block linked to the DI is also receiving the same values. See Figure 15.

### 4.2.4.2 Controlling and monitoring one valve with a DO block

The second variant of the example #1 assumes the FPAC is controlling the same valve assembly using a D0 block. The position feedback is given by the same D0 through BKCAL\_OUT\_D parameter:

Blocks and parameters that need configuration				
Resource	TB1	D0_1		
MODE_BLK = AUTO	MODE_BLK = AUTO	IO_OPTS = Use PV for BKCAL_OUT		
		MODE_BLK = CAS+AUTO*		

\* For testing purposes mode can be set to AUTO or MAN.

- 1. This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.

### FIGURE 15


- Right-click on the device you want to configure and chose Configure/Setup. See Figure 16.
- 4. On the menu tree, select Function Block Utils, then click on Block Modes and finally select the tab Block Mode-Std Transducer. In the Std TRD 1 Target Mode group, select the target mode to Automatic. Make sure to uncheck the Out of Service option. Click on Apply to write the configuration. See Figure 17.
- After a few seconds, confirm the transducer block changed the mode to Automatic by observing the parameters in the left side of the window, group Std TRD 1 Actual Mode. See Figure 18.
- 6. Important: at this point in the configuration, if you check the transducer block 1 diagnostics you will see that BLOCK\_ERR parameter will be indicating Block Configuration error and the Resource Block will be indicating Device Fault State. These errors will be cleared once the DO is configured.
- 7. Close Configure/Setup window.
- Open or create a control module and add one D0 block. Assign this D0 block to the D0\_1 block in the FPAC. If desired, add more blocks and create links to D0\_1. CAS\_IN\_D and from D0\_1.BKCAL\_OUT\_D.







- Click on the D0 block and make sure that Mode = Auto, I0\_OPTS = Use PV for BKCAL\_ OUT and Channel = 1 - TRD1: 0-Close / 1-Open. See Figure 19.
- 10. Download the control module configuration to the fieldbus network. See Figure 20.







11. When the download finishes, open the control module on-line. Move the valve by changing the parameter linked to the DO\_1.CAS\_IN\_D and observe the valve position feedback will show '0' for valve closed, '1' for valve opened, '3' for valve opening or '4' for valve closing. The LEDs on the module will indicate the position accordingly. Notice the block linked to the DI is also receiving the same values. See Figure 21.

4.2.4.3 Controlling and monitoring one valve with one DO block and two DI blocks The third variant of the example #1 shows a combination of one DO block to control the valve position and 2 (two) DI blocks for the position feedback.

Blocks and parameters that need configuration					
Resource	TB1	D0_1	DI_1 (CLOSED)	DI_2 (OPENED)	
MODE_BLK =	MODE_BLK =	I0_0PTS = Use PV	CHANNEL = 11:	CHANNEL = 10:	
AUTO	AUTO	for BKCAL_OUT	TRD1: 0-Not Closed /	TRD1: 0-Not	
			1-Closed	Opened / 1-Opened	
		MODE_BLK = CAS+AUTO*	MODE_BLK = AUTO	MODE_BLK = AUTO	

 $\ast$  For testing purposes mode can be set to AUTO or MAN.

- 1. This example utilizes the exact same configuration of the previous example for the transducer TB1 and D0\_1 blocks. Therefore, we can jump straight to the control module differences that are basically the DI blocks.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- Open or create a control module and add one DO block and two DI blocks: DI\_CLOSED and DI\_OPENED. Assign the DO and DI blocks in the control module to FPCA's DO\_1, DI\_1 and DI\_2 respectively. If desired, add more blocks and create links from/to these blocks.
- Click on the D0 block and make sure that Mode = Auto, I0\_0PTS = Use PV for BKCAL\_0UT and Channel = 1 - TRD1: 0-Close / 1-Open, identical to the previous example.



- Click on the DI\_CLOSED block and make sure that Mode = Auto and Channel = 11: TRD1: 0-Not Closed / 1-Closed. Notice that '1' in this DI output means the valve is CLOSED, which is not the typical convention but may be useful in some applications.
- Click on the DI\_OPEN block and make sure that Mode = Auto and Channel = 10 TRD1: 0-Not Opened / 1-Opened.
- 7. Download the control module configuration to the fieldbus network.
- 8. When the download finishes, open the control module on-line. Move the valve by changing the parameter linked to the DO\_1.CAS\_IN\_D and observe the valve position feedback will show '0' for valve closed, '1' for valve opened, '3' for valve opening or '4' for valve closing. The LEDs on the module will indicate the position accordingly. Notice the block linked to the DI is also receiving the same values. See Figure 22.
- Compare the position indication amongst the blocks. Notice the indication "valve opening" or "valve closing" is only present in the DO.BKCAL\_OUT\_D.



4.2.5 Configuration for example #2: one valve, rotary, dual coil/piezo solenoid

This example assumes the device is at the factory default state. It shows control and monitoring of one rotary valve with dual coil/piezo solenoid (Double Action). The FPAC is installed on top of the actuator and the internal Hall effect sensors are used as limit switches. It assumes it is wired as illustrated in the previous section "Wiring for Example #2".OUT0 and OUT1 are used to power the double coil/piezo solenoid valve. The DO\_1 block is used for control and feedback. DI\_1 is optional and can also be used for position feedback. In addition, DO and DI channels with the option "2-Stop" are chosen to illustrate the usage. The following parameters need to be configured:

Blocks and parameters that need configuration				
Resource	TB1	D0_1	DI_1 (Optional)	
MODE_BLK = AUTO	ACTION_ELEMENT =	IO_OPTS = Use PV for	CHANNEL = TRD1:	
	Double Action	BKCAL_OUT	0-Close / 1-Open / 2-Stop	
	MODE_BLK = AUTO	CHANNEL = TRD1:	MODE_BLK = AUTO	
		0-Close / 1-Open / 2-Stop		
		MODE BLK = $CAS+AUTO*$		

\* For testing purposes mode can be set to AUTO or MAN.

**Note:** for double action valves it is possible to command the DO block to "STOP" the valve at the current position writing value '2' to the set-point. The transducer block will deactivate both OUT0 and OUT1 to trap the air in the actuator causing the valve to stay at the current position. Depending on the time to open or close the valve may stop at any intermediate position. **Note:** in this configuration, despite the fact that FPAC is powering two coils/piezos, there is only one coil/piezo powered at a time, so the dipswitch #6 must remain OFF and the power consumption of the module is 12 mA. In the STOP condition both outputs are de-energized.

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- 3. Right-click on the device you want to configure and chose Configure/Setup. See Figure 23.



- The Device Identification window will appear after a few seconds. Click on Basic Device Configuration to start the method. A series of warning windows will be shown. Read them carefully and click Next until the method starts making changes to the device. See Figure 24.
- A series of messages will be displayed, for a few seconds. Wait until the message "Transducer blocks are in OOS (WCON005)" is shown. Then click Next.
- Configure there is only 1 valve attached to this FPAC and click on Next. Select Monit Control and click on Next. See Figure 25.
- Choose internal sensors option and click Next. Configure for a Double Action (dual coil/piezo solenoid) and click Next. See Figure 26.



#### FIGURE 25

Bosic Device Configuration - FPAC2 Ase you going to connect 1 or 2 Valve(s) / Actualo(s)? (WCDN006)	×	Basic Device Configuration - FPAC2 Are you going to use the valve(s) for monitoring and control or just for monitoring? (\not Work 008) (\not Work 009) (\not Konta) (\not Ko	×
Cancel	Help	Next > Cancel Help	

18 Basic Device Configuration - FPAC2	×	Basic Device Configuration - FPAC2	×
Is the device using the internal position (Hall) sensors (Nor instance, a device mounted on top of a rotary actuator, using the internal shaft sensors) or is it using the auxiliar inputs, Aux 1 and Aux 2 (Nor instance, a device connected to limit switches of a linear actuator) ? (VCDN000) (* [Im: Sensor C Aux Sensor C Back		Is the actuator single action or double action? (wCDN010) C Single C Single C Back	
Next> Cancel Hep		Next> Cancel	el Help

- Configure the valve type is Rotary. This is informative and does not affect any functionality. Click on Next to continue. See Figure 27.
- A series of messages will follow, for a few seconds. Wait until the message "Configuration finished. Start downloading/ writing...(WCON0019)" appears, then click on Next to continue.
- 10. Another series of configuration messages will be shown. Wait until the message "Configuration finished. Returning transducers to Auto...[WCON0020]" appears, then click on Finish to close the method window. Close the Configure/Setup window. Note: although possible, it is not

recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section.

- 11. Open or create a control module and add one D0 block and one DI block. Assign these blocks to FPAC's D0\_1 and DI\_1 respectively. If desired, add more blocks and create links to D0\_1.CAS\_IN\_D, DI\_1.0UT\_D and from D0\_1.BKCAL\_OUT\_D.
- 12. Click on the DO block and make sure that Mode = Auto, IO\_OPTS = Use PV for BKCAL\_ OUT and Channel = 5 - TRD1: 0-Close / 1-Open / 2-Stop. See Figure 28.
- 13. Click on the DI block and make sure that Mode = Auto and Channel = 12 -TRD1: 0-Closed / 1-Opened / 2-Stopped. See Figure 29.

FIGURE 29

2 - TRD1: 0-Closed

/1-Opened /2-Stopped

# Set Basic Device Configuration - FPAC2 Is the actuator rotary or linear? Obs: The local actuator is the one directly mounted with the FPAC. The local actuator is always notary and the feedback used is the intermal Hall (magnetic field) sensors. (wCDN011) @ Flotail C. Linear C. Abott C. Ab

Cancel

Help

Next >

FIGURE 28

FIGURE 27

Allow user-entered value	Value:
/alue:	Use Fault Store
5 - TRD1: 0-Close /1-Open /2-Stop	SP-PV Track in LO or IMan

-

- 14. Download the control module configuration to the fieldbus network.
- 15. When the download finishes, open the control module on-line. Move the valve by changing the parameter linked to the DO\_1. CAS\_IN\_D and observe the valve position feedback will show '0' for valve closed, '1' for valve opened, '2' for valve stopped, '3' for valve opening and '4' for valve closing. The LEDs on the module will indicate the position accordingly. The values. Notice the block linked to the DI is also receiving the same values. See Figure 30.

**Note:** values '3' = OPENING and '4' = CLOSING may only be seen for assemblies where the time to open/close is at least a few seconds. Faster valves will make the position feedback switch from '0'=CLOSED to '1' = OPENED and vice-versa.

**Note:** the feedback value '2' = STOPPED is only seen when the D0 commands the valve to stop. If this command is sent right after an open/ close command, while the valve is still moving (closing or opening) the valve may stop at an intermediate position. See screenshots below. These conditions can be reproduced manually of using a very slow assembly. See Figure 31.





4.2.6 Configuration for example #3: one valve, linear, with simple solenoid This example is similar to example #1. The only difference is that FPAC uses auxiliary inputs AUX1 and AUX2 for the limit switches. Because of DD method convention, this example uses OUT1 to power the solenoid. Position feedback is given by the DO through BKCAL\_OUT\_D parameter. It assumes it is wired as illustrated in the previous section "Wiring for Example #3". This example assumes the device is at the factory default state. It shows control and monitoring of one linear valve with simple solenoid (single coil/piezo). The following parameters need to be configured:

A. Just monitoring the valve with one DI block. Transducer block TB2 is used. The valve is controlled by some other means (manually or by a separate controller):

Blocks and parameters that need configuration				
Resource	TB2	DI_1		
MODE_BLK = AUTO	ACTION_ELEMENT = 4: Monitoring	MODE_BLK = AUTO		
	IO_ASSIGNMENT = Aux1,Aux2,Out1			
	MODE_BLK = AUTO			

B. The second variant of the example assumes the FPAC is controlling the valve using a D0 block (OUT1 is used to power the solenoid) and the position feedback is given by the same D0 through BKCAL\_OUT\_D parameter:

Blocks and parameters that need configuration			
Resource	TB2	D0_1	
MODE_BLK = AUTO	ACTION_ELEMENT = 4: Monitoring	IO_OPTS = Use PV for BKCAL_OUT	
	IO_ASSIGNMENT = Aux1,Aux2,Out1	CHANNEL: TRD2: 0-Close / 1-Open	
	MODE_BLK = AUTO	MODE_BLK = CAS+AUTO*	

\* For testing purposes mode can be set to AUTO or MAN.

- To configure this application using the DD method, follow the same steps illustrated in example #1 except that you should choose Aux sensor for the limit switches and click Next. Configure the valve type for Linear and click on Next to continue. See the screenshots below.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state. See Figure 32.
- 3. The strategy for the linear valve is exactly the same as for the rotary valve in example #1. The linear valve can be monitored and controlled using a combination of D0 and DI blocks depending on the application requirements.

**Note:** the physical limit switches must be wired to AUX1 and AUX2 at the J4 connector. LEDs AUX1=0PENED and AUX2=CLOSED should be used to verified the limit switches activity. The solenoid coil/piezo must be wired to 0UT1.

**Note:** although possible, it is not recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section.

ZBasic Device Configuration - FPAC2	×	Basic Device Configuration - FPAC2	×
Is the device using the internal position (Hall) sensors (for instance, a device mounted on top of a rotary actuator, using the internal shaft sensors) or is it using the auxiliar inputs, Aux 1 and Aux 2 (for instance, a device connected to limit switches of a linear actuator) ? (WCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (MCDND09) (		Is the actuator rotary or linear? Obc. The local actuator is the one directly mounted with the FPAC. The local actuator is adexys to cary and the feedback used is the internal Hall (magnetic field) sensors. (WCON011) C Rotary C Extransl Abot C Black	
Next> Cancel Help		Next> Cancel H	lelp

#### 4.2.7 Configuration for example #4: two rotary valves, direct and reverse action

This example shows control and monitoring of two rotary valves with simple solenoids (single coil/ piezo). Position feedback is given by the DO blocks through BKCAL\_OUT\_D parameter. It assumes it is wired as illustrated in the previous section "Wiring for Example #4".The next sections show 2 (two) possible realizations for this example:

- 1. Just monitoring the 2 (two) valves with DI blocks (it does not control the solenoids).
- 2. Controlling and monitoring the 2 (two) valves with D0 blocks.

#### 4.2.7.1 Just monitoring two valves using DI blocks

This example assumes the device is at the factory default state. It shows monitoring of two rotary valves. Position feedback is given by DI blocks. Since the valves are controlled by some other means it does not matter if the valve is direct or reverse action.

- Valve 1 uses internal TOP and BOTTOM Hall effect sensors as limit switches.
- Valve 2 uses AUX1 (OPENED) and AUX2 (CLOSED) inputs for the limit switches.

Blocks and parameters that need configuration				
Resource	TB1	DI_1	TB2	DI_2
MODE_BLK =	ACTION_ELEMENT =	MODE_BLK = AUTO	ACTION_ELEMENT =	CHANNEL = TRD2:
AUTO	Monitoring		Monitoring	0-Close / 1=Open
	MODE_BLK = AUTO		IO_ASSIGNMENT =	MODE_BLK = AUTO
			Aux1,Aux2,Out1	
			MODE_BLK = AUTO	

\* For testing purposes mode can be set to AUTO or MAN.

This example does not use the DD method. It shows how to configure the parameters directly in the transducer blocks.

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- 3. Right-click on the device you want to configure and chose Configure/Setup. See Figure 33.



- On the menu tree, click on Basic Setup, then click on Transducer Basic Setup.
   On the Std Transducer 1 group, click on ACTION\_ELEMENT parameter drop box and select Monitoring. Repeat this for the Std Transducer 2. Click on Apply. See Figure 34.
- 5. On the menu tree, click on Function Block Utils, then click on Block Modes and finally select the tab Block Mode-Std Transducer. In the Std TRD 1 Target Mode group, select the target mode to Automatic. Make sure to uncheck the Out of Service option. Scroll down the window and check Automatic also for the Std TRD 2 Target Mode. Click on Apply to write the configuration. See Figure 35.

PAC2[PPAC Res.5]		J.
Configure/Setup	12 Trendson Bris Set p	
- G Carlow, Sec. p		
8-1-Dext Setup	EditoreAce 1	- Sid Travolueir 2
- the framework fait for an	ACTON ELEMENT	ACTON CLOHOVT
L-3 Resource Black Senup	Poseng 1	Learned T
8 2-Advanced Solup	LC ADDRINE X1	LC-USERPER.
8 3CdBaten	Top.1 of mo. Dell	Ant An 2011
11 TF and the Rest USA	Signal Action	SpelActor
Adding Patrick and	Prosace fo Spec	Promane To Open
+ 2 Pade Back-OC	Participa (05 Datase	Producer DOS Oxform
40 Pade State OD and 4	FeiOset	Fel Court .
+2/9 Clannes	Hand a Alberta Streets	Wild Fack Data Vision Francis
en biel chickes wer /the	San an one case too me	Statistic Solition (Sector)
	man and a	
	Poly and Second	Print had been clean
	hoo res and	here converse
	End TRD 1 Cusert Sirk	Std. TRD 2 Current Sink
	SET_CLEEDITSING	SET_CURRENTIER.
1	Kaneri Leve 1 2	Caller Frida
Configure. Setup	Das Turolana 1	Diss Furniture 2
	HODELT LOS BRADY	MODULE LO SPANNY
K Device programmed		
Process Variables	G vite	O WP
2	() SN	0.94
ĩ	HE Caser	CK Cancel Scott Hee



 After a few seconds, confirm both transducer blocks changed the mode to Automatic by observing the parameters in the left side of the window, group Std TRD 1 Actual Mode. Scroll down and check also Std TRD 2 Actual Mode. See Figure 36.

**Note:** although possible, it is not recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section.

- Open or create a control module and add two DI blocks. Assign these DI blocks FPAC's DI\_1 and DI\_2 respectively. Add more blocks and create links from the DI\_1. OUT\_D and DI\_2.OUT\_D if you will.
- Click on the first DI (valve 1) and make sure that Mode = Auto and Channel = 9 - TRD1: 0-Closed / 1-Opened. See Figure 37.

# FIGURE 36

Fie Actions Balle			A 10 10 10		
Configure/Setup	41 Book Node-Researce 41 Direk Made Did Traved	ww   41 Bodi. Modo-Dog Transdavor	Configurations	ATBird Haleferover ATBackhadelist Tar	akar [41 Bei MahDig Tarakar]
Big Configurations     Configurations     Configurations     Configurations     Configuration     Configuration	Bettep 11 aget Mode Taget Mode PDJ RCa Ca R Accession Accession Dense Out of Servee	SuffRD 1 Annal Mode Annal Mode I RCu II RCU	Contract in the set of the s	16/10 / Tops Yeak -Tops Field F: Hon F: Hon F: Con F: Advante F: Honel F: Honel F: Doct Fiscal	E Derform 1970 Decarrow E Rod E Rod E Rod E Rod E denot E remit E r
Configure, Sochup		IT 0.4 starse	Translat and control of the state	** (Capet)	DK Gener

	Mad Critical High	Properties
• •	MACSALES	Allow user-entered value
Fitnedity: PPP PPPP	Matherbiosi is the application	Value:
Parameter Dettaut Linked   Fill_D_initD   MARPL_T_	ACT ACT ACT	9 - TRD1: 0-Closed /1-Opened
DearDipring.	Assigned for CTU-UT280	

- 9. Click on the second DI (valve 2) and make sure that Mode = Auto and Channel = 29 -TRD2: 0-Closed / 1-Opened. See Figure 38.
- 10. Download the control module configuration to the fieldbus network. See Figure 39.
- 11. When the download finishes, open the control module on-line. Move the valves and observe the DI outputs will show '0' for valve closed, '1' for valve opened and '3' or '4' for opening/closing positions. The LEDs on the module will indicate the position accordingly. See Figure 40.



.

÷ Close

1



✓ OnefeoLacFle

in the 100

whead Ste

 Verifying Configuration V General V Des ✓ Usdains Do

1 84



4.2.7.2 Controlling and monitoring two valves using DO blocks

This example assumes the device is at the factory default state. It shows control and monitoring of two rotary valves with simple solenoids (single coil/piezo). Position feedback is given by the DO blocks through BKCAL\_OUT\_D parameter.

- Valve 1 uses internal Hall effect sensors as limit switches and OUT0 to power the solenoid. This valve is DIRECT action (increase to open).
- Valve 2 uses AUX1 and AUX2 as limit switches and OUT1 to power the solenoid. This valve is REVERSE action (increase to close).

Blocks and parameters that need configuration				
Resource	TB1	D0_1	TB2	D0_2
MODE_BLK =	MODE_BLK = AUTO	IO_OPTS = Use PV	ACTION_ELEMENT =	IO_OPTS = Use PV for
AUTO		for BKCAL_OUT	Single Action	BKCAL_OUT
		MODE_BLK =	SIGNAL_ACTION =	CHANNEL = TRD2:
		CAS+AUTO*	Increase to Close	0-Close / 1=Open
			SET_CURRENT_SINK =	MODE_BLK =
			Current Level 2	CAS+AUTO*
			MODE_BLK = AUTO	
		CAS+AUTU	SET_CURRENT_SINK = Current Level 2 MODE_BLK = AUTO	MODE_BLK = CAS+AUTO*

\* For testing purposes mode can be set to AUTO or MAN.

**Note:** dipswitch #6 MUST BE SET TO ON otherwise the transducer blocks will not go to AUTO. To control 2 single action valves SIMULTANEOUSLY it is necessary that FPAC takes 17 mA from the bus in order to power the 2 solenoids. Therefore it is necessary to configure "SET\_CURRENT\_ SINK = Set Current Level 2" parameter and to turn dip switch 6 (AUX) on. If this is not done the second transducer configured as single action will remain with a block error AND WILL NOT CHANGE MODE TO AUTO.

**Note:** if after the configuration for two single action valves is done the dip switch 6 (AUX) is turned off, the transducer block will change state from AUTO to OOS and remain until the condition is fixed. Use MODULE\_I0\_SUMMARY parameter from the Diagnostics transducer block to read the switch status.

This example will make use of the DD method to configure both valves at once.

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- 3. Right-click on the device you want to configure and chose Configure/Setup. See Figure 41.



- The Device Identification window will appear after a few seconds. Click on Basic Device Configuration to start the method. A series of warning windows will be shown. Read them carefully and click Next until the method starts making changes to the device. See Figure 42.
- A series of messages will be displayed for a few seconds. Wait until the message "Transducer blocks are in OOS (WCON005)" is shown. Then click Next.
- Configure there are 2 valves attached to this FPAC and click on Next. Select Monit Control and click on Next. See Figure 43.



Basic Device Configuration - FPAC2	×	Seasic Device Configuration - FPAC2	×
Are you going to connect 1 or 2 Vahre(s) / Actuator(s)? (WCDN006) C 1 (one) C 20(mo) C Abort		Are you going to use the valve(s) for monitoring and control or just for monitoring? (wCDN008) C Monit Only C Monit Only C Abot C Back	
Next > Cancel	Неф	Next > Cancel Help	

- Inform these 2 valves are Single Action and click on Next. Configure the two valves are Rotary and click on Next to continue. See Figure 44.
- It is not necessary to select the I/O for the limit switches as the DD method convention for two valves is always the following:
   a. Internal Hall sensors and OUTO for valve 1
  - b. Auxiliary inputs and OUT1 for valve 2.
  - c. If you application requires a different configuration you need to change transducers configuration manually.
- Configure now the valve 1 is direct (increase to open / fail closed) and valve 2 is reverse (increase to close / fail opened). Click Next to continue.
  - a. This way, when the D0 that controls valve 1 gets '1' in the set-point it will turn the OUT0 on, powering the coil/piezo.
  - b. On the other hand, when the DO that controls valve 2 gets '1' in the set-point it will turn the OUT1 off, de-energizing the coil/piezo.
     See Figure 45.

- 10. A series of messages will follow, for a few seconds. Wait until the message "Configuration finished. Start downloading/ writing...(WCON0019)" appears, then click on Next to continue.
- 11. The method will take care of setting SET\_CURRENT\_SINK parameter to "2: Current Level 2". However, you must turn dipswitch #6 ON manually, otherwise the transducer blocks will not change the mode to AUTO and the application will not work as expected.
- 12. Another series of configuration messages will be shown. Wait until the message "Configuration finished. Returning transducers to Auto...(WCON0020)" appears, then click on Finish to close the method window. Close the Configure/Setup window.
- 13. Open or create a control module and add two DO blocks. Assign these blocks to FPAC's DO\_1 and DO\_2 respectively. If desired, add more blocks and create links.

UBasic Device Configuration - FPAC2	×	EBasic Device Configuration - FPAC2	×
You selected Two Valves: Are they connected to: 1. Two single action valves: 2. One Single Action [local] and other (aux) monitoring only 3. One monitoring only (local] and other (aux) monitoring only 4. One Double Action (local) and other (aux) monitoring only 5. One monitoring only (local) and other (aux) Double Action (WCON018) (* ]] (* ]]		Rotary or linear? Choose: 2 Rotary or 2 Linear or Rotary(local) and Linear(aus) or Linear(local) and Rotary(aux) Local is the FPAC / Intellis device mounted on top of the actuator using the internal sensors. /n Obs.: It is rare to have a Linear actuator directly mounted with the FPAC (WCON016) C <u>2 Rotary</u> C <u>2 Linear</u> C Rot and Lin C Rot and Lin C Abott C Back	
Next > Cancel Help	,	Next> Cancel Help	

UBasic Device Configuration - FPAC2	×
Is the device configured for direct action (increase to open) or reverse action close)?  Obs:: Not applicable for the monitoring-only device(s)  (WCDN017)  C 2 Direct C 2 Reverse C Dir and Rev C Rev and Dir C Abort	on (increase
C Back	
Next > Cancel	Help

- 14. Click on the first DO block (valve 1) and make sure that Mode = Auto, IO\_OPTS = Use PV for BKCAL\_OUT and Channel = 1 - TRD1: 0-Close / 1-Open. See Figure 46.
- 15. Click on the second D0 block (valve 2) and make sure that Mode = Auto, I0\_0PTS = Use PV for BKCAL\_0UT and Channel = 21 -TRD2: 0-Close / 1-0pen. See Figure 47.
- 16. Download the control module configuration to the fieldbus network.

Allow user-entered value	Value:
Value:	Use Fault State to value Fault State to value SP-PV Track in LD or IMan
1 - TRD1: 0-Close /1-Open	SP-PV Track in Man

Allow user-entered value	Value:
Value:	Use Fault st valion restart Fault State to value SP-PV Track in LO or IMan
21 - TRD2: U-Close /1-Open	SP-PV Track in Man

17. When the download finishes, open the control module on-line. Move the valve by changing the parameter linked to the D0\_1.CAS\_IN\_D and observe the valve position feedback will show '0' for valve closed, '1' for valve opened, '2' for valve stopped, '3' for valve opening and '4' for valve closing. The LEDs on the module will indicate the position accordingly. The values. Notice the block linked to the DI is also receiving the same values. See Figure 48.





**Note:** values '3' = OPENING and '4' = CLOSING may only be seen for assemblies where the time to open/close is at least a few seconds. Faster values will make the position feedback switch from '0'=CLOSED to '1' = OPENED and vice-versa.

OUT\_0

FPAC2/FFD02

4.2.8 Configuration for example #5: two valves, rotary/linear, monitoring/control This example assumes the device is at the factory default state. It assumes it is wired as illustrated in the previous section "Wiring for Example #5".The two valves in this application are as follows:

- Valve 1: rotary valve, monitoring, internal Hall Effect sensors. Valve is controlled by other means. Position feedback is performed by one FPAC DI block.
- Valve 2: linear valve, control, auxiliary inputs and OUT1. Valve is controlled by one FPAC DO which also provides the position feedback.

Blocks and parameters that need configuration				
Resource	TB1	DI_1	TB2	D0_1
MODE_BLK =	ACTION_ELEMENT =	MODE_BLK = AUTO	ACTION_ELEMENT =	IO_OPTS = Use PV for
AUTO	Monitoring		Single Action	BKCAL_OUT
	MODE_BLK = AUTO		IO_ASSIGNMENT =	CHANNEL = TRD2:
			Aux1,Aux2,Out1	0-Close / 1=Open
			MODE_BLK = AUTO	MODE_BLK =
				CAS+AUTO*

\* For testing purposes mode can be set to AUTO or MAN.

**Note:** in this configuration, despite the fact that FPAC is working with two valves, there is only one solenoid and the dipswitch #6 must remain OFF. Thus, the power consumption of the module is 12 mA.

This example will make use of the DD method to configure both valves at once.

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- 3. Right-click on the device you want to configure and chose Configure/Setup. See Figure 49.



- The Device Identification window will appear after a few seconds. Click on Basic Device Configuration to start the method. A series of warning windows will be shown. Read them carefully and click Next until the method starts making changes to the device. See Figure 50.
- A series of messages will be displayed for a few seconds. Wait until the message "Transducer blocks are in OOS (WCON005)" is shown. Then click Next.
- Configure there are 2 valves attached to this FPAC and click on Next. Select Monit Control and click on Next. See Figure 51.



Basic Device Configuration - FPAC2	×	Salasic Device Configuration - FPAC2	×
Are you going to connect 1 or 2 Valve(s) / Actuator(s)? (WCDN006) C 1 (one) C 2[](wo) C Abort		Are you going to use the valve(s) for monitoring and control or just for monitoring? (wCON006)  C Monit Only C Monit Control C Abort C Back	
Nest > Cancel	Help	Next > Cancel Help	_

- Inform to the method now that the valve

   (local valve) will be just Monitored and
   valve 2 will be controlled as Single Action
   choosing option '3' and click on Next.
   Configure the valves respectively as Rotary
   and Linear according to the screenshots
   below. Click on Next to continue.
   See Figure 52.
- It is not necessary to select the I/O for the limit switches as the DD method convention for two valves is always the following:
  - a. Internal Hall sensors and OUTO for valve 1 (local valve).
  - b. Auxiliary inputs and OUT1 for valve 2 (remote valve).
  - c. If you application requires a different configuration you need to change transducers configuration manually.
- Configure now both valves are Direct (increase to open / fail closed) and click Next. See Figure 53.
- 10. A series of messages will follow, for a few seconds. Wait until the message "Configuration finished. Start downloading/ writing...(WCON0019)" appears, then click on Next to continue.

- 11. The method will take care of setting SET\_CURRENT\_SINK parameter to "2: Current Level 2". However, you must turn dipswitch #6 ON manually, otherwise the transducer blocks will not change the mode to AUTO and the application will not work as expected.
- 12. Another series of configuration messages will be shown. Wait until the message "Configuration finished. Returning transducers to Auto...(WCON0020)" appears, then click on Finish to close the method window. Close the Configure/Setup window.

**Note:** although possible, it is not recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section.

13. Open or create a control module and add one DI and one DO blocks. Assign these blocks to FPAC's DI\_1 and DO\_1 respectively. If desired, add more blocks and create links.

# FIGURE 52

UBasic Device Configuration - FPAC2	UBasic Device Configuration - FPAC2
You selected Two Valves. Are they connected to: 1. Two single action valves 2. One Single Action (local) and other (aux) monitoring only 3. One monitoring only (local) and other (aux) Single Action 4. One Double Action (local) and other (aux) monitoring only 5. One monitoring only (local) and other (aux) Double Action (WCDN018) C 1 C 2 (* [3] C 4 C 5 C Abort Back	Rotary or linear? Dhoose: 2 Rotary or 2 Linear or Rotary[local] and Linear[aux] or Linear[local] and Rotary[aux] Local is the FPAC / Intellis device mounted on top of the actuator using the internal sensors./n Dbs: It is rate to have a Linear actuator directly mounted with the FPAC (w/CDN016) C 2 Rotary C 2 Linear C [Rot and Lin] C Lin and Rot C Back
Next > Cancel Help	Next> Cancel Help

Is the device configured for to closel?	direct action (increase to open	) or reverse action (in	crease
Obs.: Not applicable for the (WCON017) @ 2 Direct	monitoring-only device(s)		
C 2 Reverse C Dir and Rev C Rev and Dir			
C Abort C Back			
	Next>	Cancel He	lo I

- 14. Click on the DI block (valve 1) and make sure that Mode = Auto, and Channel = 9 -TRD1: 0-Close / 1-Open. See Figure 54.
- 15. Click on the D0 block (valve 2) and make sure that Mode = Auto, I0\_0PTS = Use PV for BKCAL\_0UT and Channel = 21 - TRD2: 0-Close / 1-0pen. See Figure 55.
- 16. Download the control module configuration to the fieldbus network.
- 17. When the download finishes, open the control module on-line. Move the valve 1 and verify the position is indicated by the DI block. Observe the valve position feedback will show '0' for valve closed, '1' for valve opened, '2' for valve stopped, '3' for valve opening and '4' for valve closing. The OPEN and CLSD LEDs on the module will indicate the position accordingly.

1 3	Part () has TO U TO U	Properties Allow user-entered value Value:
Personal Land a res_us_b c along dr. res_us_b c res_us_b c res_us c res_us_b c res_		9 - TRD1: 0-Closed /1-Opened

Allow user-entered value	Value: Value PV for BKCAL_OUT Top to Man if Fault St Ast Use Fault st val on restart
21 - TRD2: 0-Close /1-Open	Fault State to vaue     SP.PV Track in L0 or IMan     SP.PV Track in Mon     Invert

18. Change the parameter linked to the DO\_1. CAS\_IN\_D to cause valve 2 to move. Observe the valve position feedback will show '0' for valve closed, '1' for valve opened, '2' for valve stopped, '3' for valve opening and '4' for valve closing. The AUX1, AUX2 and OUT1 LEDs on the module will light accordingly. See below the screenshots of the control module. See Figure 55.



4.2.9 Configuration for example #6: one valve, rotary, simple solenoid, potentiometer This example assumes the device is at the factory default state. This example also assumes the optional potentiometer is installed. Therefore, instead of using the internal Hall Effect limit switches to read the shaft position, the FPAC utilizes the potentiometer assembly connected to the analog output (J5) to deliver 0-100% position indication besides discrete CLOSED and OPENED. It assumes it is wired as illustrated in the previous section "Wiring for Example #6". Two variants of the example will be shown:

A. Monitoring the valve with the AI block and one DI block. This example assumes the valve is controlled by some other means (manual valve or controlled by a separate PLC/DCS):

Blocks and parameters that need configuration					
Resource	TB1	DI_1	AI		
MODE_BLK = AUTO	IO_OPTION = 9: Analog,Out0	MODE_BLK = AUTO	MODE_BLK = AUTO		
	MODE BLK = AUTO				

B. The second variant of the example assumes the FPAC is controlling the valve with a D0 block and the position feedback is given by the D0 block using the BKCAL\_OUT\_D parameter and the AI block:

Blocks and parameter	s that need configuration		
Resource	TB1	D0_1	AI
MODE_BLK = AUTO	IO_OPTION = 9: Analog,Out0	MODE_BLK = CAS+AUTO*	MODE_BLK = AUTO
	MODE_BLK = AUTO		
* [++			

\* For testing purposes mode can be set to AUTO or MAN.

4.2.9.1 Valve monitoring using DI and AI blocks: position transmitter

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- 2. Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- 3. Right-click on the device you want to configure and chose Configure/Setup. See Figure 56.



- 4. The Device Identification window will appear after a few seconds. Click on Transducer Basic Setup and wait a few seconds until all parameters are read.
  6. On the menu tree, select Function Block Utils, then click on Block Modes and fina select the tab Block Mode-Std Transducer In the Std TRD 1 Target Mode group, select
- 5. In the Std Transducer 1 parameters group, click on the parameter ACTION\_ELEMENT drop box and select the option Monitoring. Click on the IO\_ASSIGNMENT parameter and select Analog,Out0. Click on Apply, and then on the screen that opens click on Yes. See Figure 57.
- 6. On the menu tree, select Function Block Utils, then click on Block Modes and finally select the tab Block Mode-Std Transducer. In the Std TRD 1 Target Mode group, select the target mode to Automatic. Make sure to uncheck the Out of Service option. Click on Apply to write the configuration. See Figure 58.





- After a few seconds, confirm the transducer block changed the mode to Automatic by observing the parameters in the left side of the window, group Std TRD 1 Actual Mode. See Figure 59.
- 8. Close Configure/Setup window.

**Note:** although possible, it is not recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section. 4.2.9.2 Valve control using DO and AI blocks: position transmitter

- This example assumes the device has been commissioned and is at the factory default configuration. See Appendix B for factory default procedure and Appendix D for complete list of block parameters including default values.
- Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.
- Right-click on the device you want to configure and chose Configure/Setup: See Figure 60.

#### FIGURE 59

Theorem Beau Branch Bra	s. 5]	
He Activit UND		
a C 🕺		
Configure/Setup	#1 Eleck Mode Resource 41 Block Mode Ski Tra	uducer   +1 Block Mode Drag Translucer
Configuration     Configuration     Configuration     For Device Stands     For Device Stands     For Streadser Ease     Societation     Societation     For Standser Ease	Stil TFO 11 Super Mude Target Mude Target Mude Target Mude T RCar dandt C RCar dandt C Car D Automatic ETHOR C Manuel C Manuel C Manuel	Sul TRD 1 Actual Mode Actual Hold F ROW F RCm F Cm F Actually F Name F Name F 10
		E Man
G Curfique Selas		E Dut of Service



- The Device Identification window will appear after a few seconds. Click on Transducer Basic Setup and wait a few seconds until all parameters are read.
- In the Std Transducer 1 parameters group, click on the parameter ACTION\_ELEMENT drop box and select the option Single Action. Click on the IO\_ASSIGNMENT parameter and select Analog,Out0. Click on Apply, and then on the screen that opens click on Yes.
- On the menu tree, select Function Block Utils, then click on Block Modes and finally select the tab Block Mode-Std Transducer. In the Std TRD 1 Target Mode group, select the target mode to Automatic. Make sure to uncheck the Out of Service option. Click on Apply to write the configuration. See Figure 61.
- After a few seconds, confirm the transducer block changed the mode to Automatic by observing the parameters in the left side of the window, group Std TRD 1 Actual Mode. See Figure 62.
- 8. Close Configure/Setup window.

**Note:** although possible, it is not recommended to use AMS for function block (DI, DO, AI) channel configuration once this configuration is not saved in the persistent database. Use DeltaV explorer or Control Studio for function blocks configuration as illustrated in the next section.

# FIGURE 61



FIPAC2 [FPAC Rev. 5] File Actions Help		لم
<u>e</u>		
Configure/Setup  Config	Block HodeResnuce 41 Block ModeShit Tue     Skit TRD 1 Taget Mode     Taget Mode     Taget Mode     Roa     Roa     Roa     Cas     Roa     Out of Service	Advant 41 Block Mode Diag Tunuduor   Skil TRD 1 Adval Mode Adval Mode E R0ut E R0ut E Ros E Automatic E Manual E L0 E Manual
Configure/Setup		C Out of Service

# 4.3 Configuration and operation with a FF handheld or FF bench host

The step-by-step example below illustrates an application where the FPAC is controlling 2 (two) single action valves using a FF Handheld or FF Bench Host. You can adapt the example to your application. If you are using FPAC to control or monitor one valve, just ignore the steps related to valve 2.

For more information on how to install the files see an example on Appendix G. Contact Westlock in case of any problem.

It is shown how to configure the blocks, actuate on the outputs and monitor the limit switches. In order to configure the FPAC for this application, a DD method (wizard) will be used. The simplified menu tree to access the method "Basic Device Config" is shown below (see Appendix H for the complete menu tree). See Figure 63. **Note:** Make sure the handheld or bench host has the necessary support files installed (DD/ CF). Contact Westlock in case you need help with the support files. See Technical Note TN-2014-003 "How to install Intellis 7300 (FPAC) support files into 475-375 handheld".

 Before you start, make sure the FPAC is properly powered with a suitable FF power supply and the proper impedance and bus terminators are in place. As soon as the FPAC is energized all LEDs will blink once. Notice that outputs may change during the configuration steps. Make sure your setup is safe if outputs change state.

FIGURE 63

DD menu tree to access basic configuration method



- 2. From the Handheld Main Menu select Foundation Fieldbus Application. Up and Down arrow keys scroll through the icon rows; the Right and Left arrow keys scroll through the icon columns; Enter key selects the highlighted item or press the icon on the touch screen. See Figure 64.
- 3. From the Fieldbus Application Main Menu highlight Online then press the Right Arrow key. If this is not on an active Fieldbus Segment (communicating with a Fieldbus Host or LinkActiveScheduler) then a Warning message will appear saying: "Connection Warning: No Fieldbus communication detected. Press OK to connect to this segment anyway. Press CANCEL to go to the Fieldbus Application Main Menu". Press OK to start communication. A warning message "Fieldbus Library System Management Error. SMERROR: FAILED RESPONDER IDENTIFY" may also appear. Press OK to continue.
- 4. After the handheld finds all the devices on the Fieldbus network select the FPAC. The FPAC BUS LED should start blinking at a rate around 1 Hz. If the FPAC2 does not appear then hit the Left arrow key, hit OK then continue as in step 3. Otherwise, highlight the FPAC and press the Right Arrow key. See Figure 65.
- 5. Scroll down to Device Root Menu and select it by hitting the Right arrow key. The warning "This device description may not have been tested with this version of Fieldbus Application. Do you want to proceed with this device anyway?" may appear, hit YES and continue. See Figure 66.



FIGURE 65





- Highlight Basic Setup then press the Right arrow key. Highlight Device Identification then press the Right arrow key. See Figure 67.
- 7. Wait for the entire screen to update then scroll down with the Down arrow key until you find the option "Basic Device Configuration" and then press the Right arrow key. See Figure 68.
- 8. Press NEXT twice to continue, then make sure the "Continue" option is selected. Press NEXT again to continue. See Figure 69.



#### FIGURE 68





- 9. The display will show a sequence of messages, for a few seconds. When the last message "Transducer Blocks are in OOS (WCON005)" appears press NEXT to continue. See Figure 70.
- 10. Now you are going to choose the configuration you will be using in a sequence of questions and options. This example will control 2 (two) single action rotary valves. You can adapt the example to match your application. Make sure the appropriate choice is selected (for this example choose "2 (two)") then press NEXT to continue
  - a. Valve 1 uses the cam magnets on the shaft to activate the FPAC internal Hall Effect limit switches and OUTO to power the solenoid-
  - b. Valve 2 uses the auxiliary inputs AUX1 and AUX2 as open/close limit switches and OUT1 to power the solenoid. See Figure 71.
- 11. In this example FPAC inputs are used as Open/Close limit switches and FPAC outputs are used to control the actuator, then select "Monit Control". If you are using FPAC just to monitor the valve(s) position, then select "Monit Only", then press NEXT to continue. See Figure 72.

- 12. Since both valves are Single action in this example, choose option "1" then press NEXT.
  - a. Depending on your application you may choose an option to control one of the valves and just monitor the other one, or even to monitor both.
  - b. The DD method always associated valve 1 with transducer block TB1 and channels starting with "TRD1..."
  - c. The DD method always associated valve 2 with transducer block TB2 and channels starting with "TRD2...' See Figure 73.
- 13. In this example the two valves are rotary. thus choose option "2 Rotary" then press NEXT. This option is just information and does not change any functionality in the device. See Figure 74.

WCON005)

# FIGURE 71



# FIGURE 72



NEXT

# FIGURE 73





- 14. The display will show the following items (for a few seconds). See Figure 75.
- 15. Then the following screen will appear. Select the desired configuration: "Direct" action or "Reverse" action. In this example both valves are "Direct". Press NEXT to continue.
  - a. Direct: when set-point = '1' = OPEN (on transducer or DO) it activates the FPAC output, powers the solenoid and supply air forces the actuator to the Opened position. This is often referred as a fail closed valve as in the absence of power the pneumatics will force the valve to the closed position.
  - b. Reverse: when the set-point = 1' = OPEN(on transducer or DO) it deactivates the FPAC output removing power from the solenoid, but supply air and pneumatics setup still forces the actuator to the Opened position. This is often referred as a fail opened valve as in the absence of power the pneumatics will force the valve to the opened position.

See Figure 76.

- 16. The display will show a sequence of messages, about 2 seconds each, while the method is configuring TB1 and TB2 transducer block parameters. Notice that outputs may change at this point. Make sure your setup is safe if outputs change state. Finally when the message "Configuration finished. Returning Transducer to Auto... (WCON020)" appears and the NEXT changes to FINISH, press FINISH to continue. See Figure 77.
- 17. The menu returns to the Device Identification screen. Press the Left arrow key to go up one level. Press button MODE to check the FPAC Block modes of operation. See Figure 78.



- 18. The Resource Block should be in Auto. If this is already in Auto then hit CANCEL and skip to step 24. If it is not in Auto then perform the next steps. See Figure 79.
- 19. Hit the Down arrow key to select the Resource Block then press OK. See Figure 80.
- 20. Select Auto (box checked) and make sure OOS is not selected (box is not checked). The item is toggled from selected to not selected by touching the box on the handheld LCD screen. Then press OK button. See Figure 81.
- 21. A warning about Mode change affecting the process appears. Press YES to continue and wait a few seconds. See Figure 82.
- 22. After the Mode changes the screen returns to Basic Setup menu. Press MODE to check the block modes again. Now that the Resource Block has changed to Auto, click OK. See Figure 83.
- 23.Once the Resource Block is in Auto press the Left arrow button twice to return to the top level menu.

Select Block to	r Mode Change	0	150
Block Tag	Block Type	Actual Mode	-
ResourceBlo	RES BLOC	Auto	
TB3-DIAG-V	Custom	005	
TB4-DIAG-V	Custom	005	
DI 1	DI	005	
DI 2	DI	005	
DI. 3	DI	005	

#### FIGURE 80

Select Block fo	ar Mode Chang	le
Block Tag	Block Type	Actual Mode
ResourceBlo	RES_BLOC	005
TB3 DIAG V	Custom	005 -
TB4 DIAG V	Custom	005
DI_1	DI	005
DI 2	DI	005
DI, 3	n	0.05
		ITTERSTORE INC.

# FIGURE 81



# FIGURE 82





← LAS FPAC_0501_DM FPAC_0 1-Basic Setup	6IFF2_0000
Label	Value
1.1 Device Identification 1.2 Transducer Basic Setup 1.3 Resource Block Setup	
4	
HELP MODE	

Block Tag	Block Type	Actual Mode	
ResourceBlo	RES BLOC	Auto	
TB3-DIAG-V	Custom	005	-
TB4-DIAG-V	Custom	005	
DI 1	DI	005	
DI 2	DI	005	ä
01,3	ni	005	

- 24. Now it is necessary to schedule function blocks execution. Press the Down arrow to highlight Advanced, and then press the Right arrow button to select it. See Figure 84.
- 25. Scroll down to highlight Schedule and then press the Right arrow button to select it. See Figure 85.
- 26. A warning appears to inform you that, if the device is already commissioned (has blocks scheduled), and is being used in a host system, it cannot not be commissioned by the handheld. Hit YES to allow the handheld to schedule blocks. See Figure 86.

de

四

- 27. With the Down arrow button scroll down to DO\_1 and DO\_2 blocks and select the on screen check box. Then press OK. A message informing that the block schedule was changed appears. Press OK to continue. See Figure 87.
- 28. Scroll down to Block List and then press the Right Arrow button to select it. See Figure 88.
- 29. The next steps are to set DO\_1 and DO\_2 channels and need to be repeated for each block. Scroll down to Block List and then press the Right arrow button to select DO 1. See Figure 89.

# FIGURE 84 +

LAS

**Device Root Menu** 

**Diagnostics Root Menu** 

FPAC 0501 DM FPAC 05

WTVC Device Revision 5

**Process Variables Root Menu** 

# FIGURE 85



# FIGURE 86

Advance

HELP



# FIGURE 87





## FIGURE 88



Block Tag	Block Type	Actual M
DI 6	DI	005
00_1	DO	Auto
00 2	DO	005
00 3	DO	005
00 4	DO	005

TTYC Devi	ce Revision 5	
Block Tag	Block Type	Actual Mode
DI_6	DI	005
DO_1	DO	Auto
DO 2	DO	IMan
DO_3	DO	005
DO_4	DO	005

- Highlight I/O References and then press the Right arrow button to select it. See Figure 90.
- 31. Channel is highlighted; then press the Right arrow button to select it. See Figure 91.
- 32. From the drop-down of DO\_1 menu choose "TRD1:0-Close /1-Open", then press OK twice. There is a similar option for DO\_2 but you should use transducer TB2, then choose "TRD2:0-Close /1-Open". See Figure 92.

PAC_0501_DM	FPAC_05_I	FF2_000
Label	Value	-
Ouick Config Common Config Advanced Config		
1/O References		
Connectors		-
1		
HELP MOI	DE	

← LAS	F	×
PAC_0501_DM	FPAC_05IFF2	_0000
JO_2	CONTRACTOR DESCRIPTION OF THE OWNER	
Label	Value	-
Quick Config		100
Common Config		100
Advanced Config		1 127-
I/O References		
Connectors		-
4		
HELP MODE		

FIGURE 91



LAS PAC_0501_DI 0_2 I/O Refer	FPAC_05_ rences	IFF2_000
Label	Value	
Channel	No Transd	ucer Conn
Channel	No Transd	ucer Conn
	nor I	



- 33. Press MODE to put both DO\_1 and DO\_2 blocks in Out Of Service (so that the Channel can be sent to the block). See Figure 93.
- 34. Select OOS (box checked), make sure Auto is not selected (box is not checked). The item is toggled from selected to not selected by touching the box on the handheld LCD screen. Then press the OK button. See Figure 94.
- 35. A warning about Mode change affecting the process appears. Notice that outputs may change at this point. Make sure your setup is safe if outputs change state. Press YES to continue. See Figure 95.
- 36. Now that the blocks are Out Of Service press SEND to change the Channel. See Figure 96.

Label Value  Channel TRD1: 0-Close / 1  Label Value  Channel TRD2: 0-Close / 1				***********************************
*Channel TRD1: 0-Close / 1	Label	Value	Label	Value

FIGURE 96

FIGURE 94



lock Mode Targe	et .	
RCas		
Cas		
Auto		
Man		
005		






- 37. Press the Left arrow key to go to the previous menu. Highlight Quick Config and then press the Right arrow button to select it. Repeat this for both D0\_1 and D0\_2. See Figure 97.
- 38. At this point the OUT0 and OUT1 LEDs should be OFF. Scroll down to "Setpoint Discrete Value" and then press the Right arrow button to select it. See Figure 98.
- 39. From the drop-down list choose '1' (or use the Up arrow or Down arrow to scroll through the list of values) and then press OK. See Figure 99.

### FIGURE 97

FPAC_0501_D	M FPAC_05_IFF2_00	×
Label	Value	
Quick Config		
Common Config Advanced Confi I/O References Connectors	9	
HELP	ODE	

← L PAC_050 DO_2	AS (FPAC	05IFF	2_000
Label	Val	ue	
Ouick Confi Common C Advanced ( I/O Referen Connectors	g onfig Config ces		
HELP	MODE		

### FIGURE 98

Label	Value
Alert Key	0
Process Value Discr	Good NonCascade:
Process Value Discr	4
Setpoint Discrete St	Good Cascade::Non

Label	Value
Alert Key	0
Process Value Discr	Good NonCascade:
Process Value Discr	0
Setpoint Discrete St	Good_Cascade::Non
Setpoint Discrete Va	0

-



	A-EPAC O		
DO_2		JIFF2	
*Setpoint Discrete	Value		
1			
urin 1	CAN		01
HELP	CAN	EL .	OK

- 40. The asterisk before the set-point Discrete Value means that a change has been made but has not yet been sent to the FPAC. Press SEND to make the new value effective in the output. See Figure 100.
- 41. If you write '1' to the DO\_1 set point the OUT0 LED should be ON (or flashing if no solenoid is connected) and the OUT1 LED should be OFF. If the FPAC is mounted on an actuator, pneumatics and wiring are properly set, the actuator should move to the OPENED position. This would be a good time to set the magnet on the cam for the top limit switch by observing the OPEN LED.
- 42. If you write '0' to the DO\_1 set point the OUT0 LED should be OFF and the OUT1 LED should be OFF. If the FPAC is mounted on an actuator, pneumatics and wiring are properly set, the actuator should move to the CLOSED position. This would be a good time to set the magnet on the cam for the bottom limit switch by observing the CLSD LED.
- 43. Repeat the previous steps for the DO\_2 block, observing the OUT1 will change state. Make sure both limit switches connected to AUX1 and AUX2 are also properly adjusted for opened and closed positions by observing AUX1 and AUX2 LEDs.
- 44. Press the Left arrow button 4 times to return to the top level menu. Press the Up arrow to highlight Process Variables Root Menu, and then press the Right arrow button to select it. See Figure 101.
- 45. Highlight option "1- Discrete Position and Status" and then press the Right arrow button to select it. Highlight the "Final Position Value" and then press the Right Arrow button to select it. See Figure 102.

FIGURE 100

	Value
rt Key	0
cess Value Discr	Good NonCascade:
cess Value Discr	4
point Discrete St	Good_Cascade::Non

	ck Conng	Concession of the second second	
Label		Value	
Alert Key		0	
Process Va	lue Discr	Good NonCascade:	
Process Va	lue Discr	0	
Setpoint D	iscrete St	Good Cascade::Non	
"Setpoint I	Discrete V	1	
HELP	MODE		

### FIGURE 101







- 46. Put a magnet near the CLOSED Hall sensor limit switch (bottom), the CLSD LED should light. After a few seconds the Std Transducer 1 Final Position Value should change to '0'. Put the magnet near the OPENED Hall sensor limit switch (top), the OPEN LED should light. After a few seconds the Std Transducer 1 Final Position Value should change to '1'. See Figure 103.
- 47. Now short out AUX1, the AUX1 LED should light. After a few seconds the Std Transducer 2 Final Position Value should change to '0'. Short out AUX2, the AUX2 LED should light. After a few seconds the Std Transducer 2 Final Position Value should change to '1'. See Figure 104.
- 48. Press the Left Arrow button three times to return to the top level menu. See Figure 105.

### FIGURE 103





### FIGURE 104

o_z draick coming	Contraction of the Contraction o
Label	Value
Alert Key	0
Process Value Discr	Good NonCascade:
Process Value Discr	0
Setpoint Discrete St	Good Cascade::Non
Setpoint Discrete Va	0



FPAC_0501_DM FPAC_05 WTVC Device Revision 6	IFF2_0000
Process Variables Root Menu Device Root Menu Diagnostics Root Menu Advanced	
HELP	

### **5 FIELD WIRING**

### 5.1.1 Wiring examples

This section details the various wiring options available with the FPAC-2. Refer to the wiring diagram supplied with the unit for specific details. Among the many possible applications with the Intellis 7300, the following table manual presents some examples:

Example #	Number of valves*	TB1/TB2	Type (Valve1/ Valve2)	SOV (number of coil/piezo)	Comments
1A, 1B, 1C	One	Control / Not used	Rotary	One	Typical installation for the 7344 model.
2		Control / not used		Two	One SOV with 2 piezos on the same housing (LZ2 housing).
3A, 3B	One	Control / Not used	Linear	One	Using Silver Bullet/Magnum for the linear actuator.
4	Two	Control / control	Rotary/Rotary	One	Using 764 for the second valve (second housing has only switches and SOV).
5	Two	Control / monitor	Rotary/Linear	Two	Using dual coil/piezo solenoid for the local valve; Silver Bullet/ Magnum to monitor position of the remote linear valve.
6A, 6B	One	Control	Rotary	One	Using potentiometer connected to analog input J5 instead of cam shaft magnets.

\* FPAC can control or monitor up to two valves. SOV = Solenoid valve.

**Note:** If in your application the valve is not controlled by the FPAC, then just ignore the electrical connections to the solenoid(s). In this case FPAC should be configured as "Monitoring" as explained in the "Configuration" section.

5.1.2 Wiring for example #1: one valve, rotary, with a simple solenoid This example can be used for monitoring only applications as well as for control of one valve. One FPAC output is necessary to power the solenoid.

FIGURE 106

Wiring diagram for example #1

Example #1A: one valve, rotary, just monitoring



**Note:** cams, limit switches and potentiometer are factory set. If for some reason you need to adjust them see Appendix A for more details.

Note: for a configuration example see section "Configuration for example #1".

Examples #1B and #1C: one valve, rotary, with a simple solenoid

5.1.3 Wiring for example #2: one valve, rotary, dual coil/piezo solenoid

This example shows a solenoid that has two coils/piezos, each one to move the valve in one direction. There is no spring in the solenoid valve, therefore both outputs OUT0 and OUT1 are used.

### FIGURE 107 Wiring diagram for example #2

Example #2: one valve, rotary, dual coil/piezo solenoid



Note: cams, limit switches and potentiometer are factory set. If for some reason you need to adjust them. See Appendix A for more details.

Note: for a configuration example see section "Configuration for example #2".

5.1.4 Wiring for example #3: one valve, linear, with simple solenoid This is for the case where the valve is linear and uses two external sensors connected to AUX1 and AUX2.

### FIGURE 108 Wiring diagram for example #3

Example #3: one valve, linear, just monitoring Example #3: one valve, linear, simple solenoid 0) 0) - Low power 00 ଡ 10 DITUO COTIO COUN CT OUT1 > 3 meters (10 feet DITUD OUTO OUTO OUTO 000 000 + coil/piezo 00 DRY CONTACT CLOSED LIMIT SWITCH DRY CONTACT CLOSED LIMIT 00 eters (10 feet) ٠ OO AUX2 AUX2 SWITCH 00 00 > 3 meters (10 00 DRY CONTACT OPENED LIMIT 00 DRY CONTACT AUX1 AUX1 00+ 00 OPENED LIMIT 3 meters (10 fee 3 mete SWITCH SWITCH Q Q bééééé Order option without shaft dédédé, Order option without shaft with flat cover DND with flat cover 000 000 Fieldbus A Fieldbus A Protective GROUND Protective GROUND 0 D (do not connect (do not connect Fieldbus B Fieldbus B 6 0 cable's shield) cable's shield) m m

**Note:** cams, switches and potentiometer are factory set. If for some reason you need to adjust them see Appendix A.

Note: for a configuration example see section "Configuration for example #3".

5.1.5 Wiring for example #4: two rotary valves, direct and reverse action

In this example FPAC is used to control two valves, one rotary and another rotary or linear. The FPAC housing is installed on top of the "valve 1, local", while an auxiliary housing just containing switches and the solenoid valve is installed on top of the "valve 2, remote".

### FIGURE 109 Wiring diagram for example #4

Example #4: two valves, rotary and rotary/linear, direct and reverse



**Note:** cams, switches and potentiometer are factory set. If for some reason you need to adjust them see Appendix A.

Note: for a configuration example see section "Configuration for example #4".

5.1.6 Wiring for example #5: two valves, rotary/linear, monitoring/control

This is for the case where one FPAC will be used to control one valve and to monitor another one, the two valves being one rotary and another rotary or linear. The FPAC housing is installed on top of the "valve 1, local", while an auxiliary housing just containing switches and the solenoid valve is installed on top of the "valve 2, remote". The valve 2 solenoid is powered and controlled by other means, like a PLC/DCS DO output.



**Note:** cams, switches and potentiometer are factory set. If for some reason you need to adjust them see Appendix A.

Note: for a configuration example see section "Configuration for example #5".

5.1.7 Wiring for example #6: one valve, rotary, simple solenoid, potentiometer option

This example assumes the optional potentiometer is installed and there are no cams or additional switches on the shaft. Therefore, instead of using the internal Hall Effect limit switches to read the shaft position, the FPAC utilizes the potentiometer assembly connected to the analog output. The potentiometer has to be calibrated accordingly before it can be used to monitor position.

### FIGURE 111 Wiring diagram for example #6

Example #6: one valve, rotary, potentiometer, simple solenoid



**Note:** cams, limit switches and potentiometer are factory set. If for some reason you need to adjust them see Appendix A for more details. If your application is for valve monitoring and the valve position is not controlled by the FPAC just ignore the solenoid connections. **Note:** when ACTION\_ELEMENT parameter in the transducer block is configured to use the analog option the OPEN and CLSD LEDs will no longer respond to the internal Hall Effect sensors, but to the potentiometer position after proper calibration.

### **6 MAINTENANCE AND REPAIR**

### 6.1 Troubleshooting

This chapter addresses the most common installation, configuration, and operation problems. It also introduces diagnostic parameters and procedures that help solve these problems.

## 6.2 FPAC does not turn on, LEDs do not light when powered up

- Check voltage at connector J2 pins 1 and 3. It should be between 9V and 32V, otherwise there may be a problem with the power supply, barrier, protections, bus terminators or cabling.
- Disconnect the bus cable from connector J2. Using an Ohmmeter check the resistance between pins 1 and 3 of the bus connector J2. If the resistance is higher than 100 kOhms the internal fuse may be blown. Contact Westlock technical support.

## 6.3 Where do I find device revision and firmware version?

- 1. Check the label attached to the module. It should indicate the device version.
- If you cannot access the device's label, you can use your FF Host system to open the device's Resource Block and look up the parameters listed below:
  - a. MANUFAC\_ID: manufacturer identification number, example "WESTLOCK" or "WTVC" or "0x574343".
  - b. DEV\_TYPE: device identification number, example "0x0001".
  - c. DEV\_REV: device revision, e.g., "0x05".
  - d. DD\_REV: version of the DD that needs to be used for this device, e.g., "0x01".
  - e. ITK\_VER: major version number of the ITK this device is registered, example "0x06".
  - f. REVISION\_ID: version of the firmware installed in the device, example "FPACRev1.0.0".
  - g. REVISION\_DATE: date of the firmware installed in the device, example "01 Feb 2014".

### 6.4 Which DD version should I use?

 First of all, confirm the device revision of your FPAC: it should be between 2 and 5. Then you are going to need DD files for the same device revision. For example, FPAC with device revision 4 needs DD 0401; FPAC device revision 5 needs DD 0501 and so forth. All registered DD files can be downloaded from www.fieldburs.org. Contact Westlock if you have any problem getting the DD.

### 6.5 How do I perform a factory default?

- Use dip switch #3 or Resource Block RESTART parameter. See Appendix B for more details.
- IMPORTANT: the factory default MUST be performed with the device connected to an active bus with proper voltage levels, impedance, and communication. The factory default will not work if the device is connected to a simple DC power supply.

### 6.6 FPAC2 lost configuration after some time

 After downloading a new configuration or after performing a factory default the data is stored in a volatile RAM memory. It takes some time to save the data to the non-volatile memory through a low priority task in the real time operating system of the device. Therefore the device must not be powered off before enough time has elapsed. Usually all configuration is saved after 10 minutes.

### 6.7 The device is not communicating or the Host communication statistics is showing errors

- 1. Some installation problems can cause communication malfunctions and errors:
  - a. Check for loose wires, wire strands, and bad contact on all connectors. Make sure all wires and connectors are firmly attached and all screws are tight. It has been seen in many installations that a bad contact can cause intermittent malfunctions that will not prevent the bus from working but will degraded communication and reduce the performance due to sporadic errors, like DLL retries, Token Pass Time Outs (TPTO's), Missed View List Scan, Live List appearances and so forth.
  - b. Check bus terminators, make sure there are only 2 (two) terminators enabled in the bus segment. It is common that power conditioners, junction boxes, barriers, repeaters have embedded terminators. Make sure they are configured in way that only two bus terminators are enabled at a time on the same segment.
  - c. Check cabling for shield strands making intermittent shorts in connectors; check for wire splices and junction boxes.
  - d. Check bus voltage at the device's terminals and make sure it is in the range 9 VDC to 32 VDC.

## 6.8 Blocks' tags on my application are different from the references on this manual

 In a real application the blocks' tags are going to be different from the default tags referenced in this manual. Check the table below to find out the object directory index of each block and then identify the block in your application.

Default block tag	VFD Index
RB	407
TB1-STD-VALVE1	482
TB2-STD-VALVE2	554
TB3-DIAG-VALVE1	626
TB4-DIAG-VALVE2	694
DI_1	762
DI_2	791
DI_3	820
Default block tag	VFD Index
DI_4	849
DI_5	878
DI_6	907
D0_1	936
D0 2	967
-	
 D0_3	998
D0_3 D0_4	998 1029

- See below an example of properties window of a FF Host where one can correlate the block tag with the physical block in the device.
  - a. FFDI3 in the application is the same as DI\_2 in the physical device (block index 791).
  - b. FFD01 in the application is the same as D0\_1 in the physical device (block index 936).

See Figure 112.

### FIGURE 112

### FIGURE 113

? X

#### type: Fieldbus Function Block OK 30 Jan 2014 11:06:40 AM Cancel Modified by: Smar 121 Description Discrete Input WESTLOCK Module that uses this block CONTROL-MONIT2 Execution time: 30 ms Object table index 791 ? X FDO1 Propert ect type: Fieldbus Function Block OK 30 Jan 2014 11:06:40 AM fied Cancel 2 Modified by 10 Č.m Description CINCLE CON Discrete Output CONTROL-MONIT2 Module that uses this block: Execution time: 30 ms Object table index 936 a. 41. V. - 10

### 6.9 Some parameters are showing "Error: Dictionary String Not Found"

- FPAC DD has been developed to meet the latest FF specification. If some parameters or enumerations are showing a message, like "Error: Dictionary String Not Found" there is a chance the FF Standard Dictionary installed in your FF Host is outdated. FPAC was tested with FF Standard Dictionary version 3.8. Contact your FF Host supplier to ask for more information on how to update the FF Standard Dictionary.
- 2. There is method in the DD for checking the version of the dictionary installed in your system. It can be accessed from the Device Identification menu. See Figure 113.

## 6.10 Transducer MODE\_BLK does not go to AUTO

- Check that parameters ACTION\_ELEMENT and IO\_ASSIGNMENT are properly configured.
- In applications where both TB1 and TB2 are configured with ACTION\_ELEMENT as Single Action, SET\_CURRENT\_SINK parameter must be set to "2: Current Level 2" AND dip switch #6 must be ON.

### 6.11 Transducer MODE\_BLK = AUTO but BLOCK\_ERR = BlockConfiguration

- If the transducer is configured to control the valve (ACTION\_ELEMENT = Single Action or Double Action) it is required to have a DO block feeding this transducer. Configure one DO block with a channel that belongs to this transducer and make sure DO mode is CAS+AUTO (AUTO or MAN only for testing purposes or manual control).
- 2. If more than one D0 is configured to use the same channel of a transducer (TB1 or TB2), that transducer block will indicate a block error and keep the outputs frozen until the channels are fixed even though the mode transitions to AUTO. Make sure D0 blocks in the same device use different channels and leave only one (1) D0 configured with a given channel. If after the reconfiguration of the D0 channels the block error still persists power cycle the device and recheck.

## 6.12 Can't write to ACTION\_ELEMENT parameter

- 1. Write ACTION\_ELEMENT = 0: "No selection" on both transducers and reconfigure.
- Make sure the configuration is consistent for both transducers, for example, if one transducer is configured for "Double Action", the other can only be configured for "Monitoring" or leave unused. See section "Standard Transducer block overview" for more information.
- Dipswitch #6 = ON and TBX.SET\_CURRENT\_ SINK = Current Level 2 only when TB1 AND TB2 are configured for Single Action. For all the other combinations the dipswitch #6 = OFF and TBX.SET\_CURRENT\_SINK = Current Level 1. Use parameter MODULE\_ IO\_SUMMARY from the Diagnostics transducer block to read the switch status.

## 6.13 Can't write to IO\_ASSIGNMENT parameter

 Make sure TB1 and TB2 are not using the same physical I/O. See section "Standard Transducer block overview" for more information.

## 6.14 The valve does not go to FAIL position when FPAC is powered off

- When device is powered off pneumatics and actuator assembly are responsible for moving the valve to the fail position. Check air supply, pneumatics assembly, solenoid valve, and actuator.
- There are applications where the valve is controlled by another discrete output, not the FPAC. In this case, check if the discrete output that controls the valve position.

## 6.15 The valve does not go to FAIL position when communication is lost

- If FPAC is controlling the valve, it is responsible to command the solenoid in a way that the pneumatic assembly moves the valve to the fail position when communication is lost. Check transducer block configuration, in special the following parameters:
  - a. PSNR\_FSTATE\_OPT: whenever the transducer block enters into a fault state (commanded by a DO block) the device will control the valve according to what is defined in this parameter.
  - b. PSNR\_00S\_0PT: whenever the transducer block enters into 0ut of Service (00S) mode the device will control the valve according to what is defined in this parameter.
  - c. PSNR\_FSTATE\_VAL\_D: if this parameter was chosen in any of the two previous parameters the state assumed by any of the physical outputs will match the value configured in this parameter.
- 2. Check DO configuration, in special the following parameters:
  - a. IO\_OPTS: if IO\_OPTS is '0', the value will hold the current value (freeze) if a fault is detected. If IO\_OPTS is '1', the output will go to the preset FSTATE\_VAL\_D value, if a fault is detected.
  - b. STATUS\_OPTS: options which the user may select in the block processing of status.
  - c. FSTATE \_TIME: the time, in seconds, from detection of failure of the output block remote set-point to the output action of the block output if the condition still exists.
  - d. FSTATE\_VAL\_D: the preset discrete SP\_D value to use when failure occurs. This value will be used if IO\_OPTS = "Fault State to value" is selected. The possible values are: 0: Close, 1: Open and 2: Stop.

## 6.16 The valve does not STOP at last position when communication is lost

- Fail last applications depend on the pneumatic assembly to keep the air trapped in the actuator in the event of a failure. Check the pneumatic assembly, leakages, tubing etc.
- When FPAC is controlling the valve, it also depends on the solenoid valve assembly and transducer block configuration. Fail last is typically implemented when FPAC is controlling 2 (two) coils/piezos. In the event of a failure FPAC will de-energize both coils causing the actuator to hold the valve in the current position. Check transducer block ACTION\_ELEMENT parameter that should be "Double Action".

## 6.17 FPAC is not communicating with the FF Host

- When there is regular communication the BUS LED blinks at a rate around 1 Hz. It means the device has an address in the range 0x10 to 0xF7, is receiving token pass and should be present in the Host live list and ready to use/commission.
  - a. BUS LED is on: FPAC detected valid communication on the bus but its address is in the range 0xF8 to 0xFB; or it is not receiving token pass from the bus yet. It is likely the device is not present in the Host live list or it has not been commissioned yet. Check again the FF Host configuration and addressing.
  - b. BUS LED is off: FPAC has not detected any valid activity on the bus. Check wiring, connectors, terminators, bus voltage (between 9 V and 32 V), barriers, signal amplitude.

## 6.18 Indication of valve closed or valve opened is wrong

- LEDs OPEN, CLSD, AUX1 and AUX2 work independently from any block configuration. This feature can be used to test if the limit switches are working and properly installed or adjusted. Follow the steps below:
   a. All dis gwitches chould be in the off.
  - a. All dip switches should be in the off position.
  - b. Power up the module. It must blink ALL LEDs once. If the LEDs do not blink, check wiring, connectors, and if bus voltage measured at the device connector is between 9V and 32V.
  - c. Move the shaft to the OPENED position. At this position, the cam magnet should be facing the FPAC canister and the OPEN LED should turn on. If you are not able to move the shaft you can also put a magnet near the Top Hall Effect limit switch (see Figure 1 for location).

If the LED does not turn on, check the cam alignment and make adjustments if necessary. Rotate the shaft or remove the magnet, the LED should turn off. If the LED does not turn on even when you put a magnet close to it, then the module may have been damaged. Contact Westlock technical support.

- d. Repeat the same procedure for the CLOSED position and the CLSD LED with the Bottom Hall sensor.
- e. Using a wire, clip, tweezers or pliers, short out AUX1 pins (J4 1,2). The AUX1 LED should turn on. Release the short, the LED should turn off. If the LED does not behave as explained the module may have been damaged. Contact Westlock technical support.
- f. Repeat the same procedure for AUX2 input (J4 3,4) and AUX2 LED.
- If all LEDs are turning on and off properly, then it is likely you have a configuration problem. Review device configuration or see the next sections for more troubleshooting options.

## 6.19 Valve is not moving when set-point is written to the DO block

- 1. Check pneumatic connections, air supply pressure, solenoid valve wiring.
- Check DO BLOCK\_ERR parameter for configuration errors and make sure all mandatory parameters are properly configured: MODE\_BLK, CHANNEL, SHED\_ OPT, I0\_OPTS.
- Check associated transducer block actual mode is AUTO.

### 6.20 DO block entered IMAN or AUTO mode

- Both limit switches associated to the configured channel are active at the same time. Check limit switches, actuator and valve stops, wiring etc.
- 2. The block that is publishing the set-point to the D0 is sending a BAD status. Check the application.

## 6.21 BKCAL\_OUT\_D parameter is not indicating actual valve position

- Check if parameter IO\_OPTS has been configured. Bit "Use PV for BKCAL\_OUT" has to be set to indicate actual valve position.
- Check parameter XD\_STATE if you are using the intend option. See section "READBACK parameter operating modes" for more details.
- 3. Check if the associated transducer block mode is OOS or MAN. Change it to AUTO.

## 6.22 DI.OUT\_D parameter is not indicating actual valve position

- 1. Check block mode, it should be in AUTO.
- 2. Check if parameter CHANNEL has been properly configured.
- 3. Check if the associated transducer block mode is OOS or MAN and change it to AUTO.

## 6.23 Valve OPENED and CLOSED indications are inverted

- Check IO\_ASSIGMENT parameter in the standard transducer block. The convention for the I/O order is OPENED, CLOSED, OUTPUT.
- 2. If using auxiliary inputs, check limit switches wiring.
- If using internal Hall sensors, check cams: TOP cam is for opened position and BOTTOM cam is for closed position.

### 6.24 Analog Input block is not working

- Check associated transducer block, MODE\_BLK = AUTO and IO\_ASSIGNMENT = Analog,Out1/2 parameters.
- 2. Check mode block, set to AUTO.
- 3. Check CHANNEL configuration.
- 4. Check L\_TYPE configuration.
- Check XD\_SCALE and OwUT\_SCALE configuration match the configured CHANNEL.
  - a. For Actual position: 100, 0, %, 3
  - b. For Internal Temperature: 200, -100, C or F, 3.

## 6.25 Diagnostic parameters that measure time are not working

- If parameters like VALVE\_CYCLE\_TIME, STROKE\_TIME\_CLOSED, STROKE\_TIME\_ OPEN or BREAKAWAY\_TIME are not updating check if the actual mode block is in AUTO.
- 2. Close and reopen the parameter window to update the values.

### 6.26 Transducer block is in "LO" (Local Override) mode

- It means the device is in fault state, which can be verified in the BLOCK\_ERR parameter of the Resource Block.
- Fault state is also indicated in the BLOCK\_ ALMS\_ACT parameter of the corresponding transducer block.
- 3. Check transducer block configuration and mode.
- Check transducer block is receiving a valid set-point in the FINA\_VALUE\_D or WORKING\_SP\_D parameters. It only accepts values 0, 1, and 2. Any other value will generate a fault.
- 5. Check DO block channel configuration and mode.
- Check if DO block is receiving a valid set-point in the CAS\_IN\_D and SP\_D parameters. It only accepts values 0, 1, and 2. Any other value will generate a fault.

## 6.27 Where can I see statistics of the FF communication?

1. It depends on the FF Host System. Usually the statistics are grouped by card, port and/or device. See below an example of the statistics collected for the FPAC with the DeltaV system. Usually, after the device has been configured, the statistics are reset and error counters should not increment during normal operation. If counters like NumDllRetryes, NumDllTokenPassTimeouts or NumLiveListAppearances are continuously incrementing it may indicate a misconfiguration, installation problem (power supply, bus terminator, bad contact) or ultimately a defective device. If MissedViewListScan counter is incrementing, the system is not able to read all parameters within the configured scan time. Increase the control module scan time to a suitable value

## **6.28 What does MissedViewListScan indicate about system operation (Pentair DeltaV)?** See Figure 114

1. MissedViewListScan is a diagnostic parameter. If it is incrementing, segment communications should not be seen as overloaded. Scheduled data transfers are guaranteed to get through. An incrementing MissedViewListScan parameter simply is an indication that ViewList data to the controller for operator display is not getting updated as frequently as the controller is requesting it. It is difficult to quantify what is acceptable before it is recommended to slow down the controller execution rate. As more devices are added to a segment and, more importantly, as more function blocks per device are configured, MissedViewListScans can start occurring. The general rule of running the controller execution rate at half the speed of the Macrocycle has been found to eliminate MissedViewListScans in most situations. When Control in the Field is used, a controller can execute slowly because the controller is not included in the control loop. Therefore, from the perspective of the loop, there is no need to configure a module such that misses occur, although MissedViewListScan may still occur during heavy communication usage, such as for downloads.

In practice, there is practically no functional difference between a controller running at one second with a high number of MissedViewListScans compared to the same controller running at two seconds with no MissedViewListScans. Controller execution rate can be set for best operator display update time (faster rate) while minimizing use of processor resources (slower rate). When Hybrid Control is incorporated, the most important criterion to consider is control loop performance. It is generally acceptable to expect some MissedViewListScans to achieve best control loop performance. Experience has shown that, if MissedViewListScans are within 25% of requests sent, display updates are not adversely affected. When doing this calculation make sure to account for counter rollovers.

### 6.29 When configuration is changed from "Double Action" to "Single Action" or viceversa it does not work properly

- 1. Check all other configuration parameters in the Transducer and function blocks.
- 2. Power cycle the device and download the configuration again.

## 6.30 Resolving problems using Status and Substatus

All function block input and output parameters are composed of two fields: value and status. The status field indicates health and quality of the current value being received or generated. In many cases it can be used for diagnostics and problem solving.

Statistic :	Value :	L
RequestsSent	33437	Reset Stats
bortsRxd	0	
nitsSent	0	Help
nitPosConBxd	0	
nitNeaConBxd	0	
AbortsSent	0	
AbortPosConBxd	0	
AbortNegConFlxd	0	
PerTimeoutsBad	Ŭ.	
RejectsBad	ō	
NumFasAborts	0	
astAbortLocal	ō	
astAbortReason	0	
NumDIDtPdusSent	54856	
NumDIDtPdusReceived	33979	
NumDID(TransferTimouts	0	
NumStackBeceiveQEulls	o 🥖	
NumDIBetrus		
NumDITokenPassTimeouts	n <	
Jenative Cont	ň l	
ocalStackErr	ň N	
neo Ztei Iuni/Apoesit	ů –	
lum iuel istônnearannes	ů – –	

See below an explanation on the most important parameters and how to use them depending on the block type:

### 6.30.1 Discrete output status and substatus

Use the tables below to identify configuration and operation problems related to the DO block.

Parameter	Status: Quality-Substatus-Limit	Possible causes and fixes
	Bad-OutOfService-NotLimited	<ul><li>Block mode is in OOS, check MODE_BLK parameter.</li><li>Check Resource block mode in OOS.</li><li>Check associated transducer mode in OOS.</li></ul>
OUT_D	Uncertain-InitialValue-Constant	<ul> <li>CAS_IN_D is receiving a BAD status. Check set-point publisher.</li> <li>Both limit switches are active at the same time, check limit switches, cam adjustment, wiring. Block mode is IMAN.</li> <li>Block mode is CAS+AUTO or AUTO but no CHANNEL has been assigned.</li> </ul>
	Good-NonSpecific-NotLimited	• This is the expected status when everything is working properly and the block mode is CAS+AUTO, AUTO.
Parameter	Status: Quality-Substatus-Limit	Possible causes and fixes
BKCAL_ OUT_D	Good-FaultStateActive- NotLimited	<ul> <li>Device is in Fault State and STATUS_OPTS = Propagate Fail Bkwd. See Resource block.</li> <li>Block mode goes to LO (Local Override).</li> </ul>
	Bad-OutOfService-NotLimited	<ul><li>Block mode is in OOS, check MODE_BLK parameter.</li><li>Check Resource block mode in OOS.</li></ul>
	Good-NotInvited-NotLimited	<ul> <li>Both limit switches are active at the same time, check limit switches, cam adjustment, wiring.</li> <li>Block mode is CAS+AUTO or AUTO but no CHANNEL has been assigned.</li> <li>Check associated transducer block mode in OOS or MAN</li> </ul>
BKCAL_ OUT_D	Good-NonSpecific-SensorFail	• If using the analog input, the potentiometer has not yet been calibrated.
	Good-NonSpecific-LowLimited	<ul> <li>Position reading from potentiometer is below -2%, check potentiometer calibration, mechanical assembly, valve and actuator stops.</li> </ul>
	Good-NonSpecific -HighLimited	<ul> <li>Position reading from potentiometer is above +102%, check potentiometer calibration, mechanical assembly, valve and actuator stops.</li> </ul>

### 6.30.2 Discrete input status and substatus

Use the table below to identify configuration and operation problems related to the DI block.

Parameter	Status: Quality-Substatus-Limit	Possible causes and fixes
	Bad-OutOfService-NotLimited	Block mode is in OOS, check MODE_BLK parameter.     Check Resource block mode in OOS
Parameter OUT_D	Bad-NonSpecific-NotLimited	<ul> <li>Both limit switches are active at the same time, check limit switches, cam adjustment, wiring.</li> <li>Block mode is AUTO but no CHANNEL has been assigned.</li> <li>Check associated transducer block mode in OOS or MAN.</li> </ul>
	Uncertain-NonSpecific- NotLimited	• Normal condition with block in MAN and STATUS_OPTS = Uncertain if Man.
OUT_D	Good-NonSpecific-SensorFail	<ul> <li>If using the analog input, the potentiometer has not yet been calibrated.</li> </ul>
	Good-NonSpecific-LowLimited	<ul> <li>Position reading from potentiometer is below -2%, check potentiometer calibration, mechanical assembly, valve and actuator stops.</li> </ul>
	Good-NonSpecific -HighLimited	<ul> <li>Position reading from potentiometer is above +102%, check potentiometer calibration, mechanical assembly, valve and actuator stops.</li> </ul>
	Good-NonSpecific-NotLimited	<ul> <li>Normal condition with block in AUTO.</li> </ul>
	Good-NonSpecific-Constant	<ul> <li>Actual mode in MAN and STATUS_OPT configured to set Uncertain If MAN.</li> </ul>

6.30.3 Analog input status and sub-status

Parameter	Status: Quality-Substatus-Limit	Description
	Bad-OutOfService-NotLimited	<ul> <li>Actual mode in OOS. Check block configuration and associated transducer block.</li> </ul>
OUT	Bad-NonSpecific-NotLimited	<ul> <li>Actual mode in OOS. Check block configuration and associated transducer block.</li> </ul>
001	Uncertain-NonSpecific-NotLimited	<ul> <li>Actual mode in MAN and STATUS_OPT configured to set Uncertain.</li> </ul>
	Good-NonSpecific-NotLimited	<ul> <li>Normal condition with block in AUTO.</li> </ul>
	Good-NonSpecific-Constant	• Normal condition with block in MAN.
Parameter	Status: Quality-Substatus-Limit	Description
	Bad-OutOfService-NotLimited	Actual mode in OOS.
FIELD_ VAL	Bad-ConfigurationError-NotLimited	<ul> <li>Check if transducer block IO_ASSIGNMENT parameter is configured for Analog option.</li> </ul>
	Good-NonSpecific-NotLimited	<ul> <li>Normal condition with block in AUTO.</li> </ul>

Good-NonSpecific-NotLimited

### 6.31 Resolving problems using BLOCK\_ERR (Block Error) parameter

### NOTE

The BLOCK\_ERR parameter gives the user further insight into configuration errors and operational faults that prevent the expected operation of the device. After the error is identified the user must take the appropriate steps to eliminate the error.

Use the BLOCK\_ERR (Block Error) parameter to troubleshoot configuration and operation. See below a table with possible block error indications depending on the block type:

Bit	Hex	Message	RB	ΤВ	DIAG	DI	DO	AI	Description
1	0x0002	BlockConfiguration	•	•	•	•	•	•	There is one or more parameters with invalid values in the block. Refer to the next sections for possible causes and solutions.
5	0x0010	DeviceFaultState	•						Fault state is active. The RB is either forcing this state or there is at least one block with BlockConfiguration. Refer to the next sections for possible causes and solutions.
6	0x0020	DeviceMaintenance	•						There is a transducer block configure to use the optional potentiometer
7	0x0040	SensorFailure		•				•	The analog option (potentiometer) is configured but there is a sensor or calibration failure.
15	0x8000	OutOfService	•	•	•	•	•	•	Block mode is OOS. Check target and actual modes.

See in the following sections the explanation of block error parameter for each block type, possible causes and fixes.

### 6.31.1 Resource block

- 1. BLOCK\_ERR = BlockConfiguration: check for any inconsistencies in the Resource block configuration.
- 2. BLOCK\_ERR = DeviceFaultState: device fault state is active.
  - a. The RB can be forcing this state. Check FAULT\_STATE, SET\_FSTATE and CLR\_FSTATE parameters.
  - b. There is at least one transducer or function block with BLOCK\_ERR = BlockConfiguration. Check every block to find out where the problem is and take measures to correct the problems. Only after all blocks in the application are clear from block errors this bit in the Resource block will be cleared.
  - c. One of the transducer blocks is in "LO" mode (Local Override). This can be caused by an invalid set-point value (higher than '2') or status coming from a DO block, or a DO that is not in the correct mode, or is receiving or sending an invalid set-point value for example.
  - d. This can also be caused by a DO block configured with a fault state channel. Check the DO block configuration.
- 3. BLOCK\_ERR = DeviceMaintenance: this bit indicates the position sensor (potentiometer) needs to be calibrated.
  - a. This error bit is valid only if the transducer block is configured with IO\_ASSIGNMENT parameter = "Analog,Out1/2" AND block mode is in AUTO.
  - b. If there is any configuration error in the transducer, the block mode will not go to AUTO, therefore the DeviceMaintenance bit in the Resource block will not be set.
- BLOCK\_ERR = OutOfService: Resource block is not going to AUTO when MODE\_BLK.Target = AUTO.
  - a. Check MODE\_BLK.Target = AUTO.

6.31.2 Transducer blocks TB1 and TB2 (Standard Discrete Transducer)

- BLOCK\_ERR = BlockConfiguration: this bit is the most common error. It is set whenever there is a misconfiguration in the transducer or function blocks. Check the following parameters:
  - a. IO\_ASSIGNMENT: this parameter should match the I/O used in your application. TB1 and TB2 must use different I/O. If your configuration is wrong, configure both transducers with "0: No Selection" and then reconfigure the desired I/O.
  - b. ACTION\_ELEMENT parameter is not configured. Configure using a valid option for your application: Single Action, Double Action, Monitoring or leave it as No Selection.
  - c. SET CURRENT SINK parameter is not properly configured. If FPAC is controlling 2 (two) valves and both transducer blocks are configured with ACTION ELEMENT = "1: Single Action", this parameter must be set to "2: Current Level 2". This means the two outputs can be powered simultaneously and in this condition the FPAC will consume 17 mA from the bus. Otherwise, the block is not going to change the mode to AUTO. For all other configurations this parameter should be left with "1: Current Level 1". You just need to set this parameter in one transducer, then the value is copied to the other one
  - d. DIPSWITCH #6: this switch must be ON whenever the 2 outputs can be used simultaneously, as in applications with two single action valves. In addition, check the parameter SET\_CURRENT\_ SINK = "2: Current Level 2" in the corresponding transducer block. Use parameter MODULE\_IO\_SUMMARY from the Diagnostics transducer block to check dip switch #6 status.

- e. The transducer block is configured to control the valve with ACTION\_ ELEMENT = "1: Single Action" or "2: Double Action", but there is no associated D0 block with the CHANNEL parameter configured to use this transducer. Configure a D0 channel to use this transducer. For example, if transducer TB1 is used, pick channel TRD1: 0-Close / 1-Open.
- f. There is more than one D0 block configured to use the same CHANNEL. Leave only one (1) D0 configured with a given channel. If after the reconfiguration of the D0 channels the block error still persists power cycle the device.
- g. One or more associated D0 block is in 00S mode. Change mode to AUTO.
- h. Block is in "LO" (Local Override) mode. Check parameter BLOCK\_ALMS\_ACT for the cause of the error.
- 2. BLOCK\_ERR = SensorFailure: an error occurred during analog sensor (potentiometer) calibration. Repeat the calibration procedure.
- BLOCK\_ERR = OutOfService: transducer is not going to AUTO when MODE\_BLK. Target = AUTO.
  - a. Both transducers TB1 and TB2 are configured for Single Action valves but dipswitch #6 is not ON. Move dipswitch #6 to ON position. Use parameter MODULE\_10\_SUMMARY from the Diagnostics transducer block to read the switch status.
  - b. Transducers TB1 and TB2 are both configured for Single Action valves but SET\_CURRENT\_SINK parameter is not configured to "Current Level 2".
  - c. Transducer is configured as Single or Double Action but there is no DO assigned to use any of its channels. Configure one DO block to use the transducer channel.

- 6.31.3 Diagnostic Block (TB3 and TB4)
- BLOCK\_ERR = BlockConfiguration: this bit is set when the configuration is inconsistent. Check the following parameters: a.
- BLOCK\_ERR = OutOfService: Diagnostic block is not going to AUTO when MODE\_ BLK.Target = AUTO.
   Charle MODE\_ DLK Terrest\_AUTO.
  - a. Check MODE\_BLK.Target = AUTO.

### 6.31.4 Discrete Input

- BLOCK\_ERR = BlockConfiguration: check the following parameters:
  - a. CHANNEL: it should be configured with a valid channel associated with TB1 or TB2. See Discrete Input channels table for more details.
- BLOCK\_ERR = OutOfService: DI block is not going to AUTO when MODE\_BLK.Target = AUTO.
  - a. DI block is not scheduled to execute. Include the DI block in a control strategy or application to schedule its execution.
  - b. CHANNEL parameter is not properly configured.

### 6.31.5 Discrete output

- BLOCK\_ERR = BlockConfiguration: check the following parameters:
  - a. CHANNEL: it should be configured with a valid channel associated with TB1 or TB2. See Discrete Output channels table for more details.
  - b. SHED\_OPT: should be configured with any valid option, like "NormalShed\_ NormalReturn".
- BLOCK\_ERR = OutOfService: D0 block is not going to AUTO when MODE\_BLK.Target = AUTO.
  - a. D0 block is not scheduled to execute. Include the D0 block in a control strategy or application to schedule its execution.
  - b. CHANNEL is not properly configured.
  - c. SHED\_OPT is not properly configured.

- 6.31.6 Analog input
- BLOCK\_ERR = BlockConfiguration: check the following parameters:
  - a. If your application uses the potentiometer for analog position measurement, verify that at least one of the transducer blocks TB1 or TB2 has IO\_ASSIGNMENT parameter = "Analog,Out1/2", enabling the analog input to read position.
  - b. CHANNEL: it should be configured with a valid channel associated with TB1 or TB2. See Analog Input channels table for more details.
  - c. XD\_SCALE: check this parameter is configured to match the selected channel. See section about Analog Input channels for more information.
  - d. OUT\_SCALE: check this parameter is configured to match the selected channel. See section about Analog Input channels for more information.
  - e. L\_TYPE: should be configured with any valid option, like "Direct".
- 2. BLOCK\_ERR = SensorFailure: an error occurred during analog sensor (potentiometer) calibration. Repeat the calibration.
- BLOCK\_ERR = OutOfService: Al block is not going to AUTO when MODE\_BLK.Target = AUTO.
  - AI block is not scheduled to execute.
     Include the AI block in a control strategy or application to schedule its execution.
  - b. CHANNEL is not properly configured.
  - c. L\_TYPE is not properly configured.
  - d. XD\_SCALE is not properly configured.
  - e. OUT\_SCALE is not properly configured.

### 6.32 Resolving problems using Block Alarms Active parameter

### NOTE

The BLOCK\_ALMS\_ACT parameter, located in the standard transducer blocks TB1 and TB2 gives the user further insight into configuration errors and operational faults that prevent the expected operation of the device.

See in the table below the values, possible causes and solutions.

BLOCK_ALAF	BLOCK_ALARMS_ACTIVE parameter						
Value	Message	Description					
0x00000000	None Active	No active block alarms.					
0x08000000	Fault State Active	Fault State is active in the transducer block due to an invalid input or wrong configuration, like two D0 blocks configured with the same channel or a D0 in 00S mode. Verify resource, transducer and function blocks configuration.					
0x04000000	Invalid Mode	The computed actual mode for the block is not supported, the block's actual mode will go to out of service. Review MODE_BLK.Target parameter.					
0x02000000	Bad Output Configuration	Conflicting output channels have been assigned. Please review channels assignments and make appropriate corrections. It is possible that 2 (two) DO blocks are configured with the same channel.					
0x01000000	Invalid Input	The target position is not valid for the current device configuration. There is an inconsistency between the position DO is commanding the valve to move and the position effectively detected.					
0x00800000	Out Of Service	Transducer block is out of service. Check parameter BLOCK_ERR for any configuration error that may be preventing the block to change the actual mode to AUTO.					
0x00400000	No Output Channels	No output channels have been assigned, i.e. there can be no action. Configure the transducer parameters and DO channel accordingly. For example, the transducer is configured for Single Action but there is no DO configured to use the transducer channel.					
0x00200000	Open without Close	An Open output channel has been assigned without a Close channel. Confirm D0 block's channels configuration.					
0x00100000	Conflicting Channels	Conflicting output channels have been assigned, please review and correct. It is possible D0 blocks are configured to use the same channel, or there are still blocks without proper channel configuration. Review your configuration.					
0x00080000	Both Contacts Closed	Both contacts are closed. OPENED and CLOSED Limits switches configured in the transducer block are both active. This is an invalid condition and should be verified. Check can shaft adjustment and auxiliary inputs.					
0x40000000	Mode Error	The mode calculator detected an error. Review block's configuration.					

Examples of usage:

- Transducer block TB1 is configured to used internal Hall sensors Top and Bottom. Cam shaft magnets are adjusted in a way that the angle is too small, so there is a position where cams are activating the two sensors simultaneously. In this case the BLOCK\_ALARMS\_ACTIVE parameter will indicate 0x00080000 = Both Contacts Closed. Fix the cam shaft adjustment.
- After configuring the device it does not respond and does not move the valve. The BLOCK\_ ALMS\_ACT parameter of the transducer block TB1 is indicating Fault State Active (0x08000000).

### 7 APPENDIX

## 7.1 Appendix A - Limit switches and potentiometer calibration

Although the internal limit switches (cams) and potentiometer are factory set, it is common after the installation is done and all wiring completed the cam set needs to be adjusted for the rotary valves (and external limit switches for the linear valves) in order to allow the sensors to properly read OPENED and CLOSED positions. The LEDs on the top of the electronic module can assist in verifying and adjusting the limit switches. When a limit switch is active the corresponding LED lights up, regardless the configuration in the module.

7.1.1 Quick test after factory default If FPAC is controlling the valve (low power solenoid only) and is at the factory default state there is an easy way to test pneumatic assembly, wiring, solenoid and limit switches. After the factory default (see Appendix B) the dipswitches #4 (CAL) and #5 (O/C) can be used to control the output OUT0. Therefore, if the solenoid is wired to OUT0, it is possible to open and close the valve and check LEDs by following the steps below:

- 1. Make sure the FPAC is at the factory default state (see Appendix B how to perform the factory default).
- 2. Make sure the solenoid is wired to OUT0.
- Make sure dipswitches #4 (CAL) and #5 (O/C) are at the off position.
- 4. Make sure the FPAC is properly powered from the bus connector (9-32VDC).
- 5. Check OUTO LED, it should be off.
- 6. Move the dipswitch #4 (CAL) to the ON position to enable the local calibration.

- OUTO LED should turn ON. OUTO should energize the solenoid making the valve move to the opened position.
- OPEN LED should light up. If necessary, adjust the top cam until the OPEN LED lights up.
- Move the dipswitch #5 (O/C) to the ON position (C = CLOSE).
- 10. OUT0 LED should turn off. OUT0 should de-energize the solenoid making the valve move to the closed position.
- 11. CLSD LED should light up. If necessary, adjust the bottom cam until the CLSD LED lights up.
- 12. While dipswitch #4 (CAL) is on you can control the valve position by moving switch #5 to on and off.
- 13. When you are finished testing, move the dipswitch #5 to the ON position, dipswitch#4 to off position and then finally dipswitch \$ to off position.

### NOTE

This quick test only works right after the factory default. If any configuration is download to the device this procedure will not work and the complete local calibration procedure must be used. See the next sections in this appendix for more details.

## 7.1.2 Cam shaft adjustment when FPAC IS NOT controlling valve position

There are two different ways to perform the limit switches calibration. If FPACs is controlling the valve, there is a special procedure involving block parameters and the dip switch that is explained in the next section. If the FPAC is not controlling the solenoid and is just monitoring the valve, or if you can move the shaft between opened and closed limits, follow the procedure below:

- With the valve OPENED, the TOP can magnet should face the canister and the OPEN LED should light up.
- With the valve CLOSED, the BOTTOM cam magnet should face the canister and, in turn, the CLSD LED should light up.
- If both magnets face the canister, both LEDs will light up.

## 7.1.3 Cam shaft adjustment when FPAC IS controlling valve position

If the FPAC is controlling valve position you need first to configure the transducer block according to your application then follow the procedure henceforth. In the steps below TB1/2 below can be either TB1 or TB2 depending on which transducer is configured to control the valve:

### WARNING

Notice that outputs may change during configuration and operation. Make sure your setup is safe if outputs change state.

- 1. Set Resource block mode to OOS.
- 2. Set Resource block mode to TB1/2 to OOS.
- 3. Write TB1/1.CALIBRATION\_ENABLE = "1: Manual Calibration Enabled".
- 4. Set dipswitch #4 CAL to ON.
- 5. Set dipswitch #5 O/C to ON => the valve moves to CLOSED position.
- 6. Manually adjust the BOTTOM cam shaft until the CLSD LED turns on.
- Set dipswitch #5 O/C to OFF => the valve moves to OPENED position.
- 8. Manually adjust the TOP cam shaft until the OPEN LED turns on.
- 9. Set dipswitch #4 CAL to OFF.
- 10. Return Resource and Transducer blocks to the previous modes.



**Top Cam:** with the actuator in the OPENED position, push it down and turn until the magnet faces the canister and the OPEN LED turns on, then release.

**Bottom Cam:** with the actuator in the CLOSED position, pull it up and turn until the magnet faces the canister and then CLSD LED turns on, then release.

FIGURE 115 Cam shaft adjustment



### 7.1.4 Potentiometer calibration

An optional potentiometer can be installed (see ordering guide) to read the analog position in % of the open position using an Al block. This way FPAC operates as a position transmitter. The position is transmitted to the control/ monitoring system through an Analog Input (AI) block. It is mandatory to configure the IO\_ASSIGNMENT parameter to "Analog,Out0/1" in the transducer block TB1 or TB2. In the case FPAC is just monitoring the valve position (valve is controlled by other means) the output is not used and the valve has to be moved by others means to accomplish the calibration.

**Note:** until the calibration is performed the Resource Block will keep indicating block error DeviceMaintenance as long as the transducer block mode is AUTO.

**Note:** this calibration procedure assumes the valve starts at the CLOSED position.

The calibration is done in two phases, as explained below:

- First phase: prepare for local calibration. These steps are accomplished with the FF Host system or with the use of a FF portable configurator:
  - a. This procedure applies for firmware version 5.0.0 and above.
  - b. Configure TB1/2.IO\_ASSIGNMENT = "Analog,Out0/1".
  - c. Set parameter TB1/2.CALIBRATION\_ ENABLE = "1: Manual Calibration Enabled" if not yet configured (after factory default it is automatically enabled for the first calibration).
- 2. Second phase: perform local calibration. These steps are accomplished at the FPAC:
  - a. Make sure dipswitches #5 (O/C) and #4 (CAL) are OFF.

- b. With the valve at the CLOSED position perform the initial adjustment of the gears as follows:
  - Make sure the potentiometer is installed onto the gear restrain with its label facing the main shaft as shown in the picture below. If not, contact the factory for more instructions. See Figure 116.
  - ii. If the valve opens counterclockwise (looking from the top of the module):
    - Make sure the valve remains at the CLOSED position during this adjustment.
    - 2. Push the big gear to release the clutch.
    - Rotate it in any direction until the OPEN LED turns solid ON AND the groove on top of the potentiometer shaft points towards the electronic module, as can be seen in the picture below.
  - 4. Release the big gear.
  - See Figure 117.
  - iii. If the valve opens clockwise (looking from the top of the module):
    - 1. Make sure the valve remains at the CLOSED position during this adjustment.
    - 2. Push the big gear to release the clutch.
    - Rotate it in any direction until the CLSD LED turns solid ON AND the groove on top of the potentiometer shaft points towards the main shaft, as can be seen in the picture below.
    - 4. Release the big gear.
  - See Figure 118.

### FIGURE 116

16 FIGURE 117 FIGURE 118

- c. **Warning:** the valve will move in the next steps. Make sure all safety precautions have been taken.
- d. Set switch #4 to ON => OPEN and CLSD LED's will start blinking.
- e. If FPAC is controlling the valve it will open. Otherwise, move the valve to the opened position by any other means.
- f. After the valve is stable at the opened position, set dipswitch #4 (CAL) to OFF => OPEN LED stops blinking and lights up solid. CLSD LED will still be blinking.
- g. Set dipswitch #5 (0/C) switch to 0N. If FPAC is controlling the valve it will close. Otherwise, move the valve to the closed position by any other means.
- h. After the valve is stable at the closed position, set dipswitch #4 (CAL) to ON => OPEN LED should go OFF while CLSD LED still blinks.
- i. Set dipswitch #4 CAL to OFF => CLSD LED stops blinking and lights up solid.
- j. Set dipswitch #5(O/C) to OFF position to finish the calibration.
- 3. Return Resource and Transducer Blocks to the previous modes.
- 4. Download the application and verify the AI block now reports position accurately over the calibrated range.

Note: OPENED and CLOSED positions with the potentiometer use a fixed tolerance of  $\pm 2\%$  of the full calibrated span.

**Note:** when FPAC is at factory default state there is a valid default calibration value for the potentiometer assuming a 90 degree stroke. However, in order to match the actual installation the calibration should be performed to adjust for zero, span and direction. While this calibration is not performed, the Resource Block will indicate Device Needs Maintenance in the BLOCK\_ERR parameter. After this calibration is performed the data is stored in the non-volatile memory and IS NOT LOST after a regular factory default. In order to erase the calibration values to the default values the device needs to be re-initialized as FPAFC or ZRF using a special default procedure (Deep Default, contact Westlock). See Appendix B for more information.

### 7.2 Appendix B - Dip switch usage

• Use MODULE\_I0\_SUMMARY parameter located in diagnostics transducer blocks TB3 and TB4 to check the status of the dipswitches. Both transducers exhibit the same value:

Bit	Hex	Mnemonic	Description
0	0x0001	WRP	Write protect dip switch #1 is ON
1	0x0002	SIM	Simulate enable dip switch #2 is ON
2	0x0004	FCT	Factory default dip switch #3 is ON
3	0x0008	CAL	Calibration enable dip switch #4 is ON
4	0x0010	0/C	Open/Close dip switch #5 is ON
5	0x0020	AUX	Auxiliary dip switch #6 is ON
6	0x0040	OUTO	Discrete Output 0 is energized
7	0x0080	OUT1	Discrete Output 1 is energized
8	0x0100	AUX1	Discrete Auxiliary Input 1 pins are shorted out
9	0x0200	AUX2	Discrete Auxiliary Input 2 pins are shorted out
10	0x0400	TOP	Top Hall Effect sensor is active (magnet detected)
11	0x0800	BOT	Bottom Hall Effect sensor is active (magnet detected)
12-15	-	-	Reserved for future use

7.2.1 Switch #1 write protect

• When this switch is set to ON Resource block parameter WRITE\_LOCK = Locked. This prevents any unwanted change in the configuration.

- 7.2.2 Switch #2 simulate enable
- When this switch is set to ON it enables simulation capability for AI, DI, DO blocks.
   Simulations is useful for commissioning, test and diagnostic purposes. In these blocks the SIMULATE.ENABLE\_DISABLE parameter can only be enable (written to Active) when this switch is ON, otherwise the device will reject the write.

7.2.3 Switch #3 Factory Default procedure

### WARNING

Factory default will erase device's configuration stored in the non-volatile memory. Notice that outputs may change during the factory default procedure. Make sure your setup is safe if outputs change state.

- The regular factory default can be performed following the steps below. Bear in mind this process erases device tag, blocks tags, links, device address and block parameters. The configuration will have to be downloaded again. This factory default does not erase the analog input calibration data for the potentiometer though.
- The procedure below only applies with FF communication on the bus. It will not work if the device is connected to a regular DC power supply.
- 2. Close any supervision window for this device while the factory default is not completed.
- 3. Set dip switch 3 to ON.
- 4. Power cycle the device, all LEDs will start blinking.
- 5. Set dip switch 3 to OFF.

- 6. LEDs will stop blinking. LED BUS light up.
- 7. DO NOT TURN POWER OFF while device is saving non-volatile data.
- 8. It may take from 1 to 3 minutes.
- 9. LED BUS will blink when factory default finishes and device will reset.
- 10. If device does not enter promptly in the FF Host list power cycle it.
- 11. All LEDs will blink once and turn off.
- 12. Device is ready for use.

### 7.2.4 Deep Default

### WARNING

This procedure will clear device's configuration and restore potentiometer default calibration. A new download and calibration is necessary to restore device operation.

**Step 1:** Make sure the device is properly powered and connected to the FF Host System or portable configurator. The procedure below only applies with FF communication on the bus. It will not work if the device is connected to a regular DC power supply. Close any supervision window for this device while the factory default is not completed.

**Step 2:** Make sure all dipswitches are in the OFF position. See Figure 119.

**Step 3:** Set dip switches 1, 3 and 5 to ON. Leave all other switches OFF. See Figure 120. **Step 4:** Power cycle the device, LEDs OUT0 e OUT1 start blinking.

**Step 5:** Set only switches 1 and 5 to OFF, leaving switch 3 ON. See Figure 121.

### FIGURE 119



### FIGURE 120





Step 6: Now set dip switch 3 to OFF (this switch must be the last one to be switched OFF). If you don't follow this sequence you may have to repeat the procedure.

Step 7: LEDs will stop blinking. LED BUS light up.

Step 8: DO NOT TURN POWER OFF while device is saving non-volatile data.

Step 9: LED BUS will blink when factory default finishes. It may take from 1 to 3 minutes. Step 10: Power cycle the device, all LEDs will blink

Step 11: Device is ready for use and DEVICE ID will show default FPAC information. See Figure 122.

Step 12: Remember to set dipswitch #6 to ON in case the application requires two single action solenoids powered simultaneously by FPAC.

7.2.5 Switch #4 and #5 Local Calibration and Real Time Clock

- Local calibration.
  - When the switch #4 is ON it enables local control of the outputs. This switch works along with CALIBRATION\_ENABLE parameter, present in transducers TB1 and TB2. To enable local calibration CALIBRAITON ENABLE = "1: Manual Calibration Enabled" AND switch #4 = ON.
- Once the local calibration is enabled, switch #5 is used to move the valve to opened and closed positions in order to adjust the cams.
- See section about local calibration for more information

- Real time clock adjustment:
  - When switch #4 is ON it enables Real Time Clock adjustment through PST INITIAL START TIME parameter located in the Diagnostic Transducer block. RTC can be used for operations like event logging and automatic tests like PST and FST.

7.2.6 Switch #6 Auxiliary power, high current mode

- This switch controls the current consumption of the device. It works along with parameter SET CURRRENT SINK located in the transducer blocks TB1 and TB2. The switch AND the parameter determine if the FPAC will drain 12 mA or 17 mA from the bus.
- THIS SWITCH SHOULD ALWAYS BE IN THE OFF POSITION unless the FPAC is configured to control 2 (TWO) SINGLE ACTION VALVES with power coming from the bus. It is NOT necessary to turn switch #6 ON for any other configuration. With the switch in the off position FPAC will drain 12 mA from the bus.
- In order to enable FPAC to power 2 coils/ piezos simultaneously, dip switch #6 should be set to the ON position AND SET CURRRENT SINK parameter set to "2: Current Level 2". In this situation FPAC will drain 17 mA from the bus.
- Use MODULE\_IO\_SUMMARY parameter in the Diagnostics transducer block to read the status of the dipswitches. See Figure 123.

FIGURE 122	
Image: State of the second system (ver 2.3.6): FCP1         File       Edit       Verr       27.5.6): FF2_00005       Configure       Window       Help         Image: State of the second system       Image: State of the second system       Image: State of the second system       Verr       2.3.6): FCP1         Image: State of the second system       Image: State of the second system       Image: State of the second system       Verr       2.3.6): FCP1         Image: State of the second system       Image: State of the second system <t< td=""><td>FIGURE 123</td></t<>	FIGURE 123

INSTALLATION AND OPERATION MANUAL

### 7.3 Appendix C - DO.READBACK parameter tables

Westlock Controls manufacturer specific state tables:

• State Table 64000 (0xFA00) Pure bit value:

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
Out0	Out1	Bottom	Тор	Aux1	Aux2	Analog	Fail

• State Table 64001 (0xFA01) Bit value is channel dependent:

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
Cl/Op cmd1	Cl/Op cmd2	Closed1	Opened1	Stopped1	Closed2	Opened2	Stopped2

### 7.4 Appendix D - Complete list of block parameters

7.4.1 Common definitions and tables

- Factory Default (FCT default) values are obtained after a Resource block RESTART parameter is written to '5', or '11' or dipswitch #3 is used. See Appendix B for more details on the factory default procedure.
- Deep Default values are obtained after a special procedure using the dipswitches. See Appendix B for more details on the factory default and deep procedures.
- BLOCK\_ALMS\_ACT table (valid for the Standard Transducer block only):

Value	Meaning
0x00000000	None Active => No active block alarms
0x0800000	Fault State Active => Fault State is active in the transducer block due to an invalid input or
	mis-configuration
0x04000000	Invalid Mode => The computed actual mode for the block is not supported, the blocks actual
	mode will go to out of service
0x02000000	Bad Output Configuration => Conflicting output channels have been assigned. Please review
	channels assignments and make appropriate corrections
0x01000000	Invalid Input => The target position is not valid for the current device configuration
0x00800000	Out Of Service => Transducer block is out of service
0x00400000	No Output Channels => No output channels have been assigned, i.e. there can be no action
0x00200000	Open without Close => An Open output channel has been assigned without a channel Close
0x00100000	Conflicting Channels => Conflicting output channels have been assigned, please review and
	correct
0x00080000	Both Contacts Closed => Both contacts are closed
0x4000000	Mode Error -> The mode calculator detected an error

• SIGNAL\_MASK and MASKABLE\_SIGNAL table:

### Value Meaning

- **0** No Selection => No signal is selected to generate discrete
- 1 Cycle Count exceeds limits => Number of valve cycles exceeds the CYCLE\_COUNT\_LIM
- 2 Cycle Time exceeds limits => Cycle time exceeds limit set in CYCLE\_TIME\_LIM
- **4** Bad Xducer Status => Status of the transducer is not Good
- **5** Low Temp. Alarm exceeds limits => Threshold configured for this parameter has been exceeded
- 6 Hi Temp. Alarm exceeds limits => Threshold configured for this parameter has been exceeded

• Function block channels after factory default (dip switch #3):

# DEFAULT CHANNEL (FCT DEFAULT DIP SWITCH #3 OR RB.RESTART = 5 OR 11) Block CHANNEL DI\_1 9: TRD1: 0-Closed / 1-Opened DI\_2 0: No Transducer Connection DI\_3 0: No Transducer Connection

DI_4	0: No Transducer Connection
DI_5	0: No Transducer Connection
DI_6	0: No Transducer Connection
D0_1	1: TRD1: 0-Close / 1-Open
D0_2	0: No Transducer Connection
D0_3	0: No Transducer Connection
D0_4	0: No Transducer Connection

AI 1: Actual Position

### 7.4.2 Complete list of discrete standard transducer block parameters

Index	Parameter	Description / DD Help	Valid range	Default	FCT default	Deep default	Units	Write	R/W
1	ST_REV	The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.	Yullu Fullyc	Denual	ucidutt	ucidutt	onits	Witte	Read only
2	TAG_DESC	The user description of the intended application of the block.							R/W
3	STRATEGY	The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.							R/W
4	ALERT_KEY	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.	1 to 255				None		R/W
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.	See MODE	0/S	0/S	0/S	NA		R/W
6	BLOCK_ERR	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.							Read only
7	UPDATE_EVT	This alert is generated by any change to the static data.							Read only
8	BLOCK_ALM	The block alarm is used for all configuration, hardware, connection failure or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status attribute. As soon as the Unreported status is cleared by the alert reporting task, another block alert may be reported without clearing the Active status, if the subcode has changed.							Read only
9	TRANSDUCER_ DIRECTORY	A directory that specifies the number and starting indices of the transducers in the transducer block. For further information, please refer to section 3.4.7.	At a minimum is an array of 1 element containing a 0	0	0	0	None		Read only
10	TRANSDUCER_ TYPE	Identifies the transducer that follows.	See Standard Tables (TN-016)	107: Standard Discrete Valve	107: Standard Discrete Valve	107: Standard Discrete Valve	E		Read only
11	TRANSDUCER_ TYPE_VER	The version of the transducer identified by TRANSDUCER_ TYPE in the form 0xAABB where AA is the major revision of the transducer specification on which the transducer is based, and BB is a revision number assigned and controlled by the manufacturer of the device.	See parameter description	0x1100	0x1100	0x1100			Read only
12	XD_ERROR	One of the error codes defined in section 4.4 XD_ERROR and Block Alarm Subcodes below.	See section 4.4 XD_ERROR and Block Alarm Subcodes				E		Read only
13	COLLECTION_ DIRECTORY	A directory that specifies the number, starting indices, and DD Item IDs of the data collections in each transducer within a transducer block. For further information, please refer to section 3.4.8 above.	Legacy, array with one element = 0.	0	0	0	None		Read only
14	FINAL_ VALUE_D	The requested valve position and status written by a discrete Function Block.		0	0	0	None	0/S, Man	R/W

	Parameter				FCT	Deep			
Index	mnemonic	Description / DD Help	Valid range	Default	default	default	Units	Write	R/W
15	FINAL_ POSITION_ VALUE_D	The actual valve position and status; can be used for a DI block and as the READBACK_ VALUE in a DO block.		0	0	0	None		Read only
16	WORKING_ POS_D	The actual measured discrete feedback position before de-characterization.		0	0	0			Read only
17	WORKING_ SP_D	The final discrete command value to the positioning algorithm after characterization.		0	0	0		0/S, Man	R/W
18	PSNR_ FSTATE_VAL_D	User defined discrete position in case of fault state of transducer.		0	0	0		0/S, Man	R/W
19	DISCRETE_ STATE		See DD enumeration	0	0	0			R/W
20	PSNR_ FSTATE_OPT	Defines an action to be taken on a transducer fault state. Enumerations defined in Standard Tables (TN-016).	0: Hold Last Value 1: Fail Closed 2: Fail Open 3: PSNR_FSTATE_VAL_D 4-7: Reserved 8-255: Mfg Specific						
21	CYCLE_CNTR	Totalized cycle counts since last clear. A cycle is defined as a complete movement from one end to another.							
22	SIGNAL_ ACTION	Defines actuator movement relative to increasing command. Enumerations defined in Standard Tables (TN-016).	0: Increase to Open 1: Increase to Close						
23	READBACK_ SELECT	Selects whether working position or final position value is passed back to connected function block. Enumerations defined in Standard Tables (TN-016).	0: Final Position Value 1: Working Position Value						
24	PSNR_ COMMAND	Command to start device-specific procedure. Command value will reset to zero after execution of procedure regardless of value of PSNR_COMMAND_STATE.	0: Normal Operation 1-7: Reserved 8-65535: Mfg Specific: 8: Arm 9: Verify Open/Close 10: Verify Open Position 11: Verify Closed Position 15: Abort						
25	PSNR_ COMMAND_ STATE	The state of the procedure initiated by PSNR_ COMMAND.	0: Normal Operation 1-7: Reserved 8-65535: Mfg Specific: 8: Arm 9: Verify Open/Close 10: Verify Opened Position 11: Verify Closed Position 15: Abort	0: Normal Operation	0: Normal Operation	0: Normal Operation	E		Read only
26	PSNR_00S_ OPT	Defines an action to be taken whenever the Transducer Block transitions to Out of Service mode. *Note: not all options are required to be supported.	0: Hold Last Value 1: Fail Closed 2: Fail Open 3: PSNR_FSTATE_VAL_D 4-7: Reserved 8-255: Mfg Specific	1: Fail Closed	1: Fail Closed	1: Fail Closed	E	O/S, Man	R/W

	Parameter				FCT	Deep			
Index	mnemonic	Description / DD Help	Valid range	Default	default	default	Units	Write	R/W
27	POS_ FEATURES	BIT_ENUMERATED parameter indicating the parameter groups supported by this transducer block.	0: Group A 1: Group B 2: Group C 3: Group D 4: Group E 5: Group F 6: Group G 7: Group H 8: Group I 9: Group J 10: Group K 11: Group L 12-15 Reserved	А, С, D, К, L	A, C, D, K, L	A, C, D, K, L	Ε		Read
28	ACT_FAIL_ ACTION	Informative parameter, does not affect the block. Specifies the final failure position of the actuator as defined in the Standard Tables (TN-016). It is a recommendation that only the first four enumerations of the table be used.	0: Undefined 1: Self-closing 2: Self-opening 3: Hold last value 4: Maximum value 5: Minimum value 255: Indeterminate	0	0	0	E		R/W
29	ACT_MAN_ID	The actuator manufacturer identification.					None		R/W
30	ACT_MODEL_ NUM	The actuator model number.					None		R/W
31	ACT_SN	The actuator serial number.					None		R/W
32	ACT_TYPE	Actuator type, just and informative parameter.	0: Undefined 1: Linear 2: Rotary 3: Rotary - Multi-turn 4: Rotary - Quarter-turn 5: Linear - Lever 6-32767: Reserved 32768-65534: Manufacturer Specific	4: Rotary - Quarter- turn	4: Rotary - Quarter- turn	4: Rotary - Quarter- turn			R/W
33	VALVE_MAN_ID	The valve manufacturer identification.					None		R/W
34	VALVE_ MODEL_NUM	The valve model number.					None		R/W
35	VALVE_SN	The valve serial number.					None		R/W
36	VALVE_TYPE	The type of the valve as defined in the Standard Tables (TN-016).	0: Globe 1: Gate 2: Butterfly 3: Ball 4: Plug 5: Diaphragm 6: Float 7: Check 8: Triple Offset 255: Other	2: Butterfly	2: Butterfly	2: Butterfly	E		R/W

	Parameter								
Index	mnemonic	Description / DD Help	Valid range	Default	FCT default	Deep default	Units	Write	R/W
37	XD_CAL_LOC	The location of last positioner calibration. This describes the physical location at which the calibration was performed. (ex. "NIST", "Acme Labs").					None		R/W
38	XD_CAL_DATE	The date of the last positioner calibration.		01/01/2013 00:00:00 000	01/01/2013 00:00:00 000	01/01/2013 00:00:00 000	None		R/W
39	XD_CAL_WHO	The name of the person responsible for the last positioner calibration.					None		R/W
40	CHARACTERIZA- TION	Desired characterization operation. Enumerations defined in Standard Tables (TN-016)	0: Linear 1: Percent 2: Quick Opening 3: Custom 4-7: Reserved 8-255: Mfg Specific	0	0	0	E	O/S, Man	R/W
41	STROKE_TIME_ CLOSE_LIM	The user defined time of a full span travel in closing direction in seconds, used to slow down valve movement.		0	0	0	Sec	0/S, Man	R/W
42	STROKE_TIME_ OPEN_LIM	The user defined time of a full span travel in opening direction in seconds, used to slow down valve movement.		0	0	0	Sec	0/S, Man	R/W
43	TRAVEL_ACCUM_ LIM	User defined limit of accumulator value that will trigger alert.					TAU		R/W
44	TRAVEL_ACCUM_ UNITS	Travel units as defined in standard table in TN-016.	See Standard Tables (TN-016)				TAU	0/S, Man	R/W
45	INTERNAL_TEMP	Internal device temperature in user defined temperature units.	-40 to +185				ITU		Read only
46	INTERNAL_ TEMP_MIN	Minimum internal device temperature in user defined temperature units over operation lifetime of device.	-40 to +185			22	ITU		Read only
47	INTERNAL_ TEMP_MAX	Maximum internal device temperature in user defined temperature units over operation lifetime of device.	-40 to +185			22	ITU		Read only
48	INTERNAL_ TEMP_UNITS	Internal temperature units as defined in standard table in (TN-016).	Only accepts °C and °F	°C	°C	°C	ITU		R/W
49	HIGH_ TEMPERATURE_ LIM	Sets the threshold for the HIGH_ TEMPERATURE_ALM. Unit is given by INTERNAL_TEMP_UNITS parameter.	-40 to +185	80	80	80	E		R/W
50	HIGH_ TEMPERATURE_ PRI	Alarm priority for the HIGH_ TEMPERATURE_ALARM.		0	0	0	E		R/W
51	LOW_ TEMPERATURE_ LIM	Sets the threshold for the LOW_ TEMPERATURE_ALARM. Unit is given by INTERNAL_TEMP_UNITS parameter.	-40 to +185	-35	-35	-35	E		R/W
52	LOW_ TEMPERATURE_ PRI	Alarm priority for the LOW_ TEMPERATURE_ALARM.		0	0	0	E		R/W
53	TEMPERATURE_ ALARM_ HYSTERESIS	Amount the TEMPERATURE must return within the alarm limits before the alarm condition clears.	-40 to +185	5	5	5			R/W

	Parameter								
Index	mnemonic	Description / DD Help	Valid range	Default	FCT default	Deep default	Units	Write	R/W
54	ACTION_ ELEMENT	User configurable parameter to determine the type of valve operation needed. It MUST be set before operation. To achieve the same combinations as in the old FPAC the user must also configure the parameter SIGNAL ACTION.	0: No Selection 1: Single Action 2: Double Action 3: See other transducer 4: Monitoring	0: No Selection	TB1: 1: Single Action TB2: 0: No Selection	TB1: 1: Single Action TB2: 0: No Selection		0/S	R/W
55	IO_ASSIGNMENT	Assign physical I/O to this transducer block. The convention that is used to reflect the physical I/O to the parameters values is: 1, 0, OUT. For example: - If option "1: Top,Bottom,OutO" is selected, when sensor "Top" is active, parameter WORKING_POS_D = 1. - If option "3: Bottom,Top,OutO" is selected, when sensor "Bottom" is active, parameter WORKING_POS_D = 1. When ACTION_ELEMENT is configured as Double Action both physical output are automatically allocated to this transducer. When Analog options is selected the OPEN and CLOSE positions come from the position sensor after proper calibration. - If ACTION_ELEMENT is configured as "4: Monitoring" the output is not used and becomes available for the other transducer block.	0: No selection 1: Top,Bottom,Out0 2: Top,Bottom,Out1 3: Bottom,Top,Out0 4: Bottom,Top,Out1 5: Aux1,Aux2,Out0 6: Aux1,Aux2,Out1 7: Aux2,Aux1,Out0 8: Aux2,Aux1,Out1 9: Analog,Out0 10: Analog,Out1	0: No Selection	TB1 = 1: Top,Bottom, Out0 TB2: 0: No Selection	TB1 = 1: Top,Bottom, Out0 TB2: 0: No Selection		O/S	R/W
56	RESERVED1	Reserved for future use.	0	0	0		0/S, Man	R/W	
57	CYCLE_COUNT_ PRI	Priority of the first cycle count alarm.	0	0	0			R/W	
58	CYCLE_TIME_ LIM	User configurable Floating Point value used as limit to determine cycle time alarm. Unit is in seconds.	0	0	0			R/W	
59	CYCLE_TIME_PRI	User configurable priority of cycle time alarm.		0	0	0			R/W
60	SIGNAL_MASK	Used to select which operational failures will be reflected in MASKABLE_SIGNAL.	See SIGNAL_MASK table	No Selection	No Selection	No Selection			R/W
61	COLLECT_ CYCLE_TIME	Enables the collection of cycle_time in cycle_time_history.	0: Inactive 1: Active 2: Report	0	0	0			R/W
62	CYCLE_TIME_ COLLECT_TYPE	Selects Continuous or stop when full collection of cycle time.	0: No Op 1: Continuous 2: Stop when full	0	0	0			R/W
63	CALIBRATION_ ENABLE	Parameter must be enabled for the Limit Sensor Calibration Switch to be operative.	0: Manual Calibration Disabled 1: Manual Calibration Enabled	0: Manual Calibration Disabled	TB1: 1 TB2: 0	TB1: 1 TB2: 0		0/S, Man	R/W
64	SET_CURRENT_ SINK	Allows user to select Ultra-low Current mode (No power for the solenoids is available through Out()/Out1)		1: Current Level 1	1: Current Level 1	1: Current Level 1		0/S, Man	R/W

	Parameter								
Index	mnemonic	Description / DD Help	Valid range	Default	FCT default	Deep default	Units	Write	R/W
65	RESERVED2	Reserved for future use.		0	0	0			R/W
66	WSN_	Password needed to write the Serial		0	0	0		0/S,	R/W
	PASSWORD	Number.						Man	
67	WSN_CONTROL_	Status of serial number write command	0: Disabled	0	0	0			Read
	FLAG	(Disabled,Arm,Fail).	1: Armed						only
			3: Fail						
68	WSN_SERIAL_	Electronic board's Serial Number used for		0	0	0		0/S,	R/W
	NUMBER	the DEVICE_ID.						Man	
69	BLOCK_ERR_	Specific details of a BLOCK_ERR with							Read
	DESC_1	additional diagnostic information.							only
70	BLOCK_ALMS_	Detailed listing of active block alarms to	See BLOCK_ALMS_	0	0	0			Read
	ACT	assist troubleshooting.	ACT table						only
71	SUPPORTED_	Read only parameter that indicates the	0x08: Automatic (Auto)	Auto: Man:	Auto: Man:	Auto: Man:			Read
	MODES	modes supported by the block.	0x10: Manual (Man)	Oos	Oos	Oos			only
			0x80: Out of Service						
			(0/S)						

### 7.4.3 Complete list of discrete output block parameters

	Parameter					Deep			
Index	mnemonic	Description / DD Help	Valid Range	Default	FCT Default	Default	Units	Write	R/W
1	ST_REV	The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.							Read only
2	TAG_DESC	The user description of the intended application of the block.							R/W
3	STRATEGY	The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.							R/W
4	ALERT_KEY	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.	1 to 255				None		R/W
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.	See MODE	0/S	0/S	0/S	NA		R/W
6	BLOCK_ERR	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.					E		Read only
7	PV_D	Either the primary discrete value for use in executing the function, or a process value associated with it. May also be calculated from the READBACK_D value of a D0 block.							
8	SP_D	The discrete setpoint of this block.							
9	OUT_D	The primary discrete value calculated as a result of executing the function block.							

	Parameter								
Index	mnemonic	Description / DD Help	Valid Range	Default	FCT Default	Deep Default	Units	Write	R/W
10	SIMULATE_D	Allows the transducer discrete input or output to the block to be manually supplied when simulate is enabled. When simulate is disabled, the simulate value and status track the actual value and status.							
11	PV_STATE	Index to the text describing the states of a discrete PV.							
12	XD_STATE	Index to the text describing the states of a discrete PV.							
13	GRANT_DENY	Options for controlling access of host computers and local control panels to operating, tuning, and alarm parameters of the block.							
14	IO_OPTS	Option which the user may select to alter input and output block processing.							
15	STATUS_OPTS	Option which the user may select to alter input and output block processing.							
16	READBACK_D	This indicates the readback of the actual discrete valve or other actuator position, in the transducer state.							
17	CAS_IN_D	This indicates the readback of the actual discrete valve or other actuator position, in the transducer state.							
18	CHANNEL	The number of the logical hardware channel that is connected to this I/O block. This information defines the transducer to be used going to or from the physical world.	See table with complete description of the D0 channels	0	DO_1 = 1: TRD1: 0-Close / 1-Open D0_2-4 = 0	DO_1 = 1: TRD1: 0-Close / 1-Open DO_2-4 = 0			
19	FSTATE_TIME	The time in seconds from detection of failure of the output block remote setpoint to the output action of the block output if the condition still exists.							
20	FSTATE_VAL_D	The preset discrete SP_D value to use when failure occurs. This value will be used if the I/O option Fault state to value is selected.							
21	BKCAL_OUT_D	The output value and status provided to an upstream block output tracking when the loop is broken, as determined by the status bits. This information is used to provide bumpless transfer to closed loop control.							
22	RCAS_IN_D	Target setpoint and status provided by a supervisory Host to a discrete control or output block.							
23	SHED_OPT	Defines action to be taken on remote control device timeout.							
24	RCAS_OUT_D	Block setpoint and status provided to a supervisory Host for back calculation and to allow action to be taken under limiting conditions or mode change.							
25	UPDATE_EVT	This alert is generated by any change to the static data.							Read only
	Parameter				FCT	Deep			
-------	----------------	--------------------------------------------------------	----------------------------	---------	---------	---------	-------	-------	------
Index	mnemonic	Description / DD Help	Valid Range	Default	Default	Default	Units	Write	R/W
26	BLOCK_ALM	The block alarm is used for all configuration,							Read
		hardware, connection failure or system problems							only
		in the block. The cause of the alert is entered in the							
		subcode field. The first alert to become active will							
		set the Active status in the Status attribute. As soon							
		as the Unreported status is cleared by the alert							
		reporting task, another block alert may be reported							
		without clearing the Active status, if the subcode has							
		changed.							
27	XDUCER_VAL_D	The value and status received from the transducer							
		block on the selected channel.							
28	BLOCK_ERR_	Specific details of a BLOCK_ERR.							Read
	DESC_1								only
29	BLOCK_ALMS_ACT	Reserved for future use.		0	0	0			Read
									only
30	SUPPORTED_	Read only parameter that indicates the modes	0x08: Automatic (Auto)						Read
	MODES	supported by the block.	0x10: Manual (Man)						only
			0x80: Out of Service (0/S)						

#### 7.4.4 Complete list of discrete input block parameters

	Parameter				FCT	Deep			
Index	mnemonic	Description / DD Help	Valid Range	Default	Default	Default	Units	Write	R/W
1	ST_REV	The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.							Read only
2	TAG_DESC	The user description of the intended application of the block.							R/W
3	STRATEGY	The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.							R/W
4	ALERT_KEY	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.	1 to 255				None		R/W
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.	See MODE	0/S	0/S	0/S	NA		R/W
6	BLOCK_ERR	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.					E		Read only
7	PV_D	Either the primary discrete value for use in executing the function, or a process value associated with it. May also be calculated from the READBACK_D value of a DO block.							
8	OUT_D	The primary discrete value calculated as a result of executing the function block.							
9	SIMULATE_D	Allows the transducer discrete input or output to the block to be manually supplied when simulate is enabled. When simulate is disabled, the simulate value and status track the actual value and status.							

	Parameter				FCT	Deen			
Index	mnemonic	Description / DD Help	Valid Range	Default	Default	Default	Units	Write	R/W
10	XD_STATE	Index to the text describing the states of a discrete							
		for the value obtained from the transducer.							
11	OUT_STATE	Index to the text describing the states of a discrete output.							
12	GRANT_DENY	Options for controlling access of host computers and local control panels to operating, tuning, and alarm parameters of the block.							
13	IO_OPTS	Option which the user may select to alter input and output block processing.							
14	STATUS_OPTS	Option which the user may select to alter input and output block processing.							
15	CHANNEL	The number of the logical hardware channel that is connected to this I/O block. This information defines the transducer to be used going to or from the physical world.	See table with complete description of the DI channels.	0	DI_1 = 9: TRD1: 0-Closed / 1-Opened DI_2-6 = 0	DI_1 = 9: TRD1: 0-Closed / 1-Opened DI_2-6 = 0			
16	PV_FTIME	Time constant of a single exponential filter for the PV, in seconds.							
17	FIELD_VAL_D	Raw value of the field device discrete input, with a status reflecting the Transducer condition.							
18	UPDATE_EVT	This alert is generated by any change to the static data.							Read only
19	BLOCK_ALM	The block alarm is used for all configuration, hardware, connection failure or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status attribute. As soon as the Unreported status is cleared by the alert reporting task, another block alert may be reported without clearing the Active status, if the subcode has changed.							Read
20	ALARM_SUM	The current alert status, unacknowledged states, unreported states, and disabled states of the alarms associated with the function block.							
21	ACK_OPTION	Selection of whether alarms associated with the function block will be automatically acknowledged.							
22	DISC_PRI	Priority of the discrete alarm.							
23	DISC_LIM	State of discrete input which will generate an alarm.							
24	DISC_ALM	The status and time stamp associated with the discrete alarm.							
25	XDUCER_VAL_D	The value and status received from the transducer block on the selected channel.							
26	BLOCK_ERR_ DESC_1	Specific details of a BLOCK_ERR.							Read only
27	BLOCK_ALMS_ ACT	Reserved for future use.		0	0	0			Read only
28	SUPPORTED_ MODES	Read only parameter that indicates the modes supported by the block.	0x08: Automatic (Auto) 0x10: Manual (Man) 0x80: Out of Service (0/S)						Read only

7.4.5 Complete list of analog input block parameters

	Parameter				FCT	Deep			
Index	mnemonic	Description / DD Help	Valid range	Default	default	default	Units	Write	R/W
1	ST_REV	The revision level of the static data associated with the							Read
		function block. The revision value will be incremented each							only
		time a static parameter value in the block is changed.							
2	TAG_DESC	The user description of the intended application of the block.							R/W
3	STRATEGY	The strategy field can be used to identify grouping of blocks.							R/W
1		This data is not checked or processed by the block.	1 255				N.L		DAA
4	ALERI_KEY	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.	l to 255				None		R/W
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.	See MODE	0/S	0/S	0/S	NA		R/W
6	BLOCK_ERR	This parameter reflects the error status associated with the					E		Read
		hardware or software components associated with a block. It							only
		is a bit string, so that multiple errors may be shown.							
7	PV	Either the primary analog value for use in executing the							
		function, or a process value associated with it. May also be							
		calculated from the READBACK value of an AO block.							
8	OUT	The primary analog value calculated as a result of executing the function block.							
9	SIMULATE	Allows the transducer analog input or output to the block							
		to be manually supplied when simulate is enabled. When							
		simulate is disabled, the simulate value and status track the							
		actual value and status.							
10	XD_SCALE	The high and low scale values, engineering units code,							
		and number of digits to the right of the decimal point used							
		with the value obtained from the transducer for a specified							
		channel.							
11	OUT_SCALE	The high and low scale values, engineering units code, and							
		number of digits to the right of the decimal point to be used							
		In displaying the UUT parameter and parameters which have							
10	CRANT DENV	Options for controlling access of bost computers and local							
ΙZ	GRANT_DENT	options for controlling access of nost computers and local							
		of the block							
13	IO OPTS	Ontion which the user may select to alter input and output							
10	10_01 13	block processing.							
14	STATUS_OPTS	Options which the user may select in the block processing							
		of status.							
15	CHANNEL	The number of the logical hardware channel that is	See table with	0	1: Actual	1: Actual			
		connected to this I/U block. This information defines the	complete		Position	Position			
		transducer to be used going to or from the physical world.	description						
			of the DI						
14	I TVDE	Determines if the values passed by the transducer black to	channels.						
10	L_IIFE	the Al block may be used directly (Direct) or if the value is in							
		different units and must be converted linearly (Indirect) or							
		with square root [Ind Sar Root] using the input range defined							
		for the transducer and the associated output range							
		ion and a subsacer and the associated output range.							

Indax	Parameter	Description ( DD Help	Valid range	Default	FCT	Deep	Unite	Maita	D/W
17		Limit used in square root processing. A value of zero percent	valid range	Default	derault	default	Units	write	R/W
17	LOW_COT	ef coole is used in block processing. A value of zero per cent							
		falls below this limit in % of scale. This feature may be used							
		to eliminate poise poar zero from a flow consor							
18	DV ETIME	Time constant of a single exponential filter for the PV in							
10	· v_i in•i∟	seconds							
19	FIFLD VAL	Raw value of the field device in % of PV range, with a							
17	TILLD_VAL	status reflecting the Transducer condition before signal							
		characterization (ITYPE) or filtering (PV_ETIME)							
20	LIPDATE EVT	This alert is generated by any change to the static data							Read
20	0.0/0/02_000								only
21	BLOCK ALM	The block alarm is used for all configuration, hardware.							Read
		connection failure or system problems in the block. The							only
		cause of the alert is entered in the subcode field. The first							,
		alert to become active will set the Active status in the Status							
		attribute. As soon as the Unreported status is cleared by the							
		alert reporting task, another block alert may be reported							
		without clearing the Active status, if the subcode has							
		changed.							
22	ALARM_SUM	The current alert status, unacknowledged states, unreported							
		states, and disabled states of the alarms associated with the							
		function block.							
23	ACK_OPTION	Selection of whether alarms associated with the function							
		block will be automatically acknowledged.							
24	ALARM_HYS	Amount the PV must return within the alarm limits before							
		the alarm condition clears. Alarm hysteresis expressed as							
		a percent of the span of the PV.							
25	HI_HI_PRI	Priority of the high high alarm.							
26	HI_HI_LIM	The setting for high high alarm in engineering units.							
27	HI_PRI	Priority of the high alarm.							
28	HI_LIM	The setting for high alarm in engineering units.							
29	LO_PRI	Priority of the low alarm.							
30	LO_LIM	The setting for the low alarm in engineering units.							
31	LO_LO_PRI	Priority of the low low alarm.							
32	LU_LU_LIM	The setting of the low low alarm in engineering units.							
33	HI_HI_ALM	I he status for high high alarm and its associated time							
27		stamp.							
34		The status of the law elerm and its associated time stamp.							
35		The status of the low low alarm and its associated time statup.							
30	LU_LU_ALM	stamp							
37	YDUCER VAL	The value and status received from the transducer block on							
57	XDOCEN_VAL	the selected channel							
38	XDUCER	The value and status received from the transducer block on							
00	UNITS	the selected channel							
39	BLOCK FRR	Specific details of a BLOCK_ERR.							Read
0,	DESC 1								only
40	BLOCK ALMS	Reserved for future use.		0	0	0			Read
	ACT								only
41	SUPPORTED	Read only parameter that indicates the modes supported by	0x08: Automatic						Read
	MODES	the block.	(Auto)						only
			0x10: Manual						,
			(Man)						
			0x80: Out of						
			Service (0/S)						

112

7.4.6 Complete list of diagnostic transducer block parameters

	<b>.</b> .						0.1
Index	Parameter	Description / DD Holn	Valid range	Initial value	Unite	Write	Uther
1		The revision level of the static data associated with the function	valiu i alige		Units	moue	R/W Road only
1	51_1(2)	block The revision value will be incremented each time a static		0			iteau onty
		narameter value in the block is changed					
2	TAG DESC	The user description of the intended application of the block.					R/W
3	STRATEGY	The strategy field can be used to identify grouping of blocks. This		0			R/W
		data is not checked or processed by the block.					
4	ALERT_KEY	The identification number of the plant unit. This information may	1 to 255	0	None		R/W
		be used in the host for sorting alarms, etc.					
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.	See MODE	0/S	NA		R/W
6	BLOCK_ERR	This parameter reflects the error status associated with the		0	E		Read only
		hardware or software components associated with a block. It is a					
		bit string, so that multiple errors may be shown.					
7	UPDATE_EVT	This alert is generated by any change to the static data.		Uninitialized			Read only
8	BLOCK_ALM	The block alarm is used for all configuration, hardware,		Uninitialized			Read only
		connection failure or system problems in the block. The cause of					
		the alert is entered in the subcode field. The first alert to become					
		active will set the Active status in the Status attribute. As soon					
		as the Unreported status is cleared by the alert reporting task,					
		another block alert may be reported without clearing the Active					
Q		A directory that specifies the number and starting indices of the	Which at a minimum is		Nono		Road only
/		transducers in the transducer block. For further information	an array of 1 alomont		None		iteau onty
	DIRECTOR	nlease refer to section 3 / 7	containing a 0				
10	TRANSDUCER	Identifies the transducer that follows.	See Standard Tables	65535	E		Read only
	TYPE		(TN-016)	(0xFFFF):			,
				other			
11	TRANSDUCER_	The version of the transducer identified by TRANSDUCER_TYPE	See parameter				Read only
	TYPE_VER	in the form 0xAABB where AA is the major revision of the	description				
		transducer specification on which the transducer is based,					
		and BB is a revision number assigned and controlled by the					
		manufacturer of the device.					
12	XD_ERROR	One of the error codes defined in section 4.4 XD_ERROR and	See section 4.4		E		Read only
		Block Alarm Subcodes below.	XD_ERROR and Block				
			Alarm Subcodes				
13	COLLECTION_	A directory that specifies the number, starting indices, and DD	Legacy, array of one		None		Read only
	DIRECTORY	Item IDs of the data collections in each transducer within a	element = 0.				
		transducer block. For further information, please refer to section					
1/	VCT	3.4.8 above.	0.11.1.1.1.1.1.1	0.11	-		DAM
14		Command for VST (PST or FST) execution. Enumerations defined	U: Un-initialized	U: Un-	E		R/W
	COMMAND	IN Standard Tables (TN-016).	1: Execute VST (store as	initiatized			
			2. Execute VST (store as				
			2: Execute VST (Store as				
			3. Abort stroke test				
			4: Reset VST_RFSULT				
			to 'no initial result'				
			5-7: Reserved				
			8-255: Mfg Specific				

	Parameter					Write	Other
Index	mnemonic	Description / DD Help	Valid range	Initial value	Units	mode	R/W
15	VST_MODE	Specifies different modes of the valve stroke test (start at normal operating position). Enumerations defined in Standard Tables (TN-016).	0: Disable 1: PST for ESD valves 2: FST for ESD valves 3-7: Reserved 8-255: Mfg Specific	0: Disable	E		R/W
16	VST_PAUSE	Pause time between test ramp and ramp back to start position. Delay once the target position is reached prior to returning to the normal operating position. See FF-906 Figure 7.		0	Sec		R/W
17	VST_RESULT	Result of latest valve stroke test. Enumerations defined in Standard Tables (TN-016).	0: No initial results 1: Last VST successful 2: Last VST failed	0: No initial results	E		Read only
18	VST_ DETAILED_ RESULT	Detailed results of valve stroke test if VST_RESULT indicates failure. Enumerations defined in Standard Tables (TN-016).	0: Test command rejected 1: Time Limit Exceeded 2: Pres Limit Exceeded 3: Friction Limit Exceeded 4: PST Travel Limit Exceeded 5: Overridden (abort due to external event) 6-7: Reserved 8-15: Mfg Specific	0: Test command rejected	Ε		Read only
19	CLOSED_POS_ DEADBAND	User defined dead band for the closed position.		0			R/W
20	CLOSED_POS_ SHIFT	Closed position change since last calibration.		0			Read only
21	CUSTOM_ CURVE_ DESCRIPTION	Description of the size of the table and the data type used for table.					Read only
22	CUSTOM_ CURVE_XY_ NUM PTS			0			R/W
23	CUSTOM_ CURVE_ SCALING_ FACTOR	The scaling factor is a divisor value which can be used to obtain fractional values for X and Y.		0			R/W
24	CUSTOM_ CURVE X			0			R/W
25	CUSTOM_ CURVE Y			0			R/W
26	CUSTOM_ CURVE_XY_ FLOAT			0			R/W
27	CYCLE_CNTR_ DEADBAND	User defined minimum movement before incrementing cycle counter.		0	%		R/W
28	FRICTION_ UNITS	Friction units as defined in standard table in (TN-016).	See Standard Tables (TN-016)	0	FU	Man	R/W
29	FRICTION	Calculated dynamic friction value.		0	FU		Read only
30	HYSTERISIS	Maximum measured amount of difference between desired and actual position after a signal reversal.		0	%		R/W
31	POS_ DEADBAND	Configurable dead band for the control algorithm.		0		Man	R/W

Index	Parameter	Description / DD Heln	Valid range	Initial value	Units	Write	Other R/W
32	STROKE_TIME_	The measured time in seconds the valve took in its last	vata range	0	onits	moue	Read only
	CLOSED	movement to go from opened to closed position. It is used to calculate VALVE_CYCLE_TIME.					
33	STROKE_TIME_ OPEN	The measured time in seconds the valve took in its last movement to go from closed to opened position. It is used		0			Read only
34	TRAVEL_ ACCUM_ DEADBAND	to calculate VALVE_UYCLE_TIME. User defined allowable movement before incrementing travel accumulator.		0	%		R/W
35	TRIP_TIMEOUT	Time in seconds beyond which an alert will be set if the target is not reached during an actual trip event. A trip event is defined as the signal from the Safety Logic Solver to the Safety Instrumented positioner causing the positioner to activate its defined safety function as configured.		0	Sec		R/W
36	PSNR_ COMMAND_ FLAGS	Manufacturer specific enumerated procedures.	0: Normal Operation 1-7: Reserved 8-65535: Mfg Specific: 8: Arm 9: Verify Open/Close 10: Verify Opened Position 11: Verify Closed Position 15: Abort	0: Normal Operation	E	Man	RO
37	CYCLE_CNTR_ LIM	User defined limit of cycle counter value that will trigger alert.		0			R/W
38	PST_BREAKOUT_ TIME	Actual delay until valve movement is detected. See FF-906 Fig 3.		0	Sec		Read only
39	PST_BREAKOUT_ TIMEOUT	Allowable delay at start of test to break the valve out of the seat. See graphical definition in FF-906 Fig 3.		0	Sec		R/W
40	PST_INITIAL_ START_TIME	Date and time scheduled for start of initial PST.		01/01/2013 00:00:000			R/W
41	PST_INTERVAL	Time interval between the periodic execution of the partial stroke test (hours). Setting of 0 indicates no PST.		0	Days		R/W
42	PST_OPTIONS	Options which the user may select to influence block behavior during valve stroke test 1. Enumerations defined in Standard Tables (TN-016).	0: Freeze analog Feedback 1: Freeze discrete Feedback 2-7: Reserved 8-15: Mfg Specific	0	E		R/W
43	PST_RAMP_ RATE	Defined rate of travel (% per second) during the valve stroke test. See FF-906 fig 5.		0	%/s		R/W
44	PST_STRK_TRAV	Target position for valve travel during partial stroke test. (PST Target). See FF-906 fig 5.		0	%		R/W
45	PST_STRK_ TRAV TIMEOUT	Allowed time to reach the PST Target. See FF-906 fig 6.		0	Sec		R/W
46	PST_ COMPLETION_ TIMEOUT	Allowed time to perform a complete PST. See FF-906 figure 8.		0	Sec		R/W
47	FST_BREAKOUT_ TIME	Actual delay until valve movement is detected. See FF-906 Fig 10.		0	Sec		Read only

Index	Parameter mnemonic	Description / DD Help	Valid range	Initial value	Units	Write mode	Other R/W
48	FST_BREAKOUT_ TIMEOUT	Allowable delay at start of test to break the valve out of the seat. See FF-906 Fig 10.		0	Sec		R/W
49	FST_RAMP_RATE	Defined rate of valve travel (% per second) during the valve test 100% travel target by default during the FST. See FF-906 figure 11.		0	%/s		R/W
50	FST_STRK_ TRAV_TIMEOUT	Allowed time to reach the fully closed position. See FF- 906 figure 12.		0	Sec		R/W
51	FST_ COMPLETION_ TIMEOUT	Allowed time to perform a complete FST. See FF-906 figure 13.		0	Sec		R/W
52	BLOCK_ERR_ DESC_1	Specific details of a BLOCK_ERR with additional diagnostic information.					Read only
53	DEVICE ERR	Errors preventing proper operation of device.		0			Read only
54	DIAG_CNTR	Communication diagnostic counters. Reset with DIAG_ CLEAR.	DIAG_CNTR(0): DIAG_CNTR(1): Number of resets since last clear DIAG_CNTR(2): DIAG_CNTR(3): DIAG_CNTR(4): DIAG_CNTR(5): DIAG_CNTR(6): DIAG_CNTR(6):				Read only
55	DIAG_CLEAR	User writable to clear diagnostics counters and begin counting from 0 again: CYCLE_CNTR, DIAG_CNTR.	0x0001: Clear DIAG_ CNTR(0): 0x0002: Clear DIAG_ CNTR(1): Number of resets since last clear 0x0004: Clear DIAG_CNTR(2) 0x0008: Clear DIAG_CNTR(4) 0x0020: Clear DIAG_CNTR(5) 0x0040: Clear DIAG_CNTR(6) 0x0080: Clear DIAG_CNTR(7) 0x0100: Clear CYCLE CNTR	0			R/W
56	OUT_LOAD_ STATUS	It indicates the condition of the discrete output load (SOV coil) based on the supply current when the corresponding output is active.	Bit0: Out0 Short Bit1: Out0 Open Bit2: Out1 Short Bit3: Out1 Open	0, no bit set			Read only
57	VALVE_CYCLE_ TIME	The time in seconds the valve took to complete the previous cycle (open + close). It is the same as STROKE_ TIME_CLOSED + STROKE_TIME_OPEN.		0			Read only
58	BREAKAWAY_ TIME	The last reported time taken in seconds for the valve to begin moving (opening or closing). When FPAC is just monitoring the valve (ACTION_ELEMENT = Monitoring) there is no way to measure this time, so it is set to 0.		0			Read only
59	MASKABLE_ SIGNAL	User configurable mask that allows alarms to be linked as discrete parameter.	See MASKABLE_SIGNAL table	0: No Selection			Read only
60	MODULE_IO_ SUMMARY	FPAC generated value indicating whether Dip Switches, Outputs, Auxiliary inputs and sensors are active or not.	See MODULE_IO_SUMMARY table	0			Read only

	Parameter					Write	Other
Index	mnemonic	Description / DD Help	Valid range	Initial value	Units	mode	R/W
61	CYCLE_COUNT_ ALM	Alarm generated when the number of cycles on the first valve exceeds the limit.					Read only
62	CYCLE_TIME_ ALM	Alarm generated when valve does not cycle in the desired time.					Read only
63	HIGH_ TEMPERATURE_ ALM	Alarm indicating that the TEMPERATURE has exceeded the HIGH_TEMPERATURE_LIM.					Read only
64	LOW_ TEMPERATURE_ ALM	Alarm indicating that the TEMPERATURE has exceeded the HIGH_TEMPERATURE_LIM.					Read only
65	CYCLE_TIME_ HISTORY	Last cycle_time, used for trending cycle_time.		0	FPAC1	FPAC1	R/W
66	BLOCK_ALMS_ ACT	Reserved for future use.		0			Read only
67	SUPPORTED_ MODES	Read only parameter that indicates the modes supported by the block.	0x08: Automatic (Auto) 0x10: Manual (Man) 0x80: Out of Service (0/S)	Auto: Man:Oos			Read only

#### 7.4.7 Complete list of resource block parameters

	Parameter							Write	Other
Index	mnemonic	Description / DD Help	Valid range	Default	FCT default	Deep default	Units	Mode	R/W
1	ST_REV	The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.							Read only
2	TAG_DESC	The user description of the intended application of the block.							R/W
3	STRATEGY	The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.							R/W
4	ALERT_KEY	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.	1 to 255				None		R/W
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.	See MODE	0/S	AUTO	AUTO	NA		R/W
6	BLOCK_ERR	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.					E		Read only
7	RS_STATE	State of the function block application state machine.							
8	TEST_RW	Read/write test parameter - used only for conformance testing.							
9	DD_RESOURCE	String identifying the tag of the resource which contains the Device Description for this resource.							

Index	Parameter	Description / DD Help	Valid range	Default	FCT default	Deen default	Units	Write Mode	Other R/W
10		Manufacturer identification number - used by	vada range	WESTLOCK	WESTLOCK	WESTLOCK	onits	Houe	10/11
10	MANOTAC_ID	an interface device to locate the DD file for the							
					= VVIVC =	= WIVC =			
1 1		resource.		UX374343	UX374343	UX374343			
11	DEV_TYPE	Manufacturer's model number associated with		FPACZ =	FPAUZ =	FPACZ =			
		the resource - used by interface devices to		UxUUU1	UxUUU1	UxUUU1			
		locate the DD file for the resource.							
12	DEV_REV	Manufacturer revision number associated with		FPAC2 =	FPAC2 =	FPAC2 =			
		the resource - used by an interface device to		0x05	0x05	0x05			
		locate the DD file for the resource.							
13	DD_REV	Revision of the DD associated with the resource		FPAC2 =	FPAC2 =	FPAC2 =			
		- used by an interface device to locate the DD file		0x01	0x01	0x01			
		for the resource.							
14	GRANT_DENY	Options for controlling access of host computers							
		and local control panels to operating, tuning, and							
		alarm parameters of the block.							
15	HARD_TYPES	The types of hardware available as channel							
		numbers.							
16	RESTART	Allows a manual restart to be initiated. Several	See						
		degrees of restart are possible. They are 1: Run,	description of						
		2: Restart resource, 3: Restart with defaults,	the parameter.						
		4: Restart processor, 5: Restart with factory							
		defaults (same as dipswitch #3), 11: Restart with							
		factory defaults (same as dipswitch #3) and 12:							
		Restart Transducer with factory defaults.							
17	FEATURES	Used to shows supported resource block							
		options.							
18	FEATURE_SEL	Used to select resource block options.							
19	CYCLE_TYPE	Identifies the block execution methods available							
		for this resource. FPAC2 = SCHEDULED.							
20	CYCLE_SEL	Used to select the block execution method for		SCHEDULED					
		this resource.							
21	MIN_CYCLE_T	Time duration of the shortest cycle interval of							
		which the resource is capable.							
22	MEMORY_SIZE	Available configuration memory in the empty							
		resource. To be checked before attempting a							
		download.							
23	NV_CYLE_T	Interval between writing copies of NV							
		parameters to non-volatile memory. Zero means							
		never.							
24	FREE_SPACE	Percent of memory available for further							
		configuration. Zero in a preconfigured device.							
25	FREE_TIME	Percent of the block processing time that is free							
		to process additional blocks.							
26	SHED_RCAS	Time duration at which to give up on computer							
		writes to function block RCas locations.							
27	SHED_ROUT	Time duration at which to give up on computer							
		writes to function block ROut locations.							

	Parameter		Valid		FCT	Deep		Write	Other
Index	mnemonic	Description / DD Help	range	Default	default	default	Units	Mode	R/W
28	FAULT_	Condition set by loss of communication to an output block, failure	-						
	STATE	promoted to an output block or a physical contact. When fault state							
		condition is set, then output function blocks will perform their ESTATE actions							
29	SET_FSTATE	Allows the fault state condition to be manually initiated by selecting							
30	CLR ESTATE	Set. Writing a Clear to this parameter will clear the device fault state if							
00	ULIL_I SIAIL	the field condition, if any, has cleared.							
31	MAX NOTIFY	Maximum number of unconfirmed alert notify messages possible.							
32	LIM_NOTIFY	Maximum number of unconfirmed alert notify messages allowed.							
33	CONFIRM_ TIME	The minimum time between retries of alert reports.							
34	WRITE_LOCK	If set, no writes from anywhere are allowed, except to clear WRITE_							
		LOCK. Block inputs will continue to be updated.							
35	UPDATE_EVT	This alert is generated by any change to the static data.							Read only
36	BLOCK_ALM	The block alarm is used for all configuration, hardware, connection							Read only
		failure or system problems in the block. The cause of the alert is							
		entered in the subcode field. The first alert to become active will set							
		the Active status in the Status attribute. As soon as the Unreported							
		status is cleared by the alert reporting task, another block alert may							
		be reported without clearing the Active status, if the subcode has							
07		changed.							
37	ALARM_SUM	and disabled states of the alarms associated with the function block							
38		Selection of whether alarms associated with the function block will							
50	ACK_OF HON	be automatically acknowledged							
39	WRITE PRI	Priority of the alarm generated by clearing the write lock.							
40	WRITE ALM	This alert is generated if the write lock parameter is cleared.							
41	ITK_VER	This alert is generated if the write lock parameter is cleared.							
42	FD_VER	The major version of the Field Diagnostics specification used for the							
		development of this device.							
43	FD_FAIL_	This parameter reflects the error conditions that are being detected							
	ACTIVE	as active as selected for this category. It is a bit string, so that							
		multiple conditions may be shown.							
44	FD_	This parameter reflects the error conditions that are being detected							
	OFFSPEC_	as active as selected for this category. It is a bit string, so that							
15	ACTIVE	multiple conditions may be shown.							
45		I his parameter reflects the error conditions that are being detected							
	ACTIVE	as active as selected for this category. It is a bit string, so that							
46	ED CHECK	This parameter reflects the error conditions that are being detected							
40	ACTIVE	as active as selected for this category. It is a bit string, so that							
		multiple conditions may be shown.							
47	FD FAIL	This parameter enables or disables conditions to be detected as							
	MAP	active for this alarm category. Thus the same condition may be							
		active in all, some, or none of the 3 alarm categories.							
48	FD_	This parameter enables or disables conditions to be detected as							
	OFFSPEC_	active for this alarm category. Thus the same condition may be							
	MAP	active in all, some, or none of the 3 alarm categories.							

Index	Parameter mnemonic	Description / DD Help	Valid range	Default	FCT default	Deep default	Units	Write Mode	Other R/W
49	FD_MAINT_	This parameter enables or disables conditions to be detected as							
	MAP	active for this alarm category. Thus the same condition may be							
		active in all, some, or none of the 3 alarm categories.							
50	FD_CHECK_	This parameter enables or disables conditions to be detected as							
	MAP	active for this alarm category.							
51	FD_FAIL_	This parameter allows the user to suppress any single or multiple							
	MASK	conditions that are active, in this category, from being broadcast to							
		the host through the alarm parameter.							
52	FD_OFFSPEC_	This parameter allows the user to suppress any single or multiple							
	MASK	conditions that are active, in this category, from being broadcast to							
		the host through the alarm parameter.							
53	FD MAINT	This parameter allows the user to suppress any single or multiple							
	MASK	conditions that are active, in this category, from being broadcast to							
		the host through the alarm parameter.							
54	FD CHECK	This parameter allows the user to suppress any single or multiple							
	MASK	conditions that are active, in this category, from being broadcast to							
		the host through the alarm parameter.							
55	ED FAIL ALM	This parameter is used primarily to broadcast a change in the							
		associated active conditions, which are not masked, for this alarm							
		category to a Host System.							
56	ED OFESPEC	This parameter is used primarily to broadcast a change in the							
	AL M	associated active conditions, which are not masked, for this alarm							
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	category to a Host System							
57	FD MAINT	This parameter is used primarily to broadcast a change in the							
0,		associated active conditions, which are not masked, for this alarm							
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	category to a Host System							
58	ED CHECK	This parameter is used primarily to broadcast a change in the							
00	AL M	associated active conditions, which are not masked, for this alarm							
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	category to a Host System							
59	ED FAIL PRI	This parameter allows the user to specify the priority of this alarm							
0,		category							
60	ED OFESPEC	This parameter allows the user to specify the priority of this alarm							
00	PRI	category							
61	ED MAINT	This parameter allows the user to specify the priority of this alarm							
01	PRI	category							
62	ED CHECK	This parameter allows the user to specify the priority of this alarm							
02	PRI	category							
63	ED SIMULATE	This parameter allows the user to specify the priority of this alarm							
00	10_01102/12	category							
64	FD	This parameter is a device enumerated summarization of the							
04	RECOMMEN	most severe condition or conditions detected. The DD beln should							
	ACT	describe by enumerated action, what should be done to alleviate the							
	101	condition or conditions							
65	BLOCK ERR	New field diagnostics for ITK6							Read only
00	DESC_1								Read only
66	COMPATILITY_	This parameter is optionally used when replacing field devices. The							
	REV	correct usage of this parameter presumes the DEV_REV value of							
		the replaced device is equal or lower than the <code>COMPATIBILITY_REV</code>							
		value of the replacing device.							

	Parameter				FCT	Deep		Write	Other
Index	mnemonic	Description / DD Help	Valid range	Default	default	default	Units	Mode	R/W
67	REVISION_ID	The revision identifier of the device. It shows firmware version for the FPAC module.							
68	REVISION_ DATE	The revision date of the device. It shown firmware release date for the FPAC2 module.							
69	STACK_ REVISION	Revision ID of the Stack in the device.							
70	STACK_DATE	Date information for the Stack in the device.							
71	FBAPP_ REVISION	Revision ID of the Function Block Application in the device.							
72	FBAPP_DATE	Date information for the Function Block Application in the device.							
73	BLOCK_ ALMS_ACT	Reserved for future use.							
74	SUPPORTED_	Read only parameter that indicates the modes supported by	0x08: Automatic						Read
	MODES	the block.	(Auto)						only
			0x10: Manual						
			(Man)						
			0x80: Out of						
			Service (0/S)						

7.5 Appendix E - Wiring instructions for 7345-FC-SRS



# 7.6 Appendix F - Installation in hazardous locations

Refer to TECH-502 for more information.

#### 7.7 Appendix G - Installing DD files

7.7.1 Importing to DeltaV/AMS system This is a step-by-step guide to import the Intellis 7300 (FPAC revision 5) FF DD files into the DeltaV / AMS system using the Delta V program called "ADD DEVICE TYPE":

**Step 1:** Contact Westlock to receive the latest DD files or download directly from the Fieldbus Foundation (now incorporated in the FieldGroup organization) registered products website, link below:

http://www.fieldbus.org/index.php?option=com\_ mtree&task=viewlink&link\_id=1836&ffbstatus= Registered&ltemid=324. See Figure 124. **Step 2:** Unzip the file you downloaded from the FF site (or the one you have received from Westlock) in a temporary directory to use in the next steps. IN THIS CASE, IT IS BETTER TO CHOOSE A DIRECTORY YOU USE FOR THE DDS AND CFFS IN THE DELTAV SYSTEM, AND POINT THE DELTAV SYSTEM SOURCE DIRECTORY TO THE LAST FOLDER (0001). Example: C:/AMS/Devices/FF/574343/0001. See Figure 125.

**Step 3:** Click on Windows' "START" and find the category "AMS Device Manager". Then click on "Add Device Type". See Figure 126.

#### FIGURE 124



#### FIGURE 125



**Step 4:** Click on "Browse" and locate the temporary folder you created in the previous steps to store the DD files. Click on "OK" to proceed. See Figure 127.

**Step 5:** Follow the on-screen instructions and click on "OK" until importing the device type successfully. See Figure 128.

**Step 6:** Now your AMS / DeltaV system has installed all the necessary files to support Intellis 7300 (FPAC revision 5).

7.7.2 Importing to 475/375 field communicator Contact Westlock to get the latest DD support files for field communicators.

**Step 1:** Click on the Fieldbus icon on the first window. Select and click on Utility. See Figure 129.

**Step 2:** Select and click on Available Device Description List. Scroll down until you find WTVC (Westlock Valves & Controls) and open the tree to verify the installed DD (Dev Rev 5 DD Rev 1). If the latest DD is not installed follow the next steps, otherwise skip to step 4. See Figure 130.

FIGURE 127		
CAdd Device Type X	Select Source Directory X	Add Device Type X
To install files for this deectory, click OK	Please choose the install source Plats [C:Wien/SmainDexistig/VPIAC3F_DCP0801_R25/ED0 Discussion	To install files for this directory, click OK
To install files from a different directory, click Browse and select another directory.		To install files from a different directory, click Browse and select another directory.
Source Directory C:\ Bjowse		Source Directory C:\User\Smart\Desktop\FPAC2FF_DDP0501Browse
OK Cancel Help	Dires. C1   OX General	OK Cancel Help

#### FIGURE 128



#### FIGURE 129

HANT	ator Main Menu	M	Fieldbus Application	Fieldbus Application Utility	Available Device Description List /WTVCFPACDev Rev 5 DD Rev 1/	
HART	Tiektbus	Valvet.ink Mobile	Online Utelity Fieldbus Diagnostics	Polling Link Settings Available Device Description List	WIKA WIVC Dev Rev 3 DD Rev 1 Dev Rev 4 DD Rev 1 Dev Rev 5 DD Rev 1	

#### Step 3: DD INSTALLATION

- 3.1 Unzip the DD file in a temporary folder as shown in Figure 131.
- 3.2 Use the Field Communicator Easy Upgrade Utility to get the files in the 475. See Figure 132.
- 3.3 Follow the 475 Field Communicator instructions to complete the procedure.

Step 4: Power up the 475 Field Communicator, connect the 475 bus leads to the Fieldbus test line. Use the FF connections (not the HART) on the top of the 475 by sliding the connector cover to the right. The FPAC2 is not polarity sensitive but the 475 is, so observe polarity. Make sure the Fieldbus segment has power through a Fieldbus power conditioner. Connect the fieldbus cable to the FPAC2 bus connector (pins 1 and 3). Use suitable FF power supply and bus impedance. Install two bus terminators. The bus voltage should be between 9 V and 32 V. Also make sure all switches on the dipswitch are in the OFF position. See Figure 134. **Step 5:** From the 475 Main Menu select Foundation Fieldbus Application. (the Up and Down arrow keys scroll through the icon rows, the Right and Left arrow keys scroll through the icon columns the Enter key selects the highlighted item or press the icon on the touch screen, click YES and make sure the FF communication is running. See Figure 135.

#### FIGURE 131





#### FIGURE 134



Step 6: From the Fieldbus Application Main Menu highlight Online then press the Right Arrow key. If this is not on an active Fieldbus Segment (communicating with a Fieldbus Host or LinkActiveScheduler) then a Warning message will appear saying: "Connection Warning No Fieldbus communication detected. Press OK to connect to this segment anyway. Press CANCEL to go to the Fieldbus Application Main Menu". Press OK to start communication. A warning message "Fieldbus Library System Management Error. SMERROR: FAILED RESPONDER IDENTIFY" may also appear. Press OK to continue. See Figure 136. Step 7: After the 475 finds all the devices on the Fieldbus network select the FPAC2. As soon as the module is energized all LEDs will blink once. If there is communication on the bus the BUS LED will start blinking at a rate around 1 Hz after a few seconds to indicate that the FPAC has established communication with the 475. If the FPAC2 does not appear then hit the Left Arrow key, hit OK then continue as in step 5 above otherwise highlight the FPAC2 and press the Right Arrow key. See Figure 137.

**Step 8:** Scroll down to Device Root Menu and select it by hitting the Right Arrow key. The warning "This device description may not have been tested with this version of Fieldbus Application. Do you want to proceed with this device anyway?" may appear, hit YES and continue. See Figure 138.

#### FIGURE 136





# **INTELLIS** 7300 SERIES

INSTALLATION AND OPERATION MANUAL

#### 7.8 Appendix H - DD Menu tree



#### 7.9 Appendix I - Blocks relationship diagram

The diagram below show the way the function blocks (DO, DI and AI) connect to the transducer blocks through the I/O channels and the most important parameters involved:



#### 7.10 Appendix J - Cycle time measurement timing diagram

See below a timing diagram that illustrates the way the parameters VALVE\_CYCLE\_TIME, STROKE\_TIME\_CLOSE, STROKE\_TIME\_OPEN and BREAKAWAY\_TIME are measured depending on the applications (ACTION\_ELEMENT parameter):



#### 7.11 Appendix K - List of useful technical notes

The following Technical Notes are available with more installation and configuration examples as we as solutions for some common problems:

Reference #	Description
TN-2014-001	Importing Intellis 7300 (FPAC) FF DD files into the AMS DeltaV system
VCIOM-05124	How to replace an old FPAC (rev 2, 3 or 4) with a new FPAC2 (rev 5)
TN-2014-003	How to install Intellis 7300 (FPAC) support files into 475-375 handheld
TN-2014-004	Quick configuration for the Intellis 7300 (FPAC2) using NI-FBUS Configurator
TN-2014-005	Intellis 7300 (FPAC2) basic configuration examples
TN-2014-006	Installing NI-FBUS Tools and DD support for FPAC2-ZRF2 device revision 5
TN-2014-007	Quick configuration for the Intellis 7300 (FPAC2) using 475 Field Communicator
TN-2014-011	FPAC2 controlling one single valve using DeltaV-AMS



#### www.westlockcontrols.com

Westlock. We reserve the right to change designs and specifications without notice.